

SX-100®

SX-200®

SUPERSWITCH®

VOLUME II
GENERIC ACD



SX-200

WARNING

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

SX-100

WARNING

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.



SX-100®/SX-200®**SUPERSWITCH®****AUTOMATIC CALL DISTRIBUTION SYSTEM****DOCUMENTATION INDEX****1. GENERAL**

1.01 This Section lists MITEL Standard Practices which have been issued pertaining to the SX-100/SX-200 Automatic Call Distribution Systems.

2. DOCUMENTATION INDEX

2.01 The complete set of Practices are contained in two volumes as listed in Table 2-1. Volume I basically covers the description and operation of the Systems. Volume II is concerned with the installation aspects of the systems. All installation forms are located in Volume III. All troubleshooting information is contained in Volume IV.

2.02 Sections commencing with MITL9105- and MITL9110- contain information specific to the SX-100/SX-200 Systems respectively, while those commencing with MITL9105/9110- embrace both types of Systems.

**TABLE 2-1
PRACTICE INDEX**

VOLUME I	
Section No.	Title
MITL9105/9110-090-000-NA	Documentation Index
MITL9105/9110-090-100-NA	General Description
MITL9105/9110-090-105-NA	Feature and Services Description
MITL9105/9110-090-106-NA	Feature and Services Description
MITL9105/9110-090-107-NA	Feature and Services Description
MITL9105/9110-090-150-NA	Physical Description and Ordering Information
MITL9105/9110-090-180-NA	Engineering Information
MITL9105/9110-090-212-NA	Multi-Digit Toll Control
MITL9105/9110-090-213-NA	Automatic Route Selection
MITL9105/9110-090-220-NA	Speed Call
MITL9105/9110-090-222-NA	Automatic Call Distribution Description
MITL9105/9110-090-315-NA	Attendant Console Description
MITL9105/9110-090-450-NA	Traffic Measurement
MITL9105/9110-090-451-NA	Station Message Detail Recording
MITL9105/9110-090-500-NA	General Maintenance Information
VOLUME II	
Section No.	Title
MITL9105/9110-090-000-NA	Documentation Index
MITL9105/9110-090-200-NA	Shipping, Receiving and Installation
MITL9105/9110-090-210-NA	System Programming
MITL9105/9110-090-215-NA	Installation Test Procedures
MITL9105/9110-090-320-NA	Extension Test Procedures
VOLUME III	
INSTALLATION FORMS	
VOLUME IV	
Section No.	Title
MITL9105/9110-090-350-NA	Troubleshooting

SX-100* AND SX-200*
SUPERSWITCH*
AUTOMATIC CALL DISTRIBUTION SYSTEM
SHIPPING, RECEIVING AND INSTALLATION INFORMATION
GENERIC ACD

	CONTENTS	PAGE
1. INTRODUCTION		1
General		1
Reason for Issue		1
Documentation		1
SUPERSET 4*		1
SUPERSET 3*		1
2. IDENTIFICATION		2
General		2
Equipment Cabinet, SX-100		2
Equipment Cabinet, SX-200		2
Equipment Shelves		6
Circuit Cards		7
Equipment Shelf and Card Identification		8
Features and Services		8
Attendant Console		9
Connecting Cables		9
Power Fail Transfer		9
Power Fail Transfer Reset		10
Test Line		11
Reserve Power Supply		11
Paging, Dictation, and Music on Hold Equipment		11
Night Relays		11
3. SHIPPING AND RECEIVING		12
Introduction		12
System Shipment		12
4. PACKAGING		12
System Package		12
Consoles		12
Equipment Shelves		12
Reserve Power Shelf		13
Printed Circuit Cards		13
5. DELIVERY CHECK		13
6. UNPACKING AND HANDLING		18
Cabinet		18

Copyright of MITEL Corporation 1983

Shelves and Circuit Cards	18
7. INSPECTION	18
Cabinet	18
Shelves	18
Cards	19
Defective Items	19
8. REPACKING FOR RESHIPMENT	19
9. INSTALLATION REQUIREMENTS	19
Environmental Requirements	19
Floor Space	19
Equipment Cabinet Location	20
Power Supply Requirements	22
Equipment Grounding	22
10. CABLING AND CROSS-CONNECTIONS	23
General	23
Telephone Set and Trunk Cabling	23
Cable Terminations, SX-100	23
Cable Terminations, SX-230	20
Cross-Connections	26
FCC Cross-Connect Field Recommendations	26
11. DESIGNATIONS	26
General	26
12. INSTALLATION	27
General	27
Precautions	27
13. SUPERSET	28
General	28
Installation	28
APPENDIX 1	
MITEL ACTION PROCEDURES	A1-1
APPENDIX 2	
FCC INTERCONNECTION REQUIREMENTS	A2-1
APPENDIX 3	
SX-100 INSTALLATION PROCEDURES	A3-1/2
Unpack SX-100 Equipment (MAP200-301)	A3-3
Unpack Consoles (MAP200-302)	A3-7
Install Console Faceplate Designations (MAP200-303)	A3-11
Inspect Equipment (MAP200-304)	A3-17
Install and Connect Equipment (MAP200-305)	A3-21
Set Card Switches (MAP200-306)	A3-29/30
Power-Up System (MAP200-307)	A3-31
APPENDIX 4	
SX-200 INSTALLATION PROCEDURES	A4-1/2

Unpack Equipment Cabinet (MAP200-401)	A4-3
Inspect Equipment (MAP200-404)	A4-7
Connect Cables (MAP200-405)	A4-11
Set Card Switches (MAP200-406)	A4-15/16
Power-Up System (MAP200-407)	A4-17

APPENDIX 5

CARD SWITCH SETTINGS	A5-1/2
Set CO Trunk Option and Status Switches (Type 011/111) (MAP200-501)	A5-3
Set E and M Trunk Option Switches (MAP200-502)	A5-11
Set DID/Tie Trunk Option Switches (MAP200-503)	A5-19
Set Scanner Card Switches (MAP200-504)	A5-27
Set RAM/COS Switches (MAP200-505)	A5-33
Set CO Trunk Switches (Type 211/311) (MAP200-506) ...	A5-37
Set IPC Battery Switch (MAP200-507)	A5-45
Install SX-100 Fan Update Kit (MAP200-508)	A5-49
Install SUPERSET 3/4 (MAP200-509)	A5-53

APPENDIX 6

ADDITIONAL EQUIPMENT INSTALLATION	A6-1/2
Shell 2 Installation (MAP200-601)	A6-3
Install New Cards (MAP200-602)	A6-9
Reserve Power Supply Installation (SX-200) (MAP200-603)	A6-21
Console Interface Board Installation (MAP200-604)	A6-31
Backplane Translator Board Installation (MAP200-605) ...	A6-41
Installation of RCP Card (MAP200-606)	A6-51
Reserve Power Supply Installation (SX-100) (MAP200-607)	A6-57
Printer Installation (MAP200-608)	A6-69
Static Ground Strap Installation (MAP200-609)	A6-77
Customer Data Dump/Load (MAP200-610)	A6-79
Installation of RAC Card (MAP200-611)	A6-85

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
2-1	SX-100 Equipment Cabinet	3
2-2	SX-200 Equipment Cabinet	4
2-3	Equipment Shelf	5
2-4	Typical Circuit Card	8
2-5	Attendant Console	9
4-1	SX-100 System Packaging	13
4-2	SX-200 System Packaging	14
4-3	Console Packaging	15
4-4	Equipment Shelf Packaging	16
4-5	Circuit Card Packaging	17
9-1	SX-100 Minimum Equipment Cabinet Floor Space Requirements	20
9-2	SX-200 Minimum Equipment Cabinet Floor Space Requirements	21
10-1	Station and Console Cabling Requirements	24
10-2	SX-100 Connector Locations	25
10-3(a)	SX-200 Connector Locations	49

10-3(b)	SX-200 Connector Locations	50
10-4	Power Fail Transfer Block Diagram	50
10-5	Power Fail Transfer Wiring Diagram	51
10-6	Night Bell Connections	52
10-7	Music and PA Connections	53
11-1	Typical Terminal Layout	54
12-1	Static Protection Ground Strap	55

LIST OF TABLES

TABLE	TITLE	PAGE
1-1	Documentation	1
2-1	Physical Characteristics	6
2-2	Equipment Coding	6
11-1	Terminating Procedure	27
10-1	Shelf 1 External Plug and Jack Connections	29
10-2	Interconnect Board Plug and Jack Connections	35
10-3	Power Fail Transfer Board Plug and Jack Connections	42
10-4	Shelf 2 External Plug and Jack Connections	43
10-5	Console Interface Board Plug and Jack Connections (SX-200 only)	47

1. INTRODUCTION

General

1.01 This Section provides general identification, installation, shipping, receiving and cabling information for the SX-100 and SX-200 ACD Systems. The systems consist of two major components: the equipment cabinet, containing the switching equipment and power supply; and the attendant console(s).

Reason for Issue

1.02 This Section has been issued to provide information concerning the ACD system.

Documentation

1.03 Table 1-1 lists all MITEL practices, associated with the ACD System.

SUPERSET 4

1.04 For information on the SUPERSET 4 see Section MITL9105/9110-090-107-NA.

SUPERSET 3

1.05 For information on the SUPERSET 3 see Section MITL9105/9110-090-106-NA.

**TABLE 1-1
DOCUMENTATION**

Document No.	Title	Applicable to	
		SX-100	SX-200
MITL9105/9110-090-100-NA	General Description	*	*
MITL9105/9110-090-105-NA	Features Description	*	*
MITL9105/9110-090-150-NA	Physical Description and Ordering Information	*	*
MITL9105/9110-090-180-NA	Engineering Information	*	*
MITL9105/9110-090-200-NA	Shipping, Receiving and Installation	*	*
MITL9105/9110-090-210-NA	System Programming	*	*
MITL9105/9110-090-212-NA	Multi-Digit Toll Control	*	*
MITL9105/9110-090-213-NA	Automatic Route Selection	*	*
MITL9105/9110-090-215-NA	System Test Procedures (Installation)	*	*
MITL9105/9110-090-220-NA	Speed Call	*	*
MITL9105/9110-090-222-NA	Automatic Call Distribution Description	*	*
MITL9105/9110-090-315-NA	Attendant Console Description	*	*
MITL9105/9110-090-320-NA	Station Test Procedures	*	*
MITL9105/9110-090-350-NA	Troubleshooting Instructions	*	*
MITL9105/9110-090-450-NA	Traffic Measurement	*	*
MITL9105/9110-090-451-NA	Station Message Detail Recording	*	*
MITL9105/9110-090-500-NA	General Maintenance Information	*	*

2. IDENTIFICATION

General


- 2.01** The SX-100 and SX-200 are providing the following capacities:
- **SX-100:** Capacity of 160 ports with 112 ports available for lines, trunks and additional receivers.
 - **SX-200:** Capacity of 256 ports with 208 ports available for lines, trunks and additional receivers.
- 2.02** The systems are electrically compatible with most existing station, key telephone, Private Branch Exchange (ACD) and Central Office (CO) equipment. The ACD's provide:
- The use of a flexible numbering plan.
 - The simultaneous use of DTMF and rotary dial stations.
 - Optional use of attendant consoles - two maximum.
 - Extensive selection of standard and optional features.
 - A data port facility for traffic analysis and other requirements.
 - Freedom from scheduled maintenance.
 - Automatic diagnostics.
 - Six power fail transfer trunks (SX-100).
 - Twelve power fail transfer trunks (SX-200).
 - Optional reserve power supply.
 - SUPERSET 4.
 - SUPERSET 3.

Equipment Cabinet, SX-100


2.03 The SX-100 equipment cabinet (Figure 2-1) consists of a metal frame enclosed by back and top panels. Access to the equipment shelf is provided by the front door of the cabinet. The rear panel allows access to the line and trunk cable plugs.

Equipment Cabinet, SX-200

2.04 The SX-200 equipment cabinet (Figure 2-2) consists of a metal frame which is enclosed by side and top panels. Access to the equipment shelves is provided by the front door of the cabinet. The hinged rear panels hold the power supply and allow access to the line and trunk cable plugs.



FRONT VIEW




REAR VIEW

WEIGHT	HEIGHT	WIDTH	DEPTH
70 lb (31.8 kg)	16.82 in. (422 mm)	25.0 in. (635 mm)	18.5 in. (470 mm)

X5811

Figure 2-1 SX-100 Equipment Cabinet



X3510

Figure 2-2 SX-200 Equipment Cabinet




Figure 2-3 Equipment Shelf

**TABLE 2-1
PHYSICAL CHARACTERISTICS**

Shelf Type	SX-100 Part Number	SX-200 Part Number	Weight		Maximum No. Circuit Cards
			lb	kg	
Maintenance Panel	9105-025-000	9110-125-000-NA	2	0.9	-
Equipment Shelf	9110-012-000-NA	9110-012-000-NA	38	17	21
Reserve Power	9105-014-000-NA	9110-014-000-NA	125	57	-
Primary Power	9105-008-000	9110-008-000-NA or 108-000-NA	16/70	7/32	-

**TABLE 2-2
EQUIPMENT CODING**

Type	Part Number	Card Extractor Color Code
Equipment Shelf (Note 1)	9110-012-000-NA	-
IPC Card	9110-203-217-NA	Red
Scanner Card	9110-104-000-NA	Orange
Tone Control Card	9110-005-000-NA	Yellow
Console Control Card	9110-006-000-NA	Green
Remote Control - ACD Card (Note 2)	9110-017-000-NA	Green
Receiver Card (Dual or Quad)	9110-109-000-NA or -016-000-NA	Blue
CO Trunk Card (4 trunk)	9110-011-000-NA or -211-000-NA	Black
E&M Trunk Card (2 trunk)	9110-013-000-NA	Black
DID/Tie Trunk Card (2 trunk)	9110-031-000-NA	Black
Line Card (8 station)	9110-110-000-NA	Black
RAC Module	9110-073-000-NA	-
RAC Card 1 module	9110-072-001-NA	Black
RAC Card 2 modules	9110-072-000-NA	Black

Note: 1. All equipment shelves are identical.

2. The RCP is supplied only if required that the ACD be accessed by RMA facilities (see Section MITL9105/9110-098-101-NA, Remote Maintenance Administration and Test System).

2.05 Reserve power for the SX-200 system, if required, may be supplied from the optional battery pack shelf located at the bottom of the equipment cabinet. In the case of the SX-100 reserve power supply, it forms a separate base unit upon which the SX-100 can be installed.

Equipment Shelves

2.06 The SX-100 is equipped with one shelf, but the SX-200 may be equipped with one or two equipment shelves depending on the number of lines and trunks required. Each equipment shelf (Figure 2-3) is 10.75 in. (273 mm) high, 19 in. (485 mm) wide and 16.375 in. (415 mm) deep. The shelves are mounted in the equipment cabinet with the backplane assembly towards the rear of the cabinet. The shelves are

held in position by mounting screws which locate the shelves in the main frame.

2.07 The physical characteristics and part numbers of the shelves, power supplies and maintenance panel are given in Table 2-1. The weight for each shelf is for a shelf containing a full complement of circuit cards.

2.08 The equipment shelves used in the SX-100 and the SX-200 are identical. Figure 2-3 shows two views of an equipment shelf.

2.09 The equipment shelves hold up to 20 circuit cards. Each card plugs into a connector mounted on the shelf backplane. A locking bar assembly which passes through the sides of the shelf ensures that the circuit packs are seated correctly in the backplane connectors.

2.10 A number of card positions within each shelf are reserved for control cards. These card positions are identified by color-coded identification strips along the top and bottom edges of the shelf. Only cards with locking clips of the same color as the identification strip should be plugged into that card position. Circuit card and/or system damage may otherwise occur.

2.11 Card positions 14, 13, and 12 on equipment shelf 1, may be used for line, trunk or receiver cards. These positions are marked with a blue and black identification strip, indicating that any card coded with either of the identification color codes may be used in these positions.

2.12 Line or trunk cards can be placed in any position identified with black color-coded strips. It is recommended that line cards be placed in the lowest numbered card positions and trunk cards in the highest card positions for the following reasons:

- The maintenance test line is permanently wired to card position 1, hardware position 001.
- Separation of line and trunk cards allow ease of identification of card type during installation and maintenance.
- Ease of system programming.

Note: If more than one receiver card is used the second receiver card **MUST** be placed in card position 14, the third in position 13, and the fourth in position 12. It is therefore recommended that these card positions be used for trunk cards only when all other card positions are in use.

Circuit Cards

2.13 The circuit cards (Figure 2-4) used in the equipment shelves measure 10 in. (254 mm) high, 13 in. (330 mm) deep, and are manufactured from fiberglass board. The light-emitting diodes (LED's)

mounted at the front of each card indicate the operational status of the card. The transparent front panel protects the LED's while allowing their status to be observed.

2.14 On the front panel of each card, is the card part number and its type. Cards which must not be removed or inserted while the system power is on carry a Caution notice as shown in Figure 2-4.

2.15 Each card is equipped with two card extractors which enable the card to be easily removed. In the locked position the card extractors, in conjunction with the locking bar, ensure that the circuit cards are held firmly in position.

Equipment Shelf and Card Identification

2.16 Table 2-2 lists all shelf and card part numbers, and color codes.

Features and Services

2.17 The features and service codes are entered into the system memory through a console. No wiring or strapping is required when assigning features.





Figure 2-4 Typical Circuit Card



X3479R6

Figure 2-5 Attendant Console

Attendant Console

2.18 The attendant console (Figure 2-5) is a self-contained unit, connected to the equipment cabinet by a plug-ended 25-pair cable.

2.19 The console is equipped with two sets of handset/headset jacks. These jacks will accept all standard handsets or headsets presently in general use.

Connecting Cables

2.20 All connections to the attendant console and the equipment cabinet are made using plug- or connector-ended 25-pair cables.

Power Fail Transfer

2.21 In the event of a major alarm condition, the power fail transfer relays located on the Power Fail Transfer card, will connect Central Office trunks to selected station lines (maximum 6 trunks for

SX-100, 12 trunks for SX-200). Power fail transfer will take place under any of the following conditions:

- Commercial power failure (if no reserve power supply is used).
- Common control failure.
- Operating voltage out of accepted tolerance.
- Manual transfer from a console or the equipment cabinet.

(a) **Incoming Calls.** After a power fail transfer has occurred, ringing of extensions for incoming calls is applied directly to the selected extension line from the Central Office (CO).

(b) **Outgoing Calls.** To place an outgoing call through a ground start CO trunk, with the system in the power fail transfer mode, the extension originating the call must be equipped with a ground key. When the ground key is momentarily pressed, a ground is applied to the Ring side of the line, energizing the CO equipment. One side of the ground key must be connected to a ground and the other to the Ring conductor of the station line. Call origination over loop start trunks does not require the use of a ground start key.

Power Fail Transfer Reset

2.22 The system may be returned to normal operation from power fail transfer in one of three ways:

(a) **Major Alarm:** If the system was placed in the power fail transfer mode because of a major alarm condition, it will return to normal operation and turn off the major alarm lamp when the alarm condition is corrected.

(b) **Manual Reset:** When the system has been placed in the power fail transfer mode by operation of the switch, the major alarm lamp will light, indicating that transfer has taken place. Setting the transfer switch to NORMAL will reset the system to normal operation and turn off the alarm lamp if the alarm condition has been corrected. If the alarm condition has not been corrected, the alarm lamp will remain lit, indicating that the system has remained in the power fail transfer mode.

(c) **Reset from Commercial Power Failure:** The system will automatically return to normal operation when commercial power is restored.

Note: When the system returns to normal operation from the power fail transfer mode, all connections established through the power fail transfer circuits will be maintained until the completion of the calls.

Test Line

2.23 The test line, permanently assigned to hardware position 001, has the Tip and Ring connections wired to the two terminals on the face of the maintenance panel. The service can:

- seize individual trunks
- seize individual receivers
- seize individual speech paths
- initialize card slot
- busy out selected receivers, trunks or speech paths
- clear all alarms and raise associated busy-out conditions
- reset the system
- initiate a system dump
- control the printer.

Reserve Power Supply

2.24 The optional reserve power supply (in the form of batteries and charging system) is housed in the SX-200 equipment cabinet or in a package that forms a base for the SX-100 cabinet. The power supply is designed to maintain system operation for a minimum of two hours in the event of main power failure.

Paging, Dictation, and Music on Hold Equipment

2.25 All paging, dictation and music on hold equipment is located external to the ACD. This equipment should be located in an environment specified by the individual supplier and connected to the ACD through the cross-connect field.

Night Relays

2.26 Four relays are provided for use during night service. One is operated permanently during night service, and the other three may be assigned to various trunks to ring night bells. Power, supplied from the supply and required to operate night bells, must be connected at the cross-connect field.

3. SHIPPING AND RECEIVING

Introduction

- 3.01 This Part describes the procedures to be used when shipping or receiving the Electronic ACD equipment.

System Shipment

- 3.02 The ACD cabinet is shipped in a single carton containing the equipment cabinet. The consoles and reserve power supply, if required, are packaged and shipped separately from the system equipment package.

4. PACKAGING

System Package

- 4.01 The equipment is shipped complete with one shelf and with some cards in position. The equipment cabinet is enclosed in a polyethylene sheet and positioned on the shock-absorbant shipping pallet. A styrofoam sheet is placed around and on top of the cabinet to protect it from damage, and the complete assembly encased in a triwall sleeve. Four transportation straps are then fastened to the pallet to prevent any movement of the cabinet package. The tri-wall cap is placed over the sleeve and the complete assembly secured to the shipping pallet by two metal retaining straps. Figure 4-1 and 4-2 respectively show the packaging arrangements for the SX-100 and SX-200.

Consoles

- 4.02 Each console is wrapped in a polyethylene sheet and placed in a cardboard packing carton and protected with shock-absorbant foam inserts. The handset and cradle are placed in bags and inserted in the corners of the box at one end. The console manual is placed at the other end of the box, and the Extension Features Operation booklets are distributed in the box to fill the available space. The completed package is secured with fiberglass tape (Figure 4-3).

Equipment Shelves

- 4.03 Equipment shelves, when shipped separately, are packaged in a similar manner. A shelf, with all cards removed, is enclosed in a cardboard protector to prevent damage to the shelf backplane. The protected shelf is then wrapped in a polyethylene sheet placed in a formed foam insert. The complete assembly is finally encased in a packing carton and secured by fiberglass tape (Figure 4-4).




Figure 4-1 SX-100 System Packaging

Reserve Power Shelf


4.04 The method of packaging the reserve power shelf is the same as for equipment shelves, except a heavy duty commercial packing carton is used in place of the regular packing cartons, due to the weight of the battery packs in the reserve power shelf.

Printed Circuit Cards

4.05 All printed circuit cards, if shipped separately, are packaged as shown in Figure 4-5. If a larger number of circuit cards are to be shipped, they are individually packed and shipped in groups of ten per carton.


5. DELIVERY CHECK

5.01 At the time of delivery at the installation site, all items delivered must be checked against the order form and packaging slip. Any discrepancies must be reported immediately.




X288R1

Figure 4-2 SX-200 System Packaging



(a) CONSOLE PACKAGING -
(FOR SHIPMENT IN SX-200 1 - SHELF CABINET)



(b) CONSOLE PACKAGING -
(FOR SEPARATE SHIPMENT)

X204R2

Figure 4-3 Console Packaging




Figure 4-4 Equipment Shelf Packaging

X285




Figure 4-5 Circuit Card Packaging

6. UNPACKING AND HANDLING

Cabinet

6.01 The procedures to be used when handling and unpacking the equipment are detailed in Appendices 3 and 4.

Shelves and Circuit Cards

6.02 Shelves and circuit cards shipped separately from the equipment cabinet should not be unpacked before they are required for use. When required, the shelf and cards are to be transported to the equipment location packaged in their original containers when possible.

7. INSPECTION

Cabinet

7.01 After positioning and unpacking the equipment, a visual inspection should be performed prior to installation to ensure that:

- (a) The cabinet has not been dented or scratched during shipment.
- (b) The door on the front of the cabinet opens and closes easily.
- (c) The shelves are mounted firmly in the cabinet.
- (d) The shelves are not bent or otherwise damaged.
- (e) All cards are seated firmly in their connectors.
- (f) Rear doors open and close easily.
- (g) All components mounted in the rear panel power supply are secure.
- (h) All interconnecting cables and plugs are secure.
- (j) All connections to the power supply are tight.

Shelves

7.02 Inspect the shelf to ensure that:

- (a) Edge connector contacts are undamaged and do not contain any foreign matter.
- (b) No circuit card guides are broken.
- (c) No wires are broken.
- (d) The backplane is not cracked.

- (e) No connector pins are broken or bent.

Cards

Caution: Handle Circuit Cards by their edges only. Handling the board faces or components may cause damage. At all times wear a static-preventing wrist strap.

7.03 If printed circuit cards are shipped separately from the equipment, inspect each circuit card to ensure that:

- (a) The fiberboard is not cracked.
- (b) No loose leads or components are apparent.
- (c) The card front panel is not broken. Circuit cards shipped in the equipment do not require individual inspection unless equipment shelf damage has been found.

Defective Items

7.04 If any defective item is found, it should be tagged and returned to the supplier in accordance with accepted procedures (see Part 8).

8. REPACKING FOR SHIPMENT

8.01 When the ACD equipment is shipped from one location to another, all items must be packaged to prevent damage. Figures 4-1 through 4-5 show how the equipment was originally packaged. This method of packaging should be followed as closely as possible.

8.02 If the original packaging material is no longer available, the returned parts should be wrapped in several layers of air-cushion type wrap, placed in a suitable container, and surrounded with paper to minimize movement of the items.

9. INSTALLATION REQUIREMENTS

Environmental Requirements

9.01 The ACD equipment cabinet may be installed in any location which fulfills the requirements of 9.02, and is within the following temperature and humidity limits:

- Temperature 0-40°C (32-104°F)
- Relative Humidity 10-90% (noncondensing)

Floor Space

9.02 The minimum floor space for installation and subsequent maintenance of the SX-100 and SX-200 ACD's is shown in Figures 9-1 and 9-2 respectively.




Figure 9-1 SX-100 Minimum Equipment Cabinet Floor Space Requirements

Equipment Cabinet Location

9.03 The following requirement must be met when selecting a location for the ACD equipment. For cooling purposes the ACD cabinet equipments use natural air convection flow. For this reason the bottom areas of the cabinets must be allowed free air flow and must not be obstructed, for example, by rug pile blocking the air vent entries.

The location MUST BE:

- Dry and clean
- Well ventilated
- Well lit
- Easily accessible.




Figure 9-2 SX-200 Minimum Equipment Cabinet Floor Space Requirements

The location MUST NOT BE:

- Near a sprinkler system, sweating pipes, steam pipes or steam vents
- In areas with extreme heat or cold
- In areas where corrosive fumes or exhaust from machinery is present
- In passageways used for moving equipment
- Next to a reproducing or copying machine. A minimum clearance of 10 feet (3 m) must be provided and the room should be ventilated by an exhaust fan if the reproducing machine is not equipped with a filtering system.

Power Supply Requirements

9.04 The customer must provide a single phase power receptacle, with the following recommendations:

- 115 V, 60 Hz fused, and capable of delivering 4 A; or 250 V, 50 Hz fused, and capable of delivering 2 A.
- The power receptacle should be wired and fused independently from all other receptacles.
- A warning tag should be attached to circuit-breaker-type fuses to prevent unauthorized manual operation.
- The power receptacle must not be controlled by a switch.
- The live and neutral conductors at the receptacle shall be wired to their proper respective connections.
- The power receptacle must be a 3-wire type, with the wire connected to the ground of the electrical system.
- The receptacle should be easily accessible for the removal of the plug for maintenance.
- The receptacle location should be selected to prevent accidental removal of the power cord.
- The power cord between the cabinet and the receptacle should not present a hazard to the subscriber.
- A warning tag should be attached to the plug-end of the power cord to prevent accidental removal of the cord by the subscriber.

Equipment Grounding

9.05 The following is a description of the required ACD equipment grounding practice:

- (a) All circuit commons within the cabinet shall derive ground from a single ground concentration point within the cabinet. Each cabinet's ground concentration point shall derive ground from a single ground concentration point serving all system cabinets and peripherals collocated with the system.
- (b) The system cabinets and all associated ducting hardware along with all collocated peripherals shall not be exposed to any ground source other than the system single point ground described in (a) above.
- (c) AC service wires bringing AC power to the cabinets shall not share an enclosure or raceway with other system grounds, DC power distribution wires, or signaling wires. All nonconnec-

torized AC power terminations shall be enclosed by raceways and termination boxes whether these enclosures appear outside or within system cabinets. This is to ensure AC service wires cannot fault the circuitry within system cabinets or associated ducting hardware.

- (d) All system hardware shall be provided with an AC fault return path to the system single point ground which in turn shall be provided with a reliable path to the equipment grounding conductor (i.e. green wire ground or safety ground). The path from system equipment to system single point ground need not be a direct dedicated path but can be any reliable path to other system hardware which receives the above grounding path.
- (e) All sources of external ground (i.e. system signaling ground to the approved ground source, etc) shall connect only to the system single point ground. The intent of providing for a system point ground is to minimize ground loops and prevent lightning from finding a path through system components.
- (f) A separate grounding conductor (minimum size, 14 AWG) shall be separately run from the system single point ground to the communications ground system on the cross-connect field.

10. CABLING AND CROSS-CONNECTIONS

General

10.01 This Part details the cabling and cross-connections required when installing the ACD.

Telephone Set and Trunk Cabling


10.02 Telephone set and trunk cabling terminates on the building cross-connect terminal in the normal manner. The cabling requirements and limits for stations and consoles are shown in Figure 10-1 (a) and (b).

Cable Terminations, SX-100

10.03 All interconnecting cables must be terminated in accordance with Tables 10-1, 10-2, and Figure 10-2.


Cable Terminations, SX-200

10.04 All interconnecting cables must be terminated in accordance with Figure 10-3 and Tables 10-1, 10-2, 10-3 and 10-5. In addition if shelf 2 is installed, the interconnecting cables listed in Table 10-4 must be terminated.



NOTE: STATION LOOP LIMIT 1200 OHMS (INCLUDING STATION SET)
SUPERSET LOOP LIMIT 200 OHMS

(a) STATION CABLING & LIMITS




NOTE: CABLING LIMIT 1000 FT. (305 m) - 26 AWG MINIMUM
CABLE CONSOLE TO EQUIPMENT CABINET.

(b) ATTENDANT CONSOLE CABLING & LIMITS

X267R2

Figure 10-1 Station and Console Cabling Requirements



BOARD	CONNECTOR NO.	DESTINATION	BOARD	CONNECTOR NO.	DESTINATION
SHELF BACKPLANE	P1	X - CONNECT	INTERCONNECT	J13	MAINTENANCE CONSOLE
	P2	X - CONNECT		J14	ATTENDANT CONSOLE 2
	P3	X - CONNECT		J15	ATTENDANT CONSOLE 1
	P4	X - CONNECT		P16	P6
	P5	P17		P17	P5
P6	P18	P18		X - CONNECT	
NOTE: ALL PLUGS AND CONNECTORS EXCEPT AS NOTED ARE STANDARD 25- PAIR (AMPHENOL TYPE). THE MALE AND FEMALE DESIGNATORS REFER TO THE CONNECTORS MOUNTED ON THE EQUIP- MENT, NOT TO THE CABLE CONNECTORS. MALE = P FEMALE = J				P19	X - CONNECT
				P20	X - CONNECT
				J302	LOCAL TERMINAL
				P301	MAINTENANCE PANEL

X1315R2

Figure 10-2 SX-100 Connector Locations

Cross-Connections

- 10.05 Jumpers should be run using Z-type 24 AWG cross-connecting cables.
- 10.06 Connection between the equipment cabinet, cross-connect field, stations, trunks and consoles should be made using 26 AWG connector-ended cable in accordance with Tables 10-1 through 10-5.
- 10.07 Cabling connections between shelf 1, the interconnect board, and cross-connect field are shown in Figures 10-2 and 10-3.
- 10.08 Figures 10-4 and 10-5 illustrate typical block and wiring diagrams for a power fail transfer circuit. Figure 10-6 illustrates typical night bell wiring connections and Figure 10-7 shows the connections for music and PA requirements.
- 10.09 When backplane translator boards are used with the lines and trunk circuits, different terminal connections result. In this case the cabling arrangements must conform to the termination connections shown in Figure 605-2, MAP200-605, Appendix 6.

FCC Cross-Connect Field Recommendations

- 10.10 Trunk circuits must be connected to the telephone company interface jack sequentially. A cross-connect field is necessary to separate the lines and trunks which occur in the same cable that is connected to the shelf connector.
- 10.11 All cables containing trunk circuit pairs must be connectorized; thus, the cross-connect field must also be connectorized. Refer to Appendix 2 for details.

11. DESIGNATIONS

General

- 11.01 Designations are an integral part of the installation procedures. Correct identification of all cables and terminations improves service by reducing search time.
- 11.02 Modular cross-connecting fields are referenced to throughout this description. The procedure for terminating the cables and equipment are shown in Table 11-1 and Figure 11-1.

TABLE 11-1
TERMINATING PROCEDURE

STEP	ACTION
1	Mount cross-connecting blocks
2	Run and connect building cables
3	Identify cables using identification tape
4	Attach designation strips if required to cross-connecting blocks
5	Run and connect equipment cables
6	Run and connect required jumpers

12. INSTALLATION

General

12.01 The SX-100 and SX-200 systems should be installed in accordance with the following steps:

- (a) Consult Appendix 1 for a review of MITEL Action Procedures (MAP's).
- (b) Consult Appendix 2 for certain FCC interconnection requirements.
- (c) For installation of SX-100 equipment proceed with the steps listed in Table A3-1, Appendix 3.
- (d) For installation of SX-200 equipment proceed with the steps listed in Table A4-1, Appendix 4.
- (e) Appendix 5 lists setting of card switches which are required to be performed during the installation of the ACD equipment. Appendix 5 also outlines SUPERSET 3/4 installation.
- (f) Appendix 6 lists miscellaneous installation procedures which may be required during the ACD installation or the installation of additional equipment.

Precautions

12.02 When installing the system certain precautions must be observed, particularly when handling PCB cards, replacing modules thereon or using test equipment to measure voltages. These precautions are detailed below:

- (a) When replacing PCB cards ensure that power is first switched off (where this is possible), but maintain the ground connections to the equipment.
- (b) Handle PCB cards, as far as is practicable, only by the edges and avoiding contact with any exposed electrical connections. When removing a new card from its package, touch the ground bar first to equalize any static voltage build-up, prior to insert-

ing it in the equipment. A wrist ground strap should be worn (Figure 12-1), but failing availability, ensure that one hand is grounded to the system cabinet immediately prior to removing or inserting a PCB card.

- (c) Modules, when removed for testing, should have their pins inserted into conductive foam to equalize build up.
- (d) Conductive packages should be grounded prior to opening them to remove the contents, and similarly grounded prior to placing a card in the package. Suspected faulty cards should be placed in conductive packages to prevent further possible damage to the cards.

13. SUPERSET 3/4

General

13.01 The SUPERSET 3 and SUPERSET 4 are advanced microprocessor-controlled electronic telephone set. Because of this, certain considerations must be taken into account when installing the SUPERSET.

- (a) The SUPERSET requires no special cabling as it is a 2-wire telephone set with a maximum loop resistance of 200 ohms (typically 2500 ft (63.5 m) of 26 AWG).
- (b) The SUPERSET requires a special line card. The SUPERSET line card is not compatible with standard telephone sets. When this line card is installed in a slot only SUPERSET telephone sets may be connected to the equipment numbers associated with that slot.
- (c) Only one SUPERSET may be connected to each port.
- (d) When troubleshooting or testing a SUPERSET equipment or line, a SUPERSET must be used as a "butt-in". A standard telephone set will not work on a SUPERSET equipment number or line.
- (e) The SUPERSET derives its power from the SX-100 or SX-200. For this reason, a SUPERSET 4 cannot be used as a Power Fail Transfer extension, as the SUPERSET will not be functional during power failures.
- (f) If the announce port on the SUPERSET is to be used, an associated equipment number must be used other than the SUPERSET equipment number.

Installation

13.02 For specific installation instructions for the SUPERSET, see MAP200-509. For specific programming instructions see Section MITL9105/9110-090-210-NA.

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS

PLUG P1 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1 reserved for	T1	T1	T1	1
1	BL-W	R1 test line	R1	R1	R1	
27	W-O	T2	XT2		TR1	
2	O-W	R2	XT1		RR1	
28	W-G	T3	T2		E1	2
3	G-W	R3	R2		M1	
29	W-BR	T4				
4	BR-W	R4				
30	W-S	T1	T1	T1	T1	3
5	S-W	R1	R1	R1	R1	
31	R-BL	T2	XT2		TR1	
6	BL-R	R2	XT1		RR1	
32	R-O	T3	T2		E1	4
7	O-R	R3	R2		M1	
33	R-G	T4				
8	G-R	R4				
34	R-BR	T1	T1	T1	T1	5
9	BR-R	R1	R1	R1	R1	
35	R-S	T2	XT2		TR1	
10	S-R	R2	XT1		RR1	
36	BK-BL	T3	T2		E1	6
11	BL-BK	R3	R2		M1	
37	BK-O	T4				
12	O-BK	R4				
38	BK-G	T1	T1	T1	T1	1
13	G-BK	R1	R1	R1	R1	
39	BK-BR	T2	XT2		TR1	
14	BR-BK	R2	XT1		RR1	
40	BK-S	T3	T2		E1	2
15	S-BK	R3	R2		M1	
41	Y-BL	T4				
16	BL-Y	R4				
42	Y-O	T1	T1	T1	T1	3
17	O-Y	R1	R1	R1	R1	
43	Y-G	T2	XT2		TR1	
18	G-Y	R2	XT1		RR1	
44	Y-BR	T3	T2		E1	4
19	BR-Y	R3	R2		M1	
45	Y-S	T4				
20	S-Y	R4				
46	V-BL	T1	T1	T1	T1	5
21	BL-V	R1	R1	R1	R1	
47	V-O	T2	XT2		TR1	
22	O-V	R2	XT1		RR1	
48	V-G	T3	T2		E1	6
23	G-V	R3	R2		M1	
49	V-BR	T4				
24	BR-V	R4				
50	V-S	SPARE	SPARE			
25	S-V	SPARE	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P2 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Trunks E&M†	Card Positions
26	W-BL	T5	T3	T2	1
1	BL-W	R5	R3	R2	
27	W-O	T6	XT4	TR2	
2	O-W	R6	XT3	RR2	2
28	W-G	T7	T4	E2	
3	G-W	R7	R4	M2	
29	W-BR	T8			3
4	BR-W	R8			
30	W-S	T5	T3	T2	
5	S-W	R5	R3	R2	4
31	R-BL	T6	XT4	TR2	
6	BL-R	R6	XT3	RR2	
32	R-O	T7	T4	E2	5
7	O-R	R7	R4	M2	
33	R-G	T8			
8	G-R	R8			6
34	R-BR	T5	T3	T2	
9	BR-R	R5	R3	R2	
35	R-S	T6	XT4	TR2	7
10	S-R	R6	XT3	RR2	
36	BK-BL	T7	T4	E2	
11	BL-BK	R7	R4	M2	8
37	BK-O	T8			
12	O-BK	R8			
38	BK-G	T5	T3	T2	9
13	G-BK	R5	R3	R2	
39	BK-BR	T6	XT4	TR2	
14	BR-BK	R6	XT3	RR2	10
40	BK-S	T7	T4	E2	
15	S-BK	R7	R4	M2	
41	Y-BL	T8			11
16	BL-Y	R8			
42	Y-O	T5	T3	T2	
17	O-Y	R5	R3	R2	12
43	Y-G	T6	XT4	TR2	
18	G-Y	R6	XT3	RR2	
44	Y-BR	T7	T4	E2	13
19	BR-Y	R7	R4	M2	
45	Y-S	T8			
20	S-Y	T8			14
46	V-BL	T5	T3	T2	
21	BL-V	R5	R3	R2	
47	V-O	T6	XT4	TR2	15
22	O-V	R6	XT3	RR2	
48	V-G	T7	T4	E2	
23	G-V	R7	R4	M2	16
49	V-BR	T8			
24	BR-V	R8			
50	V-S	SPARE	SPARE	SPARE	17
25	S-V	SPARE	SPARE	SPARE	

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P3 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1	T1	T1	T1	7
1	BL-W	R1	R1	R1	R1	
27	W-O	T2	XT2		TR1	
2	O-W	R2	XT1		RR1	
28	W-G	T3	T2		E1	8
3	G-W	R3	R2		M1	
29	W-BR	T4				
4	BR-W	R4				
30	W-S	T1	T1	T1	T1	9
5	S-W	R1	R1	R1	R1	
31	R-BL	T2	XT2		TR1	
6	BL-R	R2	XT1		RR1	
32	R-O	T3	T2		E1	10
7	O-R	R3	R2		M1	
33	R-G	T4				
8	G-R	R4				
34	R-BR	T1	T1	T1	T1	11
9	BR-R	R1	R1	R1	R1	
35	R-S	T2	XT2		TR1	
10	S-R	R2	XT1		RR1	
36	BK-BL	T3	T2		E1	12
11	BL-BK	R3	R2		M1	
37	BK-O	T4				
12	O-BK	R4				
38	BK-G	T1	T1	T1	T1	See Note
13	G-BK	R1	R1	R1	R1	
39	BK-BR	T2	XT2		TR1	
14	BR-BK	R2	XT1		RR1	
40	BK-S	T3	T2		E1	11
15	S-BK	R3	R2		M1	
41	Y-BL	T4				
16	BL-Y	R4				
42	Y-O	T1	T1	T1	T1	11
17	O-Y	R1	R1	R1	R1	
43	Y-G	T2	XT2		TR1	
18	G-Y	R2	XT1		RR1	
44	Y-BR	T3	T2		E1	11
19	BR-Y	R3	R2		M1	
45	Y-S	T4				
20	S-Y	R4				
46	V-BL	T1	T1	T1	T1	12
21	BL-V	R1	R1	R1	R1	
47	V-O	T2	XT2		TR1	
22	O-V	R2	XT1		RR1	
48	V-G	T3	T2		E1	12
23	G-V	R3	R2		M1	
49	V-BR	T4				
24	BR-V	R4				
50	V-S	SPARE	SPARE			12 See Note
25	S-V	SPARE	SPARE			

Note: Position 12 can be used for lines, trunks, or receiver #4 card.

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P4 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Trunks E&M†	Card Positions
26	W-BL	T5	T3	T2	7
1	BL-W	R5	R3	R2	
27	W-O	T6	XT4	TR2	
2	O-W	R6	XT3	RR2	
28	W-G	T7	T4	E2	8
3	G-W	R7	R4	M2	
29	W-BR	T8			
4	BR-W	R8			
30	W-S	T5	T3	T2	9
5	S-W	R5	R3	R2	
31	R-BL	T6	XT4	TR2	
6	BL-R	R6	XT3	RR2	
32	R-O	T7	T4	E2	10
7	O-R	R7	R4	M2	
33	R-G	T8			
8	G-R	R8			
34	R-BR	T5	T3	T2	11
9	BR-R	R5	R3	R2	
35	R-S	T6	XT4	TR2	
10	S-R	R6	XT3	RR2	
36	BK-BL	T7	T4	E2	12
11	BL-BK	R7	R4	M2	
37	BK-O	T8			
12	O-BK	R8			
38	BK-G	T5	T3	T2	10
13	G-BK	R5	R3	R2	
39	BK-BR	T6	XT4	TR2	
14	BR-BK	R6	XT3	RR2	
40	BK-S	T7	T4	E2	11
15	S-BK	R7	R4	M2	
41	Y-BL	T8			
16	BL-Y	R8			
42	Y-O	T5	T3	T2	12
17	O-Y	R5	R3	R2	
43	Y-G	T6	XT4	TR2	
18	G-Y	R6	XT3	RR2	
44	Y-BR	T7	T4	E2	See Note
19	BR-Y	R7	R4	M2	
45	Y-S	T8			
20	S-Y	R8			
46	V-BL	T5	T3	T2	See Note
21	BL-V	R5	R3	R2	
47	V-O	T6	XT4	TR2	
22	O-V	R6	XT3	RR2	
48	V-G	T7	T4	E2	See Note
23	G-V	R7	R4	M2	
49	V-BR	T8			
24	BR-V	R8			
50	V-S	SPARE	SPARE		See Note
25	S-V	SPARE	SPARE		

Note: Position 12 can be used for lines, trunks or receiver card #4.

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P5 (Connects to Plug P17)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1 097	T1	T1	T1	13 See Note
1	BL-W	R1	R1	R1	R1	
27	W-O	T2 098	XT2		TR1	
2	O-W	R2	XT1		RR1	
28	W-G	T3 099	T2		E1 101	13 See Note
3	G-W	R3	R2		M1 101	
29	W-BR	T4 100				
4	BR-W	R4				
30	W-S	T1 105	T1	T1	T1 100	14 See Note
5	S-W	R1	R1	R1	R1	
31	R-BL	T2 106	XT2		TR1	
6	BL-R	R2	XT1		RR1	
32	R-O	T3 107	T2		E1 111	14 See Note
7	O-R	R3	R2		M1 111	
33	R-G	T4 108				
8	G-R	R4				
34	R-BR					15
9	BR-R					
35	R-S					
10	S-R	RECEIVER No. 1				
36	BK-BL					16
11	BL-BK					
37	BK-O					
12	O-BK					
38	BK-G	T (A)				16
13	G-BK	R (A)				
39	BK-BR	S DATA OUT T (A)		ATTENDANT CONSOLE		
14	BR-BK	S DATA OUT R (A)		No. 2		
40	BK-S	S DATA IN T (A)				17
15	S-BK	S DATA IN R (A)				
41	Y-BL	PA2 Control B				
16	BL-Y	PA2 Control A				
42	Y-O	T (A)				17
17	O-Y	R (A)				
43	Y-G	S DATA OUT T (A)		ATTENDANT CONSOLE		
18	G-Y	S DATA OUT R (A)		No. 1		
44	Y-BR	S DATA IN T (A)				18
19	BR-Y	S DATA IN R (A)				
45	Y-S	PA1 Control B				
20	S-Y	PA1 Control A				
46	V-BL	MUSIC IN B				18
21	BL-V	MUSIC IN A				
47	V-O	TEST LINE				
22	O-V	TEST LINE		MUSIC ON HOLD		
48	V-G	PA1 OUT B				18
23	G-V	PA1 OUT A				
49	V-BR	PA2 OUT B				
24	BR-V	PA2 OUT A				
50	V-S	SPARE	SPARE			18
25	S-V	SPARE	SPARE			

Note: Positions 14 and 13 can be used for lines or trunks, or for receiver cards #2 and #3 respectively.

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-1 SHELF 1 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P6 (Connects to Plug P16)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T5 101	T1	T1	T1 100	13 See Note
1	BL-W	R5	R1	R1	R1	
27	W-O	T6	XT2		TR1 100	
2	O-W	R6 Lines	XT1		RR1	
28	W-G	T7 103	T2		E1 100	14 See Note
3	G-W	R7	R2		M1	
29	W-BR	T8 104				
4	BR-W	R8				
30	W-S	T5 109	T1	T1	T1 201	15
5	S-W	R5	R1	R1	R1	
31	R-BL	T6	XT2		TR1 100	
6	BL-R	R6 Lines	XT1		RR1	
32	R-O	T7 111	T2		E1 101	16
7	O-R	R7	R2		M1 101	
33	R-G	T8 112				
8	G-R	R8				
34	R-BR					17
9	BR-R					
35	R-S					
10	S-R	RECEIVER No. 1				
36	BK-BL					18 (See Notes for PLUG 18)
11	BL-BK					
37	BK-O					
12	O-BK					
38	BK-G	T (A)				16
13	G-BK	R (A)				
39	BK-BR	S DATA OUT T (B)		ATTENDANT CONSOLE		
14	BR-BK	S DATA OUT R (B)		SPARE		
40	BK-S	S DATA IN T (B)				17
15	S-BK	S DATA IN R (B)		NOT USED		
41	Y-BL	R (K1)				
16	BL-Y	K1		NIGHT BELL 1		
42	Y-O	T (A)				18 (See Notes for PLUG 18)
17	O-Y	R (A)				
43	Y-G	S DATA OUT T (B)		MAINTENANCE		
18	G-Y	S DATA OUT R (B)		CONSOLE		
44	Y-BR	S DATA IN T (B)				18 (See Notes for PLUG 18)
19	BR-Y	S DATA IN R (A)(B)				
45	Y-S	UART IN				
20	S-Y	UART OUT				
46	V-BL	R (K5)		SOFTWARE ALARM		18 (See Notes for PLUG 18)
21	BL-V	K5				
47	V-O	R (K4)		NIGHT SERVICE		
22	O-V	K4				
48	V-G	R (K3)		NIGHT BELL 3		18 (See Notes for PLUG 18)
23	G-V	K3				
49	V-BR	R (K2)		NIGHT BELL 2		
24	BR-V	K2				
50	V-S	SPARE	SPARE			18 (See Notes for PLUG 18)
25	S-V	SPARE	SPARE			

Note: Positions 14 and 13 can be used for lines or trunks, or for receiver cards #2 and #3 respectively.

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS

CONNECTOR J13 MAINTENANCE CONSOLE
(Connected To Maintenance Panel)CONNECTOR J14 ATTENDANT CONSOLE
NO. 2 (See Note For J15)

Pin	Pair Color	Lead Designation	Pin	Pair Color	Lead Designation
26	W-BL	ELECTROSTATIC GROUND	26	W-BL	ELECTROSTATIC GROUND
1	BL-W	ELECTROSTATIC GROUND	1	BL-W	ELECTROSTATIC GROUND
27	W-O	ELECTROSTATIC GROUND	27	W-O	ELECTROSTATIC GROUND
2	O-W	ELECTROSTATIC GROUND	2	O-W	ELECTROSTATIC GROUND
28	W-G	ELECTROSTATIC GROUND	28	W-G	ELECTROSTATIC GROUND
3	G-W	ELECTROSTATIC GROUND	3	G-W	ELECTROSTATIC GROUND
29	W-BR	ELECTROSTATIC GROUND	29	W-BR	ELECTROSTATIC GROUND
4	BR-W	ELECTROSTATIC GROUND	4	BR-W	ELECTROSTATIC GROUND
30	W-S	DATA IN COMMON	30	W-S	DATA IN COMMON
5	S-W	DATA IN	5	S-W	DATA IN
31	R-BL	ELECTROSTATIC GROUND	31	R-BL	ELECTROSTATIC GROUND
6	BL-R	ELECTROSTATIC GROUND	6	BL-R	ELECTROSTATIC GROUND
32	R-O	DATA OUT COMMON	32	R-O	DATA OUT COMMON
7	R-O	DATA OUT	7	R-O	DATA OUT
33	R-G	ELECTROSTATIC GROUND	33	R-G	ELECTROSTATIC GROUND
8	G-R	ELECTROSTATIC GROUND	8	G-R	ELECTROSTATIC GROUND
34	R-BR	ELECTROSTATIC GROUND	34	R-BR	ELECTROSTATIC GROUND
9	BR-R	ELECTROSTATIC GROUND	9	BR-R	ELECTROSTATIC GROUND
35	R-S	CUTOVER SWB	35	R-S	CUTOVER SWB
10	S-R	CUTOVER SWA	10	S-R	CUTOVER SWA
36	BK-BL	ELECTROSTATIC GROUND	36	BK-BL	ELECTROSTATIC GROUND
11	BL-BK	ELECTROSTATIC GROUND	11	BL-BK	ELECTROSTATIC GROUND
37	BK-O	MAJOR ALARM	37	BK-O	MAJOR ALARM
12	O-BK	MAJOR ALARM	12	O-BK	MAJOR ALARM
38	BK-G	TIP	38	BK-G	TIP
13	G-BK	RING	13	G-BK	RING
39	BK-BR	ELECTROSTATIC GROUND	39	BK-BR	ELECTROSTATIC GROUND
14	BR-BK	ELECTROSTATIC GROUND	14	BR-BK	ELECTROSTATIC GROUND
40	BK-S	ELECTROSTATIC GROUND	40	BK-S	ELECTROSTATIC GROUND
15	S-BK	ELECTROSTATIC GROUND	15	S-BK	ELECTROSTATIC GROUND
41	Y-BL	ELECTROSTATIC GROUND	41	Y-BL	ELECTROSTATIC GROUND
16	BL-Y	ELECTROSTATIC GROUND	16	BL-Y	ELECTROSTATIC GROUND
42	Y-O	ELECTROSTATIC GROUND	42	Y-O	ELECTROSTATIC GROUND
17	O-Y	ELECTROSTATIC GROUND	17	O-Y	ELECTROSTATIC GROUND
43	Y-G	0V	43	Y-G	0V
18	G-Y	-48V	18	G-Y	-48V
44	Y-BR	0V	44	Y-BR	0V
19	BR-Y	-48V	19	BR-Y	-48V
45	Y-S	0V	45	Y-S	0V
20	S-Y	-48V	20	S-Y	-48V
46	V-BL	0V	46	V-BL	0V
21	BL-V	-48V	21	BL-V	-48V
47	V-O	0V	47	V-O	0V
22	O-V	-48V	22	O-V	-48V
48	V-G	0V	48	V-G	0V
23	G-V	-48V	23	G-V	-48V
49	V-BR	0V	49	V-BR	0V
24	BR-V	-48V	24	BR-V	-48V
50	V-S	0V	50	V-S	0V
25	S-V	-48V	25	S-V	-48V

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

CONNECTOR J15 ATTENDANT CONSOLE NO.1

(See Note)

Pin	Pair Color	Lead Designation	
26	W-BL	ELECTROSTATIC GROUND	NOTE: Connector J15 connected either direct to Attendant Console 1 or via plug P23 and jack J22 to console. Connector J14 similarly connected either direct to attendant console 2 or via plug P25 and jack J24.
1	BL-W	ELECTROSTATIC GROUND	
27	W-O	ELECTROSTATIC GROUND	
2	O-W	ELECTROSTATIC GROUND	
28	W-G	ELECTROSTATIC GROUND	
3	G-W	ELECTROSTATIC GROUND	
29	W-BR	ELECTROSTATIC GROUND	
4	BR-W	ELECTROSTATIC GROUND	
30	W-S	DATA IN COMMON	
5	S-W	DATA IN	
31	R-BL	ELECTROSTATIC GROUND	
6	BL-R	ELECTROSTATIC GROUND	
32	R-O	DATA OUT COMMON	
7	R-O	DATA OUT	
33	R-G	ELECTROSTATIC GROUND	
8	G-R	ELECTROSTATIC GROUND	
34	R-BR	ELECTROSTATIC GROUND	
9	BR-R	ELECTROSTATIC GROUND	
35	R-S	CUTOVER SWB	
10	S-R	CUTOVER SWA	
36	BK-BL	ELECTROSTATIC GROUND	
11	BL-BK	ELECTROSTATIC GROUND	
37	BK-O	MAJOR ALARM	
12	O-BK	MAJOR ALARM	
38	BK-G	TIP	
13	G-BK	RING	
39	BK-BR	ELECTROSTATIC GROUND	
14	BR-BK	ELECTROSTATIC GROUND	
40	BK-S	ELECTROSTATIC GROUND	
15	S-BK	ELECTROSTATIC GROUND	
41	Y-BL	ELECTROSTATIC GROUND	
16	BL-Y	ELECTROSTATIC GROUND	
42	Y-O	ELECTROSTATIC GROUND	
17	O-Y	ELECTROSTATIC GROUND	
43	Y-G	0V	
18	G-Y	-48V	
44	Y-BR	0V	
19	BR-Y	-48V	
45	Y-S	0V	
20	S-Y	-48V	
46	V-BL	0V	
21	BL-V	-48V	
47	V-O	0V	
22	O-V	-48V	
48	V-G	0V	
23	G-V	-48V	
49	V-BR	0V	
24	BR-V	-48V	
50	V-S	0V	
25	S-V	-48V	

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P16 (Interconnect Cable to P6)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T5	T3	T2	T2	13
1	BL-W	R5	R3	R2	R2	
27	W-O	T6	XT4		TR2	
2	O-W	R6	XT3		RR2	
28	W-G	T7	T4		E2	
3	G-W	R7	R4		M2	
29	W-BR	T8				
4	BR-W	R8				
30	W-S	T5	T3	T2	T2	
5	S-W	R5	R3	R2	T2	
31	R-BL	T6	XT4		TR2	14
6	BL-R	R6	XT3		RR2	
32	R-O	T7	T4		E2	
7	O-R	R7	R4		M2	
33	R-G	T8				
8	G-R	R8				
34	R-BR					
9	BR-R					
35	R-S					
10	S-R			RECEIVER 1		
36	BK-BL					16
11	BL-BK					
37	BK-O					
12	O-BK					
38	BK-G	SPARE				
13	G-BK	SPARE				
39	BK-BR	SPARE				
14	BR-BK	SPARE				
40	BK-S	SPARE				
15	S-BK	SPARE				
41	Y-BL	NIGHT BELL 1B		See Notes for Plug P18		17
16	BL-Y	NIGHT BELL 1A				
42	Y-O	TIP				
17	O-Y	RING				
43	Y-G	DATA IN COMMON				
18	G-Y	DATA IN		MAINTENANCE		
44	Y-BR	DATA OUT COMMON		CONSOLE		
19	BR-Y	DATA OUT				
45	Y-S	UART B				
20	S-Y	UART A				
46	V-BL	ALARM B				
21	BL-V	ALARM A				
47	V-O	NIGHT SERVICE B				18
22	O-V	NIGHT SERVICE A				
48	V-G	NIGHT BELL 3B		See Notes for Plug P18		
23	G-V	NIGHT BELL 3A				
49	V-BR	NIGHT BELL 2B				
24	BR-V	NIGHT BELL 2A		See Notes for Plug P18		
50	V-S	SPARE				
25	S-V	SPARE				

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P17 (Interconnect Cable to P5)

Pin	Pair Color	Lead Designation	Lead Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1	T1	T1	13
1	BL-W	R1	R1	R1	
27	W-O	T2	XT2	TR1	
2	O-W	R2	XT1	RR1	
28	W-G	T3	T2	E1	14
3	G-W	R3	R2	M1	
29	W-BR	T4			
4	BR-W	R4			
30	W-S	T1	T1	T1	15
5	S-W	R1	R1	R1	
31	R-BL	T2	XT2	TR1	
6	BL-R	R2	XT1	RR1	
32	R-O	T3	T2	E1	16
7	O-R	R3	R2	M1	
33	R-G	T4			
8	G-R	R4			
34	R-BR				17
9	BR-R				
35	R-S				
10	S-R		RECEIVER 1		
36	BK-BL				18
11	BL-BK				
37	BK-O				
12	O-BK				
38	BK-G	TIP (A)			16
13	G-BK	RING (A)	ATTENDANT CONSOLE No. 2		
39	BK-BR	S DATA IN R (A)			
14	BR-BK	S DATA IN T (A)			
40	BK-S	S DATA OUT R (A)			17
15	S-BK	S DATA OUT T (A)			
41	Y-BL	PA2 CONTROL B			
16	BL-Y	PA2 CONTROL A			
42	Y-O	TIP			18
17	O-Y	RING	ATTENDANT CONSOLE No. 1		
43	Y-G	DATA IN COMMON			
18	G-Y	DATA IN			
44	Y-BR	DATA OUT COMMON			18
19	BR-Y	DATA OUT			
45	Y-S	PA1 CONTROL B			
20	S-Y	PA1 CONTROL A			
46	V-BL	MUSIC IN B			18
21	BL-V	MUSIC IN A			
47	V-O	MAINT TIP			
22	O-V	MAINT RING			
48	V-G	PA1 OUT B			18
23	G-V	PA1 OUT A			
49	V-BR	PA2 OUT B	(See Notes For Plug P18)		
24	BR-V	PA2 OUT A			
50	V-S	SPARE			18
25	S-V	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P18 (Miscellaneous Connections to Cross-Connect Field)

Pin	Pair Color	Lead Designation	
26	W-BL	SPARE	Note: (1) Night service relay operates permanently when in night service. Night Bell continuous rating: Open circuit voltage 120 Vrms Closed circuit current 75mArms Music in 100 mV Impedance 600 Ohms PA Output Level 100 mV Impedance 600 Ohms (2) (3)
1	BL-W	SPARE	
27	W-O	SPARE	
2	O-W	SPARE	
28	W-G	SPARE	
3	G-W	SPARE	
29	W-BR	SPARE	
4	BR-W	SPARE	
30	W-S	SPARE	
5	S-W	SPARE	
31	R-BL	SPARE	
6	BL-R	SPARE	
32	R-O	SPARE	
7	R-O	SPARE	
33	R-G	SPARE	
8	G-R	SPARE	
34	R-BR	SPARE	
9	BR-R	SPARE	
35	R-S	SPARE	
10	S-R	SPARE	
36	BK-BL	SPARE	
11	BL-BK	SPARE	
37	BK-O	SPARE	
12	O-BK	SPARE	
38	BK-G	SPARE	
13	G-BK	SPARE	
39	BK-BR	SPARE	
14	BR-BK	SPARE	
40	BK-S	SPARE	
15	S-BK	SPARE	
41	Y-BL	SPARE	
16	BL-Y	SPARE	
42	Y-O	MUSIC IN B	
17	O-Y	MUSIC IN A	
43	Y-G	PA2 OUT B	
18	G-Y	PA2 OUT A	
44	Y-BR	NIGHT BELL 2B	
19	BR-Y	NIGHT BELL 2A	
45	Y-S	PA1 OUT B	
20	S-Y	PA1 OUT A	
46	V-BL	NIGHT BELL 1B	
21	BL-V	NIGHT BELL 1A	
47	V-O	PA1 CONTROL B	
22	O-V	PA1 CONTROL A	
48	V-G	PA2 CONTROL B	
23	G-V	PA2 CONTROL A	
49	V-BR	NIGHT SERVICE B	
24	BR-V	NIGHT SERVICE A	
50	V-S	NIGHT BELL 3B	
25	S-V	NIGHT BELL 3A	

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P19 ON INTERCONNECT CARD
 (Miscellaneous Connections to Cross-Connect Field)

Pin	Pair Color	Lead Designation Line	Lead Designation, CO	DID/TIE	Trunks E&M†	Card Positions
26	W-BL	SPARE				
1	BL-W	SPARE				
27	W-O					
2	O-W					
28	W-G					
3	G-W	RECEIVER 1				15
29	W-BR					
4	BR-W					
30	W-S					
5	S-W					
31	R-BL	T8				
6	BL-R	R8				
32	R-O	T7	T4		E2	
7	O-R	R7	R4		M2	14
33	R-G	T6	XT3		TR2	
8	G-R	R6	XT4		RR2	
34	R-BR	T5	T3	T2	T2	
9	BR-R	R5	R3	R2	R2	
35	R-S	T8				
10	S-R	R8				
36	BK-BL	T7	T4		E2	
11	BL-BK	R7	R4		M2	13
37	BK-O	T6	XT3		TR2	
12	O-BK	R6	XT4		RR2	
38	BK-G	T5	T3	T2	T2	
13	G-BK	R5	R3	R2	R2	
39	BK-BR					
14	BR-BK					
40	BK-S					
15	S-BK	RECEIVER 1				15
41	Y-BL					
16	BL-Y					
42	Y-O					
17	O-Y					
43	Y-G	T4				
18	G-Y	R4				
44	Y-BR	T3	T2		E1	
19	BR-Y	R3	R2		M1	14
45	Y-S	T2	XT1		TR1	
20	S-Y	R2	XT2		RR1	
46	V-BL	T1	T1	T1	T1	
21	BL-V	R1	R1	R1	R1	
47	V-O	T4				
22	O-V	R4				
48	V-G	T3	T2		E1	
23	G-V	R3	R2		M1	
49	V-BR	T2	XT1		TR1	13
24	BR-V	R2	XT2		RR1	
50	V-S	T1	T1	T1	T1	
25	S-V	R1	R1	R1	R1	

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads.

TABLE 10-2 INTERCONNECT BOARD PLUG AND JACK CONNECTIONS (CONT'D)

JACK J302

DATA PORT (SEE NOTES)

CONNECTOR P302

DATA PORT (SEE NOTES)

Pin	Lead Designation
1	0V
2	TRANSMIT DATA
3	RECEIVE DATA
4	
5	CLEAR TO SEND
6	DATA SET READY
7	SIGNAL GROUND
8	CARRIER DETECT
9	(RESERVED FOR DATA SET TESTING)
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	DATA TERM READY
21	
22	
23	
24	
25	

- Note 1.** Jack J302 is provided on the SX-100 and SX-200 ACD's for external recording devices.
- 2.** Use Connector J302 when connected to terminal equipment e.g. magnetic tape recorder or printer.
- 3.** Use a null modem when connected to a modem.
- 4.** See Appendix 5, MAP200-504 for details of switch settings for data characteristics.
- 5.** See Section MITL9105/9110-090-450-NA, Traffic Measurement, for applications of the connectors.

TABLE 10-3 POWER FAIL TRANSFER BOARD PLUG AND JACK CONNECTIONS

PLUG P20

(Power Fail Transfer Connections to Cross-Connect Field)

PLUG P21

(Power Fail Transfer Connections to Cross-Connect Field)

Pin	Pair Color	Lead Designation	Pin	Pair Color	Lead Designation
26	W-BL	STATION T1	26	W-BL	STATION T7
1	BL-W	STATION R1	1	BL-W	STATION R7
27	W-O	LINE CARD T1	27	W-O	LINE CARD T7
2	O-W	LINE CARD R1	2	O-W	LINE CARD R7
28	W-G	TRUNK T1	28	W-G	TRUNK T7
3	G-W	TRUNK R1	3	G-W	TRUNK R7
29	W-BR	TRUNK CARD T1	29	W-BR	TRUNK CARD T7
4	BR-W	TRUNK CARD R1	4	BR-W	TRUNK CARD R7
30	W-S	STATION T2	30	W-S	STATION T8
5	S-W	STATION R2	5	S-W	STATION R8
31	R-BL	LINE CARD T2	31	R-BL	LINE CARD T8
6	BL-R	LINE CARD R2	6	BL-R	LINE CARD R8
32	R-O	TRUNK T2	32	R-O	TRUNK T8
7	R-O	TRUNK R2	7	R-O	TRUNK R8
33	R-G	TRUNK CARD T2	33	R-G	TRUNK CARD T8
8	G-R	TRUNK CARD R2	8	G-R	TRUNK CARD R8
34	R-BR	STATION T3	34	R-BR	STATION T9
9	BR-R	STATION R3	9	BR-R	STATION R9
35	R-S	LINE CARD T3	35	R-S	LINE CARD T9
10	S-R	LINE CARD R3	10	S-R	LINE CARD R9
36	BK-BL	TRUNK T3	36	BK-BL	TRUNK T9
11	BL-BK	TRUNK R3	11	BL-BK	TRUNK R9
37	BK-O	TRUNK CARD T3	37	BK-O	TRUNK CARD T9
12	O-BK	TRUNK CARD R3	12	O-BK	TRUNK CARD R9
38	BK-G	STATION T4	38	BK-G	STATION T10
13	G-BK	STATION R4	13	G-BK	STATION R10
39	BK-BR	LINE CARD T4	39	BK-BR	LINE CARD T10
14	BR-BK	LINE CARD R4	14	BR-BK	LINE CARD R10
40	BK-S	TRUNK T4	40	BK-S	TRUNK T10
15	S-BK	TRUNK R4	15	S-BK	TRUNK R10
41	Y-BL	TRUNK CARD T4	41	Y-BL	TRUNK CARD T10
16	BL-Y	TRUNK CARD R4	16	BL-Y	TRUNK CARD R10
42	Y-O	STATION T5	42	Y-O	STATION T11
17	O-Y	STATION R5	17	O-Y	STATION R11
43	Y-G	LINE CARD T5	43	Y-G	LINE CARD T11
18	G-Y	LINE CARD R5	18	G-Y	LINE CARD R11
44	Y-BR	TRUNK T5	44	Y-BR	TRUNK T11
19	BR-Y	TRUNK R5	19	BR-Y	TRUNK R11
45	Y-S	TRUNK CARD T5	45	Y-S	TRUNK CARD T11
20	S-Y	TRUNK CARD R5	20	S-Y	TRUNK CARD R11
46	V-BL	STATION T6	46	V-BL	STATION T12
21	BL-V	STATION R6	21	BL-V	STATION R12
47	V-O	LINE CARD T6	47	V-O	LINE CARD T12
22	O-V	LINE CARD R6	22	O-V	LINE CARD R12
48	V-G	TRUNK T6	48	V-G	TRUNK T12
23	G-V	TRUNK R6	23	G-V	TRUNK R12
49	V-BR	TRUNK CARD T6	49	V-BR	TRUNK CARD T12
24	BR-V	TRUNK CARD R6	24	BR-V	TRUNK CARD R12
50	V-S	SPARE	50	V-S	SPARE
25	S-V	SPARE	25	S-V	SPARE

Note: Plug 21 is not installed on SX-100 equipment.

TABLE 10-4 SHELF 2 EXTERNAL PLUG AND JACK CONNECTIONS

PLUG P7 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation, CO	Lead Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1 reserved for	T1	T1	T1	
1	BL-W	R1 test line	R1	R1	R1	
27	W-O	T2	XT2		TR1	1
2	O-W	R2	XT1		RR1	
28	W-G	T3	T2		E1	
3	G-W	R3	R2		M1	
29	W-BR	T4				
4	BR-W	R4				
30	W-S	T1	T1	T1	T1	
5	S-W	R1	R1	R1	R1	
31	R-BL	T2	XT2		TR1	2
6	BL-R	R2	XT1		RR1	
32	R-O	T3	T2		E1	
7	O-R	R3	R2		M1	
33	R-G	T4				
8	G-R	R4				
34	R-BR	T1	T1	T1	T1	
9	BR-R	R1	R1	R1	R1	
35	R-S	T2	XT2		TR1	3
10	S-R	R2	XT1		RR1	
36	BK-BL	T3	T2		E1	
11	BL-BK	R3	R2		M1	
37	BK-O	T4				
12	O-BK	R4				
38	BK-G	T1	T1	T1	T1	
13	G-BK	R1	R1	R1	R1	
39	BK-BR	T2	XT2		TR1	4
14	BR-BK	R2	XT1		RR1	
40	BK-S	T3	T2		E1	
15	S-BK	R3	R2		M1	
41	Y-BL	T4				
16	BL-Y	R4				
42	Y-O	T1	T1	T1	T1	
17	O-Y	R1	R1	R1	R1	
43	Y-G	T2	XT2		TR1	5
18	G-Y	R2	XT1		RR1	
44	Y-BR	T3	T2		E1	
19	BR-Y	R3	R2		M1	
45	Y-S	T4				
20	S-Y	R4				
46	V-BL	T1	T1	T1	T1	
21	BL-V	R1	R1	R1	R1	
47	V-O	T2	XT2		TR1	6
22	O-V	R2	XT1		RR1	
48	V-G	T3	T2		E1	
23	G-V	R3	R2		M1	
49	V-BR	T4				
24	BR-V	R4				
50	V-S	SPARE	SPARE			
25	S-V	SPARE	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-4 SHELF 2 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P8 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation CO	Lead Designation DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T5	T3	T2	T2	
1	BL-W	R5	R3	R2	R2	
27	W-O	T6	XT4		TR2	
2	O-W	R6	XT3		RR2	1
28	W-G	T7	T4		E2	
3	G-W	R7	R4		M2	
29	W-BR	T8				
4	BR-W	R8				
30	W-S	T5	T3	T2	T2	
5	S-W	R5	R3	R2	R2	
31	R-BL	T6	XT4		TR2	
6	BL-R	R6	XT3		RR2	2
32	R-O	T7	T4		E2	
7	O-R	R7	R4		M2	
33	R-G	T8				
8	G-R	R8				
34	R-BR	T5	T3	T2	T2	
9	BR-R	R5	R3	R2	R2	
35	R-S	T6	XT4		TR2	
10	S-R	R6	XT3		RR2	
36	BK-BL	T7	T4		E2	3
11	BL-BK	R7	R4		M2	
37	BK-O	T8				
12	O-BK	R8				
38	BK-G	T5	T3	T2	T2	
13	G-BK	R5	R3	R2	R2	
39	BK-BR	T6	XT4		TR2	
14	BR-BK	R6	XT3		RR2	
40	BK-S	T7	T4		E2	4
15	S-BK	R7	R4		M2	
41	Y-BL	T8				
16	BL-Y	R8				
42	Y-O	T5	T3	T2	T2	
17	O-Y	R5	R3	R2	R2	
43	Y-G	T6	XT4		TR2	
18	G-Y	R6	XT3		RR2	
44	Y-BR	T7	T4		E2	5
19	BR-Y	R7	R4		M2	
45	Y-S	T8				
20	S-Y	R8				
46	V-BL	T5	T3	T2	T2	
21	BL-V	R5	R3	R2	R2	
47	V-O	T6	XT4		TR2	
22	O-V	R6	XT3		RR2	
48	V-G	T7	T4		E2	6
23	G-V	R7	R4		M2	
49	V-BR	T8				
24	BR-V	R8				
50	V-S	SPARE	SPARE			
25	S-V	SPARE	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-4 SHELF 2 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P9 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation	Lead Designation, CO	Designation, DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T1	T1	T1	T1	7
1	BL-W	R1	R1	R1	R1	
27	W-O	T2	XT2		TR1	
2	O-W	R2	XT1		RR1	
28	W-G	T3	T2		E1	8
3	G-W	R3	R2		M1	
29	W-BR	T4				
4	BR-W	R4				
30	W-S	T1	T1	T1	T1	9
5	S-W	R1	R1	R1	R1	
31	R-BL	T2	XT2		TR1	
6	BL-R	R2	XT1		RR1	
32	R-O	T3	T2		E1	10
7	O-R	R3	R2		M1	
33	R-G	T4				
8	G-R	R4				
34	R-BR	T1	T1	T1	T1	11
9	BR-R	R1	R1	R1	R1	
35	R-S	T2	XT2		TR1	
10	S-R	R2	XT1		RR1	
36	BK-BL	T3	T2		E1	12
11	BL-BK	R3	R2		M1	
37	BK-O	T4				
12	O-BK	R4				
38	BK-G	T1	T1	T1	T1	7
13	G-BK	R1	R1	R1	R1	
39	BK-BR	T2	XT2		TR1	
14	BR-BK	R2	XT1		RR1	
40	BK-S	T3	T2		E1	8
15	S-BK	R3	R2		M1	
41	Y-BL	T4				
16	BL-Y	R4				
42	Y-O	T1	T1	T1	T1	9
17	O-Y	R1	R1	R1	R1	
43	Y-G	T2	XT2		TR1	
18	G-Y	R2	XT1		RR1	
44	Y-BR	T3	T2		E1	10
19	BR-Y	R3	R2		M1	
45	Y-S	T4				
20	S-Y	R4				
46	V-BL	T1	T1	T1	T1	11
21	BL-V	R1	R1	R1	R1	
47	V-O	T2	XT2		TR1	
22	O-V	R2	XT1		RR1	
48	V-G	T3	T2		E1	12
23	G-V	R3	R2		M1	
49	V-BR	T4				
24	BR-V	R4				
50	V-S	SPARE	SPARE			
25	S-V	SPARE	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-4 SHELF 2 EXTERNAL PLUG AND JACK CONNECTIONS (CONT'D)

PLUG P10 (Connects to Cross-Connect Field)

Pin	Pair Color	Lead Designation Lines	Lead Designation CO	Trunks DID/TIE	Trunks E&M†	Card Positions
26	W-BL	T5	T3	T2	T2	7
1	BL-W	R5	R3	R2	R2	
27	W-O	T6	XT4		TR2	
2	O-W	R6	XT3		RR2	
28	W-G	T7	T4		E2	8
3	G-W	R7	R4		M2	
28	W-BR	T8				
4	BR-W	R8				
30	W-S	T5	T3	T2	T2	9
5	S-W	R5	R3	R2	R2	
31	R-BL	T6	XT4		TR2	
6	BL-R	R6	XT3		RR2	
32	R-O	T7	T4		E2	10
7	O-R	R7	R4		M2	
33	R-G	T8				
8	G-R	R8				
34	R-BR	T5	T3	T2	T2	11
9	BR-R	R5	R3	R2	R2	
35	R-S	T6	XT4		TR2	
10	S-R	R6	XT3		RR2	
36	BK-BL	T7	T4		E2	12
11	BL-BK	R7	R4		M2	
37	BK-O	T8				
12	O-BK	R8				
38	BK-G	T5	T3	T2	T2	10
13	G-BK	R5	R3	R2	R2	
39	BK-BR	T6	XT4		TR2	
14	BR-BK	R6	XT3		RR2	
40	BK-S	T7	T4		E2	11
15	S-BK	R7	R4		M2	
41	Y-BL	T8				
16	BL-Y	R8				
42	Y-O	T5	T3	T2	T2	12
17	O-Y	R5	R3	R2	R2	
43	Y-G	T6	XT4		TR2	
18	G-Y	R6	XT3		RR2	
44	Y-BR	T7	T4		E2	11
19	BR-Y	R7	R4		M2	
45	Y-S	T8				
20	S-Y	R8				
46	V-BL	T5	T3	T2	T2	12
21	BL-V	R5	R3	R2	R2	
47	V-O	T6	XT4		TR2	
22	O-V	R6	XT3		RR2	
48	V-G	T7	T4		E2	12
23	G-V	R7	R4		M2	
49	V-BR	T8				
24	BR-V	R8				
50	V-S	SPARE	SPARE			
25	S-V	SPARE	SPARE			

†For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads

TABLE 10-5 CONSOLE INTERFACE BOARD PLUG AND JACK CONNECTIONS (SX-200 ONLY)

JACK J22

Connects to Attendant Console 1)

PLUG P23

(Connects to Jack J15)

Pin	Pair Color	Lead	Designation	Pin	Pair Color	Lead	Designation
26	W-BL	ELECTROSTATIC	GROUND	26	W-BL	ELECTROSTATIC	GROUND
1	BL-W	ELECTROSTATIC	GROUND	1	BL-W	ELECTROSTATIC	GROUND
27	W-O	ELECTROSTATIC	GROUND	27	W-O	ELECTROSTATIC	GROUND
2	O-W	ELECTROSTATIC	GROUND	2	O-W	ELECTROSTATIC	GROUND
28	W-G	ELECTROSTATIC	GROUND	28	W-G	ELECTROSTATIC	GROUND
3	G-W	ELECTROSTATIC	GROUND	3	G-W	ELECTROSTATIC	GROUND
29	W-BR	ELECTROSTATIC	GROUND	29	W-BR	ELECTROSTATIC	GROUND
4	BR-W	ELECTROSTATIC	GROUND	4	BR-W	ELECTROSTATIC	GROUND
30	W-S	DATA IN	COMMON	30	W-S	DATA IN	COMMON
5	S-W	DATA IN		5	S-W	DATA IN	
31	R-BL	ELECTROSTATIC	GROUND	31	R-BL	ELECTROSTATIC	GROUND
6	BL-R	ELECTROSTATIC	GROUND	6	BL-R	ELECTROSTATIC	GROUND
32	R-O	DATA OUT	COMMON	32	R-O	DATA OUT	COMMON
7	R-O	DATA OUT		7	R-O	DATA OUT	
33	R-G	ELECTROSTATIC	GROUND	33	R-G	ELECTROSTATIC	GROUND
8	G-R	ELECTROSTATIC	GROUND	8	G-R	ELECTROSTATIC	GROUND
34	R-BR	ELECTROSTATIC	GROUND	34	R-BR	ELECTROSTATIC	GROUND
9	BR-R	ELECTROSTATIC	GROUND	9	BR-R	ELECTROSTATIC	GROUND
35	R-S	CUTOVER	SWB	35	R-S	CUTOVER	SWB
10	S-R	CUTOVER	SWA	10	S-R	CUTOVER	SWA
36	BK-BL	ELECTROSTATIC	GROUND	36	BK-BL	ELECTROSTATIC	GROUND
11	BL-BK	ELECTROSTATIC	GROUND	11	BL-BK	ELECTROSTATIC	GROUND
37	BK-O	MAJOR ALARM		37	BK-O	MAJOR ALARM	
12	O-BK	MAJOR ALARM		12	O-BK	MAJOR ALARM	
38	BK-G	TIP		38	BK-G	TIP	
13	G-BK	RING		13	G-BK	RING	
39	BK-BR	ELECTROSTATIC	GROUND	39	BK-BR	ELECTROSTATIC	GROUND
14	BR-BK	ELECTROSTATIC	GROUND	14	BR-BK	ELECTROSTATIC	GROUND
40	BK-S	ELECTROSTATIC	GROUND	40	BK-S	ELECTROSTATIC	GROUND
15	S-BK	ELECTROSTATIC	GROUND	15	S-BK	ELECTROSTATIC	GROUND
41	Y-BL	ELECTROSTATIC	GROUND	41	Y-BL	ELECTROSTATIC	GROUND
16	BL-Y	ELECTROSTATIC	GROUND	16	BL-Y	ELECTROSTATIC	GROUND
42	Y-O	ELECTROSTATIC	GROUND	42	Y-O	ELECTROSTATIC	GROUND
17	O-Y	ELECTROSTATIC	GROUND	17	O-Y	ELECTROSTATIC	GROUND
43	Y-G	0 V		43	Y-G	0 V	
18	G-Y	-48 V		18	G-Y	-48 V	
44	Y-BR	0 V		44	Y-BR	0 V	
19	BR-Y	-48 V		19	BR-Y	-48 V	
45	Y-S	0 V		45	Y-S	0 V	
20	S-Y	-48 V		20	S-Y	-48 V	
46	V-BL	0 V		46	V-BL	0 V	
21	BL-V	-48 V		21	BL-V	-48 V	
47	V-O	0 V		47	V-O	0 V	
22	O-V	-48 V		22	O-V	-48 V	
48	V-G	0 V		48	V-G	0 V	
23	G-V	-48 V		23	G-V	-48 V	
49	V-BR	0 V		49	V-BR	0 V	
24	BR-V	-48 V		24	BR-V	-48 V	
50	V-S	0 V		50	V-S	0 V	
25	S-V	-48 V		25	S-V	-48 V	

TABLE 10-5 CONSOLE INTERFACE BOARD PLUG AND JACK CONNECTIONS (SX-200 ONLY)


JACK J24

(Connects to Attendant Console 2)

PLUG P25

(Connects to Jack J14)

Pin	Pair Color	Lead Designation	Pin	Pair Color	Lead Designation
26	W-BL	ELECTROSTATIC GROUND	26	W-BL	ELECTROSTATIC GROUND
1	BL-W	ELECTROSTATIC GROUND	1	BL-W	ELECTROSTATIC GROUND
27	W-O	ELECTROSTATIC GROUND	27	W-O	ELECTROSTATIC GROUND
2	O-W	ELECTROSTATIC GROUND	2	O-W	ELECTROSTATIC GROUND
28	W-G	ELECTROSTATIC GROUND	28	W-G	ELECTROSTATIC GROUND
3	G-W	ELECTROSTATIC GROUND	3	G-W	ELECTROSTATIC GROUND
29	W-BR	ELECTROSTATIC GROUND	29	W-BR	ELECTROSTATIC GROUND
4	BR-W	ELECTROSTATIC GROUND	4	BR-W	ELECTROSTATIC GROUND
30	W-S	DATA IN COMMON	30	W-S	DATA IN COMMON
5	S-W	DATA IN	5	S-W	DATA IN
31	R-BL	ELECTROSTATIC GROUND	31	R-BL	ELECTROSTATIC GROUND
6	BL-R	ELECTROSTATIC GROUND	6	BL-R	ELECTROSTATIC GROUND
32	R-O	DATA OUT COMMON	32	R-O	DATA OUT COMMON
7	R-O	DATA OUT	7	R-O	DATA OUT
33	R-G	ELECTROSTATIC GROUND	33	R-G	ELECTROSTATIC GROUND
8	G-R	ELECTROSTATIC GROUND	8	G-R	ELECTROSTATIC GROUND
34	R-BR	ELECTROSTATIC GROUND	34	R-BR	ELECTROSTATIC GROUND
9	BR-R	ELECTROSTATIC GROUND	9	BR-R	ELECTROSTATIC GROUND
35	R-S	CUTOVER SWB	35	R-S	CUTOVER SWB
10	S-R	CUTOVER SWA	10	S-R	CUTOVER SWA
36	BK-BL	ELECTROSTATIC GROUND	36	BK-BL	ELECTROSTATIC GROUND
11	BL-BK	ELECTROSTATIC GROUND	11	BL-BK	ELECTROSTATIC GROUND
37	BK-O	MAJOR ALARM	37	BK-O	MAJOR ALARM
12	O-BK	MAJOR ALARM	12	O-BK	MAJOR ALARM
38	BK-G	TIP	38	BK-G	TIP
13	G-BK	RING	13	G-BK	RING
39	BK-BR	ELECTROSTATIC GROUND	39	BK-BR	ELECTROSTATIC GROUND
14	BR-BK	ELECTROSTATIC GROUND	14	BR-BK	ELECTROSTATIC GROUND
40	BK-S	ELECTROSTATIC GROUND	40	BK-S	ELECTROSTATIC GROUND
15	S-BK	ELECTROSTATIC GROUND	15	S-BK	ELECTROSTATIC GROUND
41	Y-BL	ELECTROSTATIC GROUND	41	Y-BL	ELECTROSTATIC GROUND
16	BL-Y	ELECTROSTATIC GROUND	16	BL-Y	ELECTROSTATIC GROUND
42	Y-O	ELECTROSTATIC GROUND	42	Y-O	ELECTROSTATIC GROUND
17	O-Y	ELECTROSTATIC GROUND	17	O-Y	ELECTROSTATIC GROUND
43	Y-G	0 V	43	Y-G	0 V
18	G-Y	-48 V	18	G-Y	-48 V
44	Y-BR	0 V	44	Y-BR	0 V
19	BR-Y	-48 V	19	BR-Y	-48 V
45	Y-S	0 V	45	Y-S	0 V
20	S-Y	-48 V	20	S-Y	-48 V
46	V-BL	0 V	46	V-BL	0 V
21	BL-V	-48 V	21	BL-V	-48 V
47	V-O	0 V	47	V-O	0 V
22	O-V	-48 V	22	O-V	-48 V
48	V-G	0 V	48	V-G	0 V
23	G-V	-48 V	23	G-V	-48 V
49	V-BR	0 V	49	V-BR	0 V
24	BR-V	-48 V	24	BR-V	-48 V
50	V-S	0 V	50	V-S	0 V
25	S-V	-48 V	25	S-V	-48 V



X1286R5

Figure 10-3(a) SX-200 Connector Locations

CONNECTOR			CONNECTOR			CONSOLE INTERFACE CONNECTOR		
SHELF	NO.	DESTINATION	BOARD	NO.	DESTINATION	BOARD	NO.	DESTINATION
1	P1	X-CONNECT	INTER-CONNECT	J13	MAINTENANCE CONSOLE		J22	CONSOLE 1
	P2	X-CONNECT		J14	P25 (NOTE 2)		P23	J15
	P3	X-CONNECT		J15	P23 (NOTE 2)		J24	CONSOLE 2
	P4	X-CONNECT		P16	P6		P25	J14
	P5	P17		P17	P5			
P6	P18	P18		X-CONNECT				
2	P7	X-CONNECT		P19	X-CONNECT			
	P8	X-CONNECT		P301	MAINTENANCE PANEL			
	P9	X-CONNECT		P302	RS232 OR			
	P10	X-CONNECT		J302	RS232			
	P11	NC	P203	POWER SUPPLY				
	P12	NC	P20	X-CONNECT				
		P21	X-CONNECT					

Figure 10-3(b) SX-200 Connector Locations




Figure 10-4 Power Fail Transfer Block Diagram






Figure 10-5 Power Fail Transfer Wiring Diagram

X260

NIGHT BELL CONNECTION AUXILIARY RELAY



NIGHT BELL RELAY DIRECT




INTERCONNECT BOARD PLUG P18							
PIN	DESTINATION	PIN	DESTINATION	PIN	DESTINATION	PIN	DESTINATION
46	NIGHT BELL 1 K1	44	NIGHT BELL 2 K2	50	NIGHT BELL 3 K3	48	NIGHT SERVICE A K4
21	NIGHT BELL 1 R(K1)	19	NIGHT BELL 2 R(K2)	25	NIGHT BELL 3 R(K3)	24	NIGHT SERVICE B(K4)

- NOTE 1: THE FACILITY IS WIRED TO EITHER THE SX-100 OR THE SX-200 TERMINAL BLOCKS AS INDICATED BY THE DASHED LINES.
- NOTE 2: THE NIGHT SERVICE RELAY K4 CONTACTS ARE IDENTICAL TO THE NIGHT BELL CONTACT ARRANGEMENTS. IT MAY BE USED TO OPERATE A LAMP TO SHOW WHEN THE ACD IS IN NIGHT SERVICE, OR SIGNAL THE CD FOR THIS CONDITION.

X572R4

Figure 10-6 Night Bell Connections



X5573

Figure 10-7 Music and PA Connections




Figure 11-1 Typical Terminal Layout




Figure 12-1 Static Protection Ground Strap

APPENDIX 1

MITEL ACTION PROCEDURES

GENERAL

A1.01 Task oriented functions in this Section are implemented using MITEL Action Procedures (MAP's).

A1.02 A MAP is a step-by-step procedure using a flow chart principle, written and illustrated where necessary to a level of detail that allows both experienced and inexperienced personnel to carry out the tasks detailed. A MAP contains two levels of information as follows:

- (a) For experienced personnel, a series of steps (level one) each numbered (n) and annotated with minimal information.
- (b) For inexperienced personnel, each step referred to in (a) above is amplified by a connected series of numbered substeps (nA) (level two).

A1.03 A typical example of a MAP is shown in Figure A1-1, with the two levels detailed.

MAP SYMBOLS

A1.04 There are four basic symbol shapes which may be used in a MAP, and are defined as follows.

A1.05 AND Block: Used to indicate a level one step that must be performed. Consists of a square with the word AND centered in the block.

A1.06 OR Block: Used to indicate a choice of level one steps, one of which must be performed. Consists of a rectangle, with the text centered in the block, and with the word OR appearing between the alternative operations.

A1.07 The rectangle is also used to border instructions which imply that the operative must perform a task outside the scope of the MAP. The text is centered in the rectangle.

A1.08 DECISION Block: Used to indicate a decision within the level one steps which must be made. The symbol is based on a hexagon with the top and bottom sides extended. Decision text is centered in the symbol.


A1.09 START/FINISH/JUMP TO Block: Used to indicate the start and finish of a MAP. Also used to indicate "jump to" points within the MAP, for example "go to (n)" or "from (n)" or "return to (n)". The

ANSWER DID TRUNK CALL

MAP215-152

Issue 1, January 80

Sheet 1 of 2



A-4 90

M110

Figure A1-1 Typical MAP Page

symbol is a rectangle with semicircular ends. Text is centered in the symbol.

THE OPERATOR'S USE OF MAP'S

Experienced Operator

A1.10 For the experienced operator to complete a task using a MAP, reference to the sequential short form level one steps is usually all that is necessary. Using Figure A1-1 as an example, the experienced operator would proceed as follows.

A1.11 At (1) makes a decision based on the information within the block. If the answer is YES, the operator must proceed to a different MAP. If the answer is NO, the operator is faced with another decision at block (2).

A1.12 At (2) if the decision is NO, there is no requirement to proceed further and the test is abandoned. This naturally results in a FINISH block. If the decision is YES, the operator proceeds to (3) and (4) in succession (i.e. dials the DID station number and completes the call to the check extension).

A1.13 The description of the instructions carried out in A1.05 and A1.06 have assumed that the level of competence of the operator is such that short form level one steps contain sufficient information, and therefore the operator reads only the center column of the MAP, top to bottom of the page.

Inexperienced Operator

A1.14 If the operator's experience is such that the level one instructions do not contain sufficient information, the level two substeps should be referred to as follows.

A1.15 Using Figure A1-1 as an example, the path followed should be:

- (a) At (1) and (2) make the decisions called for at these steps as before.
- (b) At step (3) dial the DID station number by performing substeps (3A), (3B) and (3C).

In terms of steps and substeps, the operative follows a decision, decision then step and substep paths in the example shown.

TOOLS, TEST EQUIPMENT AND SPECIAL INSTRUCTIONS

A1.16 Any tools, test equipment or special instructions that the operator requires or needs to know are stated on the first page of each MAP. If the MAP is long, and contains a number of subprocedures, these are listed in synopsis form on the first page.

APPENDIX 2

FCC INTERCONNECTION REQUIREMENTS

A. TELEPHONE COMPANY INTERCONNECTION

General

A2.01 This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard 50-pin blue ribbon prescribed by the FCC Rule. This section is applicable to telephone interconnection in the United States.

Notification

A2.02 Prior to the interconnection of this equipment, the local telephone company is to be notified; inform the company that you have FCC-registered equipment which you wish to connect to their trunks. Give them the following information:

- The PABX being connected is a MITEL Incorporated Model SX-100 or a Model SX-200.
- The 14-digit FCC Registration Number for the SX-100 is BN285B64724MFE.
- The 14-digit FCC Registration Number for the SX-200 is BN285B64724MFE.
- The Ringer Equivalence number which is 2.1B.
- The jacks or connectors required are RJ2IX, RJ2EX or RJ2GX as shown in Table A2-1.

Connection Limitations

A2.03 Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service.

Network Changes

A2.04 The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in the operational characteristics of its trunk, etc. Before doing this, however, the company shall provide official notification, so that the operation of the PABX service will not be interrupted.

Maintenance Limitations

A2.05 This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC Program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this Standard Practice.

A2.06 Circuit cards may be removed by the user; however, replacement cards are to be supplied only by MITEL or its authorized agent. No field repair of circuit cards by the user is authorized.

A2.07 No cabling or wiring changes within the console are permitted by the user. Plug-ended cables, as detailed in this Standard Practice, are to be used for all external connections between the console and the telephone company interface jack.

A2.08 Power supply components and cabling is only to be changed or maintained by MITEL or by an authorized agent of MITEL.

Trouble Corrections

A2.09 Most troubles are diagnosed by the circuitry of the system, and the console readout indicates the circuit and card that is malfunctioning. Card replacement can be made by the user.

A2.10 For more complex malfunctions, appropriate field service is provided by MITEL or its authorized agents.

TABLE A2-1
USOC CONNECTOR PIN DESIGNATIONS

Pair Pin Color	Connector Type			Pair Pin Color	Connector Type		
	RJ2IX	RJ2EX	RJ2GX		RJ2IX	RJ2EX	RJ2GX
26 W-BL	T	T	T	38 BK-G	T	T	T
1 BL-W	R	R	R	13 G-BK	R	R	R
27 W-O	T	E	T1	39 BK-BR	T	E	T1
2 O-W	R	M	R1	14 BR-BK	R	M	R1
28 W-G	T	T	E	40 BK-S	T	T	E
3 G-W	R	R	M	15 S-BK	R	R	M
29 W-BR	T	E	T	41 Y-BL	T	E	T
4 BR-W	R	M	R	16 BL-Y	R	M	R
30 W-S	T	T	T1	42 Y-O	T	T	T1
5 S-W	R	R	R1	17 O-Y	R	R	R1
31 R-BL	T	E	E	43 Y-G	T	E	E
6 BL-R	R	M	M	18 G-Y	R	M	M
32 R-O	T	T	T	44 Y-BR	T	T	T
7 O-R	R	R	R	19 BR-Y	R	R	R
33 R-G	T	E	T1	45 Y-S	T	E	T1
8 G-R	R	M	R1	20 S-Y	R	M	R1
34 R-BR	T	T	E	46 V-BL	T	T	E
9 BR-R	R	R	M	21 BL-V	R	R	M
35 R-S	T	T	E	47 V-O	T	E	T
10 S-R	R	M	R	22 O-V	R	M	R
36 BK-BL	T	T	T1	48 V-G	T	T	T1
11 BL-BK	R	R	R1	23 G-V	R	R	R1
37 BK-O	T	E	E	49 V-BR	T	E	E
12 O-BK	R	M	M	24 BR-V	R	M	M
				50 V-S	SPARE		
				25 S-V	SPARE		

Remarks

The types of Universal Service Order Code (USOC) connectors shown have pin designations according to type of interface required by the Telephone Company. Use of these connectors are determined as follows:

RJ2IX: 2-wire loop, or ground start trunk
 2-wire reverse battery (DID)
 2-wire off-premises extension
 (Class A through E)
 2-wire Automatic Identified Outward
 Dialing (AIOD)
 2-wire message register

RJ2EX: 2-wire tie trunk with E and M Type I signaling

RJ2GX: 4-wire tie trunk with E and M Type I signaling

APPENDIX 3

SX-100 INSTALLATION PROCEDURES

1. GENERAL

A3.01 The MAP's contained in this Appendix detail the procedures to be performed to complete the installation of an SX-100 ACD System.

TABLE A3-1
SX-100 INSTALLATION PROCEDURE

Step	Procedure	Reference
1	Unpack SX-100 Equipment	MAP200-301
2	Unpack Console(s)	MAP200-302
3	Install Console Faceplate Designations	MAP200-303
4	Inspect Equipment	MAP200-304
5	Install and Connect Equipment	MAP200-305
6	Set Card Switches (Appendix 5)	MAP200-306
7	Power-Up System (See Note)	MAP200-307
8	Program System	Section MITL9105/9110-090-210-NA
9	Perform System Tests	Section MITL9105/9110-090-215-NA
10	Perform Extension Test	Section MITL9105/9110-090-320-NA

Note: Appendix 6 lists miscellaneous installation requirements which may be required prior to power-up of system. This appendix should be reviewed for applicability.

UNPACK SX-100 EQUIPMENT

MAP200-301

Issue 1, September, 1983

Sheet 1 of 3

TOOLS REQUIRED


1. Set of strap cutters

WARNING

Gloves must be worn when unpacking equipment cabinet.

CAUTION

Care must be taken while moving equipment to avoid damage.



UNPACK SX-100 EQUIPMENT

MAP200- 301

Issue 1, September, 1983

Sheet 2 of 3





Fig. 301-1 Remove External Packing

UNPACK SX-100 EQUIPMENT
MAP200-301
Issue 1, September, 1983
Sheet 3 of 3



X264

Fig. 301-2 Remove Shipping Pallet

UNPACK CONSOLES

MAP200-302

Issue 1, September, 1983

Sheet 1 of 4

TOOLS REQUIRED

1 Screwdriver 0.25 inch blade

AT CONSOLE LOCATION

- (1A) Remove fiberglass tape from top of packing case
- (1B) Open packing case and remove foam sheet
- (1C) Remove cardboard insert
- (1D) Remove console accessory bag from insert
- (1E) Remove console from packing case
- (1F) Remove polyethylene sheet from console
- (1G) Place all packing material in packing case for use in reshipment

- (2A) Remove the two pieces of the bracket assembly and the five securing screws (Fig. 302-1) from the accessory bag
- (2B) Determine to which side of the console the cradle assembly is to be mounted, and assemble the two brackets accordingly. Fig. 302-1 shows a right-mounted assembly
- (2C) Secure the two brackets together with two 8-32 hex screws and felt washers using the wrench supplied
- (2D) Place console face down on desk top
- (2E) Position bracket as shown in Fig. 302-1 (or the dotted outline if it is a left-mount assembly)
- (2F) Attach bracket to base of console with three 6-32 screws




UNPACK CONSOLES

MAP200- 302

Issue 1, September, 1983

Sheet 2 of 4



UNPACK CONSOLES

MAP200-302

Issue 1, September, 1983

Sheet 3 of 4






Fig. 302-1 Install Bracket Assembly

UNPACK CONSOLES
MAP200- 302
Issue 1, September, 1983
Sheet 4 of 4




INSTALL CONSOLE FACEPLATE DESIGNATIONS

MAP200-303

Issue 1, September, 1993

Sheet 1 of 5




INSTALL CONSOLE FACEPLATE DESIGNATIONS

MAP200- 303

Issue 1, September, 1983

Sheet 2 of 5




INSTALL CONSOLE FACEPLATE DESIGNATIONS

MAP200-303

Issue 1, September, 1983

Sheet 3 of 5



INSTALL CONSOLE FACEPLATE DESIGNATIONS
MAP200- 303
Issue 1, September, 1983
Sheet 4 of 5




Fig. 303-1 Attendant - Console Key Designation, Hotel/Motel


X3103

INSTALL CONSOLE FACEPLATE DESIGNATIONS

MAP200-303


Issue 1, September, 1983

Sheet 5 of 5



X3102

Fig. 303-2 Standard Programming Console



X5257

Fig. 303-3 Commercial Key Designations

INSPECT EQUIPMENT

MAP200-304

Issue 1, September, 1983


Sheet 1 of 4

TOOLS REQUIRED


1 Phillips Screwdriver
1 Slot Screwdriver

CAUTION

When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.



INSPECT EQUIPMENT
MAP200-304
Issue 1, September, 1983
Sheet 2 of 4




INSPECT EQUIPMENT


MAP200-304

Issue 1, September, 1983

Sheet 3 of 4



INSPECT EQUIPMENT
MAP200- 304
Issue 1, September, 1983
Sheet 4 of 4



INSTALL EQUIPMENT

MAP200-305

Issue 1, September, 1983


Sheet 1 of 8

TOOLS REQUIRED


0.25 in. Slotted Screwdriver
 0.25 in. thick wooden backboard
 (Wall-mount installation only)

CAUTION

When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.



INSTALL EQUIPMENT
MAP200- 305
Issue 1, September, 1983
Sheet 2 of 8




INSTALL EQUIPMENT


MAP200-305

Issue 1, September, 1983

Sheet 3 of 8



INSTALL EQUIPMENT
MAP200- 305
Issue 1, September, 1983
Sheet 4 of 8




INSTALL EQUIPMENT


MAP200-305

Issue 1, September, 1983

Sheet 5 of 8



INSTALL EQUIPMENT
MAP200- 305
Issue 1, September, 1983
Sheet 6 of 8



INSTALL EQUIPMENT

MAP200-305

Issue 1, September, 1983

Sheet 7 of 8




Fig. 305-1 Wall Mounting

INSTALL EQUIPMENT

MAP200- 305

Issue 1, September, 1983

Sheet 8 of 8




Fig. 305-2 Cable Connections

X952F13

SET CARD SWITCHES
MAP200-306
Issue 1, September, 1983
Sheet 1 of 1

The setting of switches, to result in the required mode of operation on the Trunk Cards is detailed in the MAP's contained in Appendix A-5. The installer should ensure that these cards are properly switched for the correct mode of operation prior to performing "Power-Up" as detailed in MAP200-307.

POWER-UP SYSTEM


MAP200-307

Issue 1, September, 1983

Sheet 1 of 3

CAUTION

When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.



POWER-UP SYSTEM
MAP200- 307
Issue 1, September, 1983
Sheet 2 of 3




Fig. 307-1 Maintenance Panel

POWER-UP SYSTEM

MAP200-307

Issue 1, September, 1983

Sheet 3 of 3


NOTE

To program the system go to Section MITL9105/9110-090-210-NA.

NOTE

Occasionally, when circuit cards are plugged into the ACD system, the logic circuits on the card may not reset completely. In order to guarantee complete reset of all card logic, a slot initialization procedure must be performed. This procedure allows the service personnel to insert a card into a shelf and initialize the card slot. To initialize the card slot dial 555 + 5 + nn, where nn is the 2-digit card slot number (01-17 shelf 1, 31-42 shelf 2). Since inserting a card may cause diagnostic errors, this procedure is normally followed by dialing 555 + 1 to clear all system errors.

(5A) Place equipment cabinet in its final position if required



APPENDIX 4

SX-200 INSTALLATION PROCEDURES

1. GENERAL

A4.01 The following Table A4-1 details the procedures to be performed to complete the installation of an SX-200 ACD System.

A4.02 The SX-100 and SX-200 may utilize the same consoles. For this reason refer to MAP's 200-302, 200-303 and 200-304 of Appendix 3 when dealing with the console.

TABLE A4-1
SX-200 INSTALLATION

Step	Procedure	Reference
1	Unpack Equipment Cabinet	MAP200-401
2	Unpack Consoles	MAP200-302
3	Install Console Faceplate Designations	MAP200-303
4	Inspect Equipment	MAP200-404
5	Connect Cables	MAP200-405
6	Set Card Switches (Appendix 5)	MAP200-406
7	Power-Up System (See Note)	MAP200-407
8	Program System	Section MITL9105/9110-090-210-NA
9	Perform System Tests	Section MITL9105/9110-090-215-NA
10	Perform Extension Tests	Section MITL9105/9110-090-320-NA

Note: Appendix 6 lists miscellaneous installation requirements which may be required prior to power-up of system. This Appendix should be reviewed for applicability.

UNPACK EQUIPMENT CABINET

MAP200-401

Issue 1, September 1983

Sheet 1 of 4

START

TOOLS REQUIRED

1. Set of strap cutters

WARNING

Gloves must be worn when unpacking equipment cabinet.

CAUTION

Care must be taken when moving cabinet to avoid damage.

- (1A) Cut and remove retaining straps
 (1B) Open triwall outer sleeve
 (1C) Remove inner triwall sleeve

AND

REMOVE
EXTERNAL
PACKING (FIG.
401-1)

- (2A) Position equipment so that approx. ten inches of cabinet overhangs shipping pallet (Fig. 401-2)
 (2B) Tip equipment so that rear of cabinet touches floor
 (2C) Remove shipping pallet from under cabinet
 (2D) Gently lower cabinet onto floor

AND

REMOVE
SHIPPING
PALLET (FIG.
401-2)

- (3A) Push cabinet to its required location
 (3B) Position cabinet as shown in Fig. 401-3
 (3C) Remove plastic sheet from cabinet

AND

POSITION
CABINET (FIG.
401-3)


REMOVE



Fig. 401-2 Remove Shipping Pallet

Go to (4)

UNPACK EQUIPMENT CABINET
MAP200- 401
Issue 1, September 1983
Sheet 2 of 4



(5A) Complete relevant entries on
Damage Report Form

UNPACK EQUIPMENT CABINET

MAP200-401

Issue 1, September 1983

Sheet 3 of 4





Fig. 401-1 Remove External Packing

UNPACK EQUIPMENT CABINET
MAP200- 401
Issue 1, September 1983
Sheet 4 of 4



X257R1

Fig. 401-3 Position Cabinet

INSPECT EQUIPMENT

MAP200-404

Issue 1, September 1983


Sheet 1 of 4

TOOLS REQUIRED



1 Phillips Screwdriver
1 Slot Screwdriver - 1/4 in.

CAUTION

When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.



INSPECT EQUIPMENT
MAP200- 404
Issue 1, September 1983
Sheet 2 of 4



X262


Fig. 404-1

INSPECT EQUIPMENT

MAP200-404

Issue 1, September 1983


Sheet 3 of 4



INSPECT EQUIPMENT
MAP200- 404
Issue 1, September 1983
Sheet 4 of 4

(14A) Tag defective items and continue with inspection
 (14B) Fill in relevant portion of Damage Report

(16A) Repack tagged items




CONNECT CABLES


MAP200-405

Issue 1, September 1983

Sheet 1 of 4



CONNECT CABLES
MAP200- 405
Issue 1, September 1983
Sheet 2 of 4



CONNECT CABLES

MAP200-405

Issue 1, September 1983

Sheet 3 of 4





Fig. 405-1 SX-200 Rear View

X511R1

CONNECT CABLES
MAP200- 405
Issue 1, September 1983
Sheet 4 of 4



SET CARD SWITCHES
MAP200-406
Issue 1, September 1983
Sheet 1 of 1

The setting of switches, to result in the required mode of operation on the Trunk Cards is detailed in the MAP's contained in Appendix A-5. The installer should ensure that these cards are properly switched for the correct mode of operation prior to performing "Power-Up" as detailed in MAP200-407.

POWER-UP SYSTEM


MAP200- 407

Issue 1, September 1983

Sheet 1 of 5

CAUTION

When handling shelf cards or similar modules ensure that the procedures in paragraph 12.02 are followed.



POWER-UP SYSTEM
MAP200- 407
Issue 1, September 1983
Sheet 2 of 5




Fig. 407-1 Maintenance Panel

POWER-UP SYSTEM

MAP200-407

Issue 1, September 1983

Sheet 3 of 5

NOTE

Occasionally, when circuit cards are plugged into the ACD system, the logic circuits on the card may not reset completely. In order to guarantee complete reset of all card logic, a slot initialization procedure must be performed. This procedure allows the service personnel to insert a card into a shelf and initialize the card slot. To initialize the card slot dial $555 + 5 + nn$, where nn is the 2 digit card slot number (01-17 shelf 1, 31-42 shelf 2). Since inserting a card may cause diagnostic errors, this procedure is normally followed by dialing $555 + 1$ to clear all system errors.

AT FRONT OF CABINET

- (4A) Set SYSTEM POWER switch to ON
 (4B) SYSTEM POWER LED lit
 ON POWER SUPPLY
 (4C) EQUIPMENT SHELF POWER ON LED lit on power supply

From (3)

AND

SWITCH
POWER ON

[5]

Are all required
LED's lit

NO

YES

Set all Power Switches to OFF.
Remove Power Cord(s)Go to
MITL9105-
9110-090-350-NA


AND

POSITION
CABINET

Go to (7)


- (6A) Close and lock all doors
 (6B) Position cabinet

POWER-UP SYSTEM
MAP200- 407
Issue 1, September 1983
Sheet 4 of 5



(8A) Go to MITL9105-9110-090-210-NA and program system

POWER-UP SYSTEM
MAP200- 407
Issue 1, September 1983
Sheet 5 of 5



X3274

Fig. 407-2 SX-200 Rear View

APPENDIX 5

CARD SWITCH SETTINGS

1. GENERAL

A5.01 The MAP's contained in this Appendix (see Table A5-1) detail the procedures to be performed to result in the correct settings of the Trunk Card switches (i.e. those required to meet the particular needs of the installation).

A5.02 These procedures are performed during the installation of the SX-100 or SX-200 ACD Systems (referenced in Appendices 3 and 4).

TABLE A5-1
SETTING TRUNK CARD SWITCHES


Step	Procedure	Reference
1	Set CO Trunk Switches (Types 011-000/111-000)	MAP200-501
2	Set E&M/Tie Trunk Option Switches	MAP200-502
3	Set DID/Tie Trunk Option Switches	MAP200-503
4	Set Scanner Card Baud Rate Switch	MAP200-504
5	Set RAM/COS Switches	MAP200-505
6	Set CO Trunk Switches (Types 211-000/311-000)	MAP200-506
7	Set IPC Battery Switch	MAP200-507
8	Install SX-100 Fan Update Kit	MAP200-508

SET CO TRUNK SWITCHES (TYPES -011/111)
MAP200- 501
Issue 1, September 1983
Sheet 1 of 7


CAUTION
When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.

NOTE
Use MAP200-505 when setting switches on Trunk Card Types 9110-211-000 or -311-000.

NOTE
Installation Forms for trunk card settings, VOLUME 3 must be completed before proceeding with this MAP.



SET CO TRUNK SWITCHES (TYPES -011/111)
MAP200- 501
Issue 1, September 1983
Sheet 2 of 7




(5A) Identify trunk circuit
 (5B) Set idle conditions on trunk BUSY switch (see Notes)

SET CD TRUNK SWITCHES (TYPES -011/111)


MAP200- 501

Issue 1, September 1983


Sheet 3 of 7



SET CD TRUNK SWITCHES (TYPES -011/111)
MAP200- 501
Issue 1, September 1983
Sheet 4 of 7



SET CO TRUNK SWITCHES (TYPES -011/111)
MAP200- 501
Issue 1, September 1983
Sheet 5 of 7



(16A) Check extractor color code
machines slot color code
(16B) Lock card in position

SET CO TRUNK SWITCHES
(TYPES -011/111)

MAP200- 501

Issue 1, September 1983

Sheet 6 of 7




Fig. 501-1 Trunk Card Types 9110-011 and -111

SET CO TRUNK SWITCHES (TYPES -011/111)

MAP200- 501

Issue 1, September 1983

Sheet 7 of 7

NOTES:

TRUNK BUSY SWITCHES

1. OUTGOING BUSY SWITCHES (1 PER TRUNK) CAN BE SET FOR EITHER:
 IDLE - NORMAL TRUNK OPERATION
 BUSY - TRUNK CANNOT BE SEIZED FOR OUTGOING CALL
2. THE "OUTGOING BUSY" CONDITION MAY BE SET EITHER BY THE OUTGOING BUSY SWITCH (NOTE 1), OR BY THE CONSOLE "TRUNK BUSY OUT" FUNCTION. WHEN THIS CONDITION IS IN EFFECT THE INCOMING BUSY SWITCH AFFECTS THE TRUNK CONDITION AS FOLLOWS:
 IDLE - NO ANSWER WILL BE GIVEN TO INCOMING CO CALLS
 BUSY - A PERMANENT SEIZURE CONDITION IS GIVEN TOWARDS THE CO
3. INCOMING BUSY HAS NO EFFECT WHILE OUTGOING BUSY IS NOT SET.

TRUNK CONTROL SWITCHES

4. ACTIVE TRUNK CONTROL SWITCHES ON NONMODULAR CARD ARE CONFINED TO SWITCHES 1, 2, 3 AND 4, CORRESPONDING TO TRUNK 1, 2, 3 AND 4, 3RD WIRE CONDITIONS RESPECTIVELY (NOTE 5).

3RD WIRE SWITCHES

5. THE 3RD WIRE LEAD WHEN REQUIRED IS CONNECTED TO THE CO TO PROVIDE CERTAIN FACILITIES. THESE INCLUDE THE RECORDING OF METER PULSES (EXTENDED FROM THE CO); OR ANOTHER REQUIREMENT MAY BE A BUSY CONDITION WHEN DICTATION OR CODE CALLING EQUIPMENT AT THE CO HAS BEEN TAKEN INTO SERVICE BY OTHER TRUNKS. THE SWITCH SETTING IS EITHER:
 OPEN - RECOGNIZED GROUND FROM THE CO AS A BUSY CONDITION
 CLOSED - 3RD WIRE SWITCH IS INEFFECTIVE

LOOP/GROUND START SWITCHES

6. THE LOOP/GROUND START SWITCHES (1 PER TRUNK) CAN BE SET TO RESULT IN THE FOLLOWING CONDITIONS:
 LOOP (1) SETTING - USED FOR LOOP-START TYPE TRUNKS
 GROUND (2) SETTING - USED FOR GROUND-START TYPE TRUNKS

RELEASE TIME SWITCHES

7. VALID TRUNK RELEASE TIMES ARE RECOGNIZED BY THE FOLLOWING RELEASE TIME SETTINGS ON -0100 TO -0103 TYPE PROMS:
 OPEN - GREATER THAN 50 ms OF NO LOOP CURRENT
 CLOSED - GREATER THAN 500 ms OF NO LOOP CURRENT
8. VALID TRUNK RELEASE TIMES ARE RECOGNIZED BY THE FOLLOWING RELEASE TIME SETTINGS FOR PROM TYPE -0004 WITH SWITCHES "A" AND "B":

"A" SETTING	"B" SETTING	RELEASE TIME
OPEN	CLOSED	50 ms
CLOSED	CLOSED	500 ms
OPEN	OPEN	2.5 s
CLOSED	OPEN	INFINITE (NON-RELEASE)

IGNORE REVERSALS


9. IF LINE REVERSALS ON THE TRUNK CIRCUIT ARE REQUIRED TO HAVE NO EFFECT THE IGNORE REVERSALS SWITCH IS SET TO "OPEN". IF LINE REVERSALS ARE TO BE RECOGNIZED THE SWITCH IS SET TO CLOSED.

SET E&M/TIE TRUNK OPTION SWITCHES
MAP200- 502
Issue 1, September 1983
Sheet 1 of 8

CAUTION
When handling shelf cards or similar modules ensure that the procedures in paragraph 12.02 are followed.

NOTE
Installation Forms for trunk card settings, Volume 3, must be completed before proceeding with this MAP.

- (2A) Locate required trunk circuit card 9110-013-000-NA
- (2B) Note card position
- (2C) Lift card locking clips located at the top and bottom of the card
- (2D) Remove trunk card 9110-031-000-NA




SET E&M/TIE TRUNK OPTION SWITCHES

MAP200- 502

Issue 1, September 1983

Sheet 2 of 8



SET E&M/TIE TRUNK OPTION SWITCHES

MAP200- 502

Issue 1, September 1983


Sheet 3 of 8

NOTE


(10A) results in a 200 ms off-hook signal sent as a "ready to receive dial information" condition.

NOTE

(13A) results in waiting period of 160 to 220 ms off-hook signal from far end before sending dialing.



SET E&M/TIE TRUNK OPTION SWITCHES
MAP200- 502
Issue 1, September 1983
Sheet 4 of 8



SET E&M/TIE TRUNK OPTION SWITCHES


MAP200-502

Issue 1, September 1983


Sheet 5 of 8

NOTE

Special gain applies to 4-wire trunks only.



SET E&M/TIE TRUNK OPTION SWITCHES
MAP200- 502
Issue 1, September 1983
Sheet 6 of 8






Fig. 502-1





Fig. 502-2 E/M 9110-013-000

SET DID/TIE TRUNK OPTION SWITCHES
MAP200-503
Issue 1, September 1983
Sheet 1 of 7


CAUTION
When handling shelf cards or similar modules ensure that the procedures in paragraph 12.02 are followed.

NOTE
Installation Forms for trunk card settings, Volume 3, must be completed before proceeding with this MAP.

- (2A) Locate required trunk circuit card 9110-031-000-NA
- (2B) Note card position
- (2C) Lift card locking clips located at the top and bottom of the card
- (2D) Remove trunk card 9110-031-000-NA



SET DID/TIE TRUNK OPTION SWITCHES
MAP200- 503
Issue 1, September 1983
Sheet 2 of 7



SET DID/TIE TRUNK OPTION SWITCHES

MAP200-503

Issue 1, September 1983


Sheet 3 of 7

NOTE

(8A) results in a 200 ms off-hook signal sent as a "ready to receive dial information" condition.


NOTE

(11A) results in waiting period until off-hook signal of from 160 - 200 ms is received from far end.



SET DID/TIE TRUNK OPTION SWITCHES
MAP200- 503
Issue 1, September 1983
Sheet 4 of 7

NOTE
Trunk stops dialing immediately on receipt of or for the duration of an off-hook signal.



(14A) Set the BG-PULS switch to LOOP PULSING (Fig. 503-1 and 503-2)




Fig. 503-2

(15A) Set the PG-PULS switch to BATTERY and GROUND PULSING (Fig. 503-1 and 503-3)




Fig. 503-3

(17A) Set the STOP DIAL switch to STOP DIAL (Fig. 503-1)


(18A) Set the STOP DIAL switch to NOT STOP DIAL (Fig. 503-1)

SET DID/TIE TRUNK OPTION SWITCHES

MAP200-503

Issue 1, September 1983

Sheet 5 of 7



TRUNK TYPE TABLE

TRUNK TYPE	SWITCH A	SWITCH B
DID TRUNK	CLOSED	CLOSED
LOOP TIE TRUNK	CLOSED	OPEN
INCOMING DIAL - OUTGOING AUTO	OPEN	CLOSED
NOT USED	OPEN	OPEN






Fig. 503-1

X579R2

SET DID/TIE TRUNK OPTION SWITCHES

MAP200- 503

Issue 1, September 1983

Sheet 7 of 7

NOTES

1. TRUNK IMPEDANCE SWITCHES ARE LOCATED ON THE REAR FACE OF THE TRUNK CARD.


TRUNK BUSY SWITCHES

2. OUTGOING BUSY SWITCHES (1 PER TRUNK) CAN BE SET FOR EITHER OF THE FOLLOWING CONDITIONS:
IDLE SETTING - NORMAL TRUNK OPERATION
BUSY SETTING - TRUNK CANNOT BE SEIZED FOR OUTGOING CALL
3. THE "OUTGOING BUSY" CONDITION MAY BE SET EITHER BY THE OUTGOING BUSY SWITCH (NOTE 2), OR BY THE CONSOLE "TRUNK BUSY OUT" FUNCTION. WHEN THIS CONDITION IS IN EFFECT THE INCOMING BUSY SWITCH AFFECTS THE TRUNK CONDITION AS FOLLOWS:
IDLE SETTING - NO ANSWER WILL BE GIVEN TO INCOMING TRUNK CALLS
BUSY SETTING - A PERMANENT SEIZURE CONDITION IS GIVEN TOWARDS THE TRUNK


SET SCANNER CARD SWITCHES
MAP200-504
Issue 1, September 1983
Sheet 1 of 5

CAUTION
When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.

CAUTION
Do not remove Scanner Card from an active ACD system without following relevant procedures in MAP200-602.



SET SCANNER CARD SWITCHES
MAP200- 504
Issue 1, September 1983
Sheet 2 of 5




SET SCANNER CARD SWITCHES

MAP200-504

Issue 1, September 1983

Sheet 3 of 5



SET SCANNER CARD SWITCHES
MAP200- 504
Issue 1, September 1983
Sheet 4 of 5

TABLE 504-1

Data Character Length (i.e. number of data and stop bits) is determined by switch settings as shown in the Table. These switches are as follows:

S2 - Character length A

S3 - Character length B

S4 - Stop bits

Switch Position			Data Bits	Stop Bits
S2	S3	S4		
Closed	Closed	Closed	5	1
Closed	Closed	Open	5	1.5
Open	Closed	Closed	6	1
Open	Closed	Open	6	2
Closed	Open	Closed	7	1
Closed	Open	Open	7	2
Open	Open	Closed	8	1
Open	Open	Open	8	2


The Start Bit is always 1 bit long.

SET SCANNER CARD SWITCHES

MAP200-504

Issue 1, September 1983

Sheet 5 of 5




X3272R2


Fig. 504-1 Scanner Card Type 9110-104-000

SET RAM/COS SWITCHES
MAP200-505
Issue 1, September 1983
Sheet 1 of 3

NOTE This MAP concerns RAM/COS card type 9110-102-000 switch settings. Type 9110-002-000 does not have these switches.
NOTE This MAP applies to Generics 204, 205 and 216.



SET RAM/COS SWITCHES
MAP200- 505
Issue 1, September 1983
Sheet 2 of 3




SET RAM/COS SWITCHES

MAP200-505

Issue 1, September 1983

Sheet 3 of 3



X3165


Fig. 505-1 RAM COS Card

SET CO TRUNK SWITCHES (TYPES -211/311)
MAP200-506
Issue 1, September 1983
Sheet 1 of 8

CAUTION
When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.

NOTE
Use MAP200-501 when setting switches on Trunk Card Types 9110-011-000 or -111-000.


NOTE
Installation Forms for trunk card settings. Volume 3 must be completed before proceeding with this MAP.



(2A) Identify trunk circuit by card position type and unit number

(3A) Lift Card extractors at top and bottom of card
(3B) Remove trunk card from the shelf

SET CO TRUNK SWITCHES (TYPES -211/311)
MAP200- 506
Issue 1, September 1983
Sheet 2 of 8




SET CO TRUNK SWITCHES (TYPES -211/311)


MAP200- 506

Issue 1, September 1983

Sheet 3 of 8



SET CD TRUNK SWITCHES (TYPES -211/311)
MAP200- 506
Issue 1, September 1983
Sheet 4 of 8




SET CO TRUNK SWITCHES (TYPES -211/311)


MAP200- 506

Issue 1, September 1983

Sheet 5 of 8



SET CO TRUNK SWITCHES (TYPES -211/311)
MAP200- 506
Issue 1, September 1983
Sheet 6 of 8




SET CO TRUNK SWITCHES
(TYPES -211/311)

MAP200-506

Issue 1, September 1983

Sheet 7 of 8



TRUNK CONTROL SWITCH FUNCTIONS

SWITCH NO.	FUNCTION	TYPE		NOTES
		-211	-311	
1	3RD WIRE TRUNK 1	X	X	5
2	3RD WIRE TRUNK 2	X	X	5
3	3RD WIRE TRUNK 3	X	X	5
4	3RD WIRE TRUNK 4	X	X	5
5	IGNORE REVERSALS	X	X	6
6	RELEASE TIME "A"	X	X	7
7	MAKE/BREAK RATIO	-	X	8
8	RELEASE TIME "B"	X	X	7
9	NOT USED	-	-	
10	NOT USED	-	-	

"X" INDICATES THAT FUNCTION STATED IS APPLICABLE FOR THE TYPE 9110-211-000 OR -311-000 TRUNK CARDS; AS NOTED UNDER THE COLUMN HEADINGS.

* IN CANADA THE CO TRUNK CARD HI-Z SWITCH MUST ALWAYS BE SET TO HI-Z

X1266R4

Fig. 506-1 Trunk Card Switch Identification

**SET CO TRUNK SWITCHES
(TYPES -211/311)**

MAP200- 506

Issue 1, September 1983

Sheet 8 of 8

NOTES:

TRUNK BUSY SWITCHES

1. OUTGOING BUSY SWITCHES (1 PER TRUNK) CAN BE SET FOR EITHER:
IDLE - NORMAL TRUNK OPERATION
BUSY - TRUNK CANNOT BE SEIZED FOR OUTGOING CALL
2. THE "OUTGOING BUSY" CONDITION MAY BE SET EITHER BY THE OUTGOING BUSY SWITCH (NOTE 1), OR BY THE CONSOLE "TRUNK BUSY OUT" FUNCTION. WHEN THIS CONDITION IS IN EFFECT THE INCOMING BUSY SWITCH AFFECTS THE TRUNK CONDITION AS FOLLOWS:
IDLE - NO ANSWER WILL BE GIVEN TO INCOMING CO CALLS
BUSY - A PERMANENT SEIZURE CONDITION IS GIVEN TOWARDS THE CO
3. INCOMING BUSY HAS NO EFFECT WHILE OUTGOING BUSY IS NOT SET

TRUNK CONTROL SWITCHES

4. THE TRUNK CONTROL SWITCHES ARE PROGRAMMED TO RESULT IN THE FEATURES SHOWN BELOW.

3RD WIRE SWITCHES

5. THE 3RD WIRE LEAD WHEN REQUIRED IS CONNECTED TO THE CO TO PROVIDE CERTAIN FACILITIES. THESE INCLUDE THE RECORDING OF METER PULSES (EXTENDED FROM THE CO); OR ANOTHER REQUIREMENT MAY BE A BUSY CONDITION WHEN DICTATION OR CODE CALLING EQUIPMENT AT THE CO HAS BEEN TAKEN INTO SERVICE BY OTHER TRUNKS. THE SWITCH SETTING IS EITHER:
OPEN - RECOGNIZES GROUND FROM THE CO AS A BUSY CONDITION
CLOSED - 3RD WIRE SWITCH IS INEFFECTIVE

IGNORE REVERSALS

6. IF LINE REVERSALS ON THE TRUNK CIRCUIT ARE REQUIRED TO HAVE NO EFFECT THE IGNORE REVERSALS SWITCH IS SET TO "OPEN". IF LINE REVERSALS ARE TO BE RECOGNIZED THE SWITCH IS SET TO CLOSED.

RELEASE TIME SWITCHES

7. VALID TRUNK RELEASE TIMES ARE RECOGNIZED BY THE FOLLOWING RELEASE TIME SETTINGS FOR PROM TYPE -0004 WITH SWITCHES "A" AND "B":

"A" SETTING	"B" SETTING	RELEASE TIME
OPEN	CLOSED	50 ms
CLOSED	CLOSED	500 ms
OPEN	OPEN	2.5 s
CLOSED	OPEN	INFINITE (NON-RELEASE)

MAKE/BREAK RATIO

8. THE MAKE/BREAK RATIO SWITCH FUNCTION IS PROGRAMMED FOR TYPE 9110-311 ONLY. THE SWITCH SETTINGS RESULT IN THE FOLLOWING RATIOS:
OPEN - 33/66 (33% MAKE, 66% BREAK)
CLOSED - 40/60 (40% MAKE, 60% BREAK)
TYPE 9110-211 IS FIXED AT 40/60 RATIO.

LOOP/GROUND START SWITCHES

9. THE LOOP/GROUND START SWITCHES (1 PER TRUNK) CAN BE SET TO:
LOOP - USED FOR LOOP-START TYPE TRUNKS
GROUND - USED FOR GROUND-START TYPE TRUNKS

XT SWITCH

10. THE XT SWITCH (1 PER TRUNK) IS USED IN CONJUNCTION WITH THE 3RD WIRE SWITCH (NOTE 5) AND CAN BE SET TO PROVIDE THE FOLLOWING CONDITIONS:
-48 V - THE CIRCUIT RESPONDS TO A -48 Vdc SIGNAL (E.G. WHEN IT IS A METER PULSE OR A BUSY CONDITION). A GROUND IS EQUIVALENT TO AN OPEN.
GND - THE CIRCUIT RESPONDS TO A GROUND SIGNAL (E.G. WHEN IT IS A METER PULSE OR A BUSY CONDITION). A -48 Vdc SIGNAL IS EQUIVALENT TO OPEN.

HI-Z SWITCH

11. THE HI-Z SWITCH ALLOWS THE PROPER IMPEDANCE ON INCOMING CALLS. TO BE PRESENTED ACCORDING TO REQUIREMENTS. THE TWO SETTINGS FOR THE SWITCH RESULT IN THE FOLLOWING:
HI-Z SETTING - PRESENTS THE NORMAL IMPEDANCE TO INCOMING RINGING SIGNALS, BUT A HIGH BLOCKING IMPEDANCE TO VOICE SIGNALS
NORM SETTING - PRESENTS A NORMAL IMPEDANCE TO BOTH RINGING SIGNALS AND VOICE SIGNALS
IN CANADA THE HI-Z SWITCH MUST BE SET TO HI-Z

SET IPC BATTERY SWITCH
MAP200-507
Issue 1, September 1983
Sheet 1 of 3


Note:
It may be desirable to use the Customer Data Dump/Load feature of the SX-100/SX-200. See MAP200-610.

WARNING:
If an IPC is to be installed in an SX-100, an SX-100 Fan Update Kit must be installed. MAP200-508

- (1A) Put on a static wrist strap
- (1B) Unpack the IPC card and inspect it for damage



UNPACK IPC CARD




YES

Repackage and return to MITEL.
Stop until a new IPC is obtained.




TURN IPC CARD BATTERY PACK ON



- (3A) Turn the IPC card battery pack switches to the ON position as per Fig. 506-1

SET IPC BATTERY SWITCH
MAP200- 507
Issue 1, September 1983
Sheet 2 of 3






Fig. 507-1 IPC Card

INSTALL SX-100 FAN UPDATE KIT


MAP200-508

Issue 1, September 1983

Sheet 1 of 3

WARNING

SYSTEM MUST BE POWERED DOWN TO INSTALL KIT.
--




INSTALL SX-100 FAN UPDATE KIT

MAP200- 508

Issue 1, September 1983

Sheet 2 of 3



INSTALL SX-100 FAN
UPDATE KIT

MAP200-508

Issue 1, September 1983

Sheet 3 of 3





Fig. 508-1

INSTALL SUPERSET 3/4


MAP200- 509

Issue 1, September 1983

Sheet 1 of 7



INSTALL SUPERSET 3/4
MAP200- 509
Issue 1, September 1983
Sheet 2 of 7




INSTALL SUPERSET 3/4

MAP200-509

Issue 1, September 1983

Sheet 3 of 7







Fig. 509-1 SUPERSET 3 and Packaging

INSTALL SUPERSET 3/4

MAP200-509

Issue 1, September 1983

Sheet 5 of 7



X8503

Fig. 509-2 SUPERSET 3

INSTALL SUPERSET 3/4
MAP200- 509
Issue 1, September 1983
Sheet 6 of 7




Fig. 509-3 SUPERSET 4 and Packaging

X8001

INSTALL SUPERSET 3/4

MAP200-509

Issue 1, September 1983

Sheet 7 of 7




Fig. 509-4 SUPERSET 4 Assembly

APPENDIX 6

ADDITIONAL EQUIPMENT INSTALLATION

1. GENERAL

A6.01 The MAP's contained in this Appendix are concerned with additional installation requirements which may be required during initial or subsequent installation phases.

A6.02 A list of these additional requirements is shown in Table A6-1.

TABLE A6-1
ADDITIONAL INSTALLATION REQUIREMENTS

Step	Procedure	Reference
1	Shelf 2 Installation (SX-200)	MAP200-601
2	Install New Cards	MAP200-602
3	Reserve Power Supply Installation (SX-200)	MAP200-603
4	Console Interface Board Installation (SX-200)	MAP200-604
5	Backplane Translator Board Installation	MAP200-605
6	Installation of RCP Card	MAP200-606
7	Reserve Power Supply Installation (SX-100)	MAP200-607
8	Printer Installation	MAP200-608
9	Static Wrist Strap Installation	MAP200-609
10	Customer Data Dump/Load	MAP200-610
11	Installation of RAC Card	MAP200-611

SHELF 2 INSTALLATION (SX-200)

MAP200-601

Issue 1, September 1983

Sheet 1 of 6

TOOLS REQUIRED

- 1 Screwdriver 1/4 inch blade
- 1 Screwdriver Phillips

CAUTION

When handling shelf cards or similar modules ensure that a static wrist strap is used.

NOTE


This MAP applies only to SX-200 equipment.

- (1A) Unpack shelf
- (1B) Check backplane for cracks and bent pins
- (1C) Check hardware against packing slip
- (1D) Check fuses (if supplied)

WARNING

If the system has any power to it (48 Vdc reserve or AC power), this power must be removed (Step 3).

- AT REAR OF CABINET
- (3A) Set CONVERTER INPUT switch to OFF
 - (3B) Set BATT switch to OFF
 - (3C) Remove power plug(s) from outlet



SHELF 2 INSTALLATION (SX-200)
MAP200- 601
Issue 1, September 1983
Sheet 2 of 6






Fig. 601-1

SHELF 2 INSTALLATION (SX-200)


MAP200-601

Issue 1, September 1983

Sheet 3 of 6



SHELF 2 INSTALLATION (SX-200)
MAP200- 601
Issue 1, September 1983
Sheet 4 of 6






Fig. 601-2 SX-200 Backplanes

X116R4





Fig. 601-3 P104 Backplane Connections

X5046

INSTALL NEW CARDS
MAP200-602
Issue 1, September 1983
Sheet 1 of 12

CAUTION
When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.


- (1A) Unpack cards from containers
- (1B) Inspect cards for physical damage
- (1C) Check card types and quantities against invoice



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 2 of 12

NOTE
Trunk card switches must be set to proper positions as detailed in Appendix 5 to give correct configuration for trunk circuit.

- (4A) Unlock and open front door of cabinet
(4B) Remove locking bars from shelf




INSTALL NEW CARDS


MAP200-602

Issue 1, September 1983

Sheet 3 of 12



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 4 of 12




INSTALL NEW CARDS


MAP200-602

Issue 1, September 1983

Sheet 5 of 12



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 6 of 12




INSTALL NEW CARDS


MAP200- 602

Issue 1, September 1983

Sheet 7 of 12



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 8 of 12




INSTALL NEW CARDS


MAP200-602

Issue 1, September 1983

Sheet 9 of 12



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 10 of 12




INSTALL NEW CARDS


MAP200-602

Issue 1, September 1983

Sheet 11 of 12



INSTALL NEW CARDS
MAP200- 602
Issue 1, September 1983
Sheet 12 of 12




RESERVE POWER SUPPLY INSTALLATION (SX-200)
MAP200-603
Issue 1, September 1983
Sheet 1 of 10

Note:
This MAP applies only to the installation of MITEL part number 9110-014-003-NA in the SX-200 equipment cabinet.

CAUTION
Check that the BATTERY switch on the reserve battery pack is set to OFF. Check that the three switches on the battery charging unit are set to OFF.

Tools Required
1. Slot Screwdriver




RESERVE POWER SUPPLY
INSTALLATION (SX-200)

MAP200- 603

Issue 1, September 1983

Sheet 2 of 10



NOTE: PLUG IS LINED UP FOR INSERTION INTO RECEPTACLE CORRESPONDING TO 110 V INPUT POWER.

X5578


Fig. 603-1 Voltage Setting Board and Plug

RESERVE POWER SUPPLY INSTALLATION (SX-200)

MAP200-603

Issue 1, September 1983

Sheet 3 of 10





RESERVE POWER SUPPLY INSTALLATION (SX-200)

MAP200- 603

Issue 1, September 1983

Sheet 4 of 10






X5578

Fig. 603-2 Reserve Power Supply

RESERVE POWER SUPPLY INSTALLATION (SX-200)
MAP200- 603
Issue 1, September 1983
Sheet 6 of 10



RESERVE POWER SUPPLY
INSTALLATION (SX-200)

MAP200-603

Issue 1, September 1983

Sheet 7 of 10




Fig. 603-3 Alarm Indicator Connections


X5590

RESERVE POWER SUPPLY
INSTALLATION (SX-200)

MAP200- 603

Issue 1, September 1983

Sheet 8 of 10




RESERVE POWER SUPPLY INSTALLATION (SX-200)


MAP200-603

Issue 1, September 1983

Sheet 9 of 10



RESERVE POWER SUPPLY INSTALLATION (SX-200)
MAP200- 603
Issue 1, September 1983
Sheet 10 of 10




CONSOLE INTERFACE BOARD INSTALLATION (SX-200)
MAP200-604
Issue 1, September 1983
Sheet 1 of 9

TOOLS REQUIRED
1 Wrench 1/2 inch 1 Flat blade screwdriver

NOTE
This MAP applies only to SX-200 equipment.

CAUTION
Check that main power is off. Check that the three switches on the battery charging unit are set to OFF. If there is a reserve battery pack set it to off.

NOTE
Step 2 is required to make room to affix Console card to bracket in Step 7.




CONSOLE INTERFACE BOARD INSTALLATION (SX-200)
--

MAP200- 604

Issue 1, September 1983

Sheet 2 of 9




CONSOLE INTERFACE BOARD
INSTALLATION (SX-200)

MAP200-604

Issue 1, September 1983

Sheet 3 of 9



X876R1


Fig. 604-1 1st Console Interface PCB

CONSOLE INTERFACE BOARD
INSTALLATION (SX-200)

MAP200- 604

Issue 1, September 1983

Sheet 4 of 8



X875R1


Fig. 604-2 2nd Console Interface PCB's

CONSOLE INTERFACE BOARD
INSTALLATION (SX-200)

MAP200-604

Issue 1, September 1983

Sheet 5 of 9



X062R1


Fig. 604-3 Interconnect Wiring

CONSOLE INTERFACE BOARD INSTALLATION (SX-200)
--

MAP200- 604

Issue 1, September 1983

Sheet 6 of 9




CONSOLE INTERFACE BOARD INSTALLATION (SX-200)
--

MAP200-604

Issue 1, September 1983

Sheet 7 of 9



CONSOLE INTERFACE BOARD INSTALLATION (SX-200)
--

MAP200- 604

Issue 1, September 1983

Sheet 8 of 9

TABLE 604-1
INTERCONNECT BLOCK - CONSOLE INTERFACE CARD

Pin No.	Pair Color	Lead Designation
26	W-BL	ELECTROSTATIC GROUND
1	BL-W	ELECTROSTATIC GROUND
27	W-O	ELECTROSTATIC GROUND
2	O-W	ELECTROSTATIC GROUND
28	W-G	ELECTROSTATIC GROUND
3	G-W	ELECTROSTATIC GROUND
29	W-BR	ELECTROSTATIC GROUND
4	BR-W	ELECTROSTATIC GROUND
30	W-S	DATA IN COMMON
5	S-W	DATA IN
31	R-BL	ELECTROSTATIC GROUND
6	BL-R	ELECTROSTATIC GROUND
32	R-O	DATA OUT COMMON
7	O-R	DATA OUT
33	R-G	ELECTROSTATIC GROUND
8	G-R	ELECTROSTATIC GROUND
34	R-BR	ELECTROSTATIC GROUND
9	BR-R	ELECTROSTATIC GROUND
35	R-S	CUTOVER SWB
10	S-R	CUTOVER SWA
36	BK-BL	ELECTROSTATIC GROUND
11	BL-BK	ELECTROSTATIC GROUND
37	BK-O	MAJOR ALARM
12	O-BK	MAJOR ALARM
38	BK-G	TIP
13	G-BK	RING
39	BK-BR	ELECTROSTATIC GROUND
14	BR-BK	ELECTROSTATIC GROUND
40	BK-S	ELECTROSTATIC GROUND
15	S-BK	ELECTROSTATIC GROUND
41	Y-BL	ELECTROSTATIC GROUND
16	BL-Y	ELECTROSTATIC GROUND
42	Y-O	ELECTROSTATIC GROUND
17	O-Y	ELECTROSTATIC GROUND
43	Y-G	0 V
18	G-Y	-48 V
44	Y-BR	0 V
19	BR-Y	-48 V
45	Y-S	0 V
20	S-Y	-48 V
46	V-BL	0 V
21	BL-V	-48 V
47	V-O	0 V
22	O-V	-48 V
48	V-G	0 V
23	G-V	-48 V
49	V-BR	0 V
24	BR-V	-48 V
50	V-S	0 V
25	S-V	-48 V

CONSOLE INTERFACE BOARD
INSTALLATION (SX-200)

MAP200-604

Issue 1, September 1983

Sheet 9 of 9


TABLE 604-2
CONSOLE WIRING

POSITION	LEAD DESIGNATION	P5	P17	J14	P25	J24
16	CONSOLE 2					
	T (A)	35	30	38	38	38
	R (A)	13	13	13	13	13
	S DATA OUT T (A)	39	39	32	32	32
	S DATA OUT R (A)	14	14	7	7	7
	S DATA IN T (A)	40	40	30	30	30
	S DATA IN R (A)	15	15	5	5	5
	MAJOR ALARM TB1-5			12 37	12 37	12 37
	-48 V TB 301			18 19 20	18 19 20	18 19 20
				21 22 23	21 22 23	21 22 23
				24 25	24 25	24 25
	0VTB301-1			43 44 45	43 44 45	43 44 45
				46 47 48	46 47 48	46 47 48
				49 50	49 50	49 50
	CUT OVER SWA			25	25	25
	CUT OVER SWB			10	10	10
	ALL UNLISTED PINS GO TO ESG TB301-2					
		P5	P17	J15	P23	J22
17	CONSOLE 1					
	T (A)	42	42	38	38	38
	R (A)	17	17	13	13	13
	S DATA IN T (A)	10	18	5	5	5
	S DATA IN R (A)	43	43	30	30	30
	S DATA OUT T (A)	19	19	7	7	7
	S DATA OUT R (A)	44	44	32	32	32
	MAJOR ALARM TB1-5			12 37	12 37	12 37
	-48 V TB 301			18 19 20	18 19 20	18 19 20
				21 22 23	21 22 23	21 22 23
				24 25	24 25	24 25
	0VTB 301-1			43 44 45	43 44 45	43 44 45
				46 47 48	46 47 48	46 47 48
				49 50	49 50	49 50
	CUT OVER SWB			25	25	25
	CUT OVER SWA			10	10	10
	ALL UNLISTED PINS GO TO ESG TB301-2					

BACKPLANE TRANSLATOR BOARD INSTALLATION
MAP200-605
Issue 1, September 1983
Sheet 1 of 9

TOOLS REQUIRED
1 Slotted screwdriver 1/4 inch

WARNING: A SUPERSET line card and the equipment numbers associated with the card, may be used only with SUPERSET electronic telephone sets. This should be taken into account when using backplane translators.




BACKPLANE TRANSLATOR BOARD INSTALLATION
--

MAP200- 605

Issue 1, September 1983

Sheet 2 of 9




BACKPLANE TRANSLATOR BOARD INSTALLATION
--


MAP200-605

Issue 1, September 1983

Sheet 3 of 9



BACKPLANE TRANSLATOR BOARD INSTALLATION
MAP200- 605
Issue 1, September 1983
Sheet 4 of 9




BACKPLANE TRANSLATOR BOARD
INSTALLATION

MAP200-605

Issue 1, September 1983

Sheet 5 of 9




BACKPLANE TRANSLATOR BOARD INSTALLATION
--

MAP200- 605

Issue 1, September 1983

Sheet 6 of 9



X10G2R3

Fig. 605-1 Translator Board Installation

BACKPLANE TRANSLATOR BOARD
INSTALLATION

MAP200-605

Issue 1, September 1983

Sheet 7 of 9

TABLE 605-1 BACKPLANE TRANSLATOR BOARD CONNECTIONS (SHELF 1)
TO CROSS-CONNECT FIELD

Pin	Pair Color	Line and Trunk Connections				Shelf 1 Translator Board Plug Numbers							
		Extn	CO	DID/Tie	E&M+	P1	P2	P3	P4				
26	W-BL	T1	T1	T1	T1	001	Equipment Numbers Card Position 1	025	Equipment Numbers Card Position 4	049	Equipment Numbers Card Position 7	073	Equipment Numbers Card Position 10
1	BL-W	R1	R1	R1	R1	002		026		050		074	
27	W-O	T2	XT2		TR1	003		027		051		075	
2	O-W	R2	XT1		RR1	004		028		052		076	
28	W-G	T3	T2		E1	005		029		053		077	
3	G-W	R3	R2		M1	006		030		054		078	
29	W-BR	T4			TR2	007		031		055		079	
4	BR-W	R4			RR2	008		032		056		080	
30	W-S	T5	T3	T2	T2	009	Equipment Numbers Card Position 2	033	Equipment Numbers Card Position 5	057	Equipment Numbers Card Position 8	081	Equipment Numbers Card Position 11
5	S-W	R5	R3	R2	R2	010		034		058		082	
31	R-BL	T6	XT4		TR2	011		035		059		083	
6	BL-R	R6	XT3		RR2	012		036		060		084	
32	R-O	T7	T4		E2	013		037		061		085	
7	O-R	R7	R4		M2	014		038		062		086	
33	R-G	T8			TR2	015		039		063		087	
8	G-R	R8			RR2	016		040		064		088	
34	R-BR	T1	T1	T1	T1	017	Equipment Numbers Card Position 3	041	Equipment Numbers Card Position 6	065	Equipment Numbers Card Position 9	089	Equipment Numbers Card Position 12 (See Note)
9	BR-R	R1	R1	R1	R1	018		042		066		090	
35	R-S	T2	XT2		TR1	019		043		067		091	
10	S-R	R2	XT1		RR1	020		044		068		092	
36	BK-BL	T3	T2		E1	021		045		069		093	
11	BL-BK	R3	R2		M1	022		046		070		094	
37	BK-O	T4			TR2	023		047		071		095	
12	O-BK	R4			RR2	024		048		072		096	
38	BK-G	T5	T3	T2	T2								
13	G-BK	R5	R3	R2	R2								
39	BK-BR	T6	XT4		TR2								
14	BR-BK	R6	XT3		RR2								
40	BK-S	T7	T4		E2								
15	S-BK	R7	R4		M2								
41	Y-BL	T8			TR2								
16	BL-Y	R8			RR2								
42	Y-O	T1	T1	T1	T1								
17	O-Y	R1	R1	R1	R1								
43	Y-G	T2	XT2		TR1								
18	G-Y	R2	XT1		RR1								
44	Y-BR	T3	T2		E1								
19	BR-Y	R3	R2		M1								
45	Y-S	T4											
20	S-Y	R4											
46	V-BL	T5	T3	T2	T2								
21	BL-V	R5	R3	R2	R2								
47	V-O	T6	XT4		TR2								
22	O-V	R6	XT3		RR2								
48	V-G	T7	T4		E2								
23	G-V	R7	R4		M2								
49	V-BR	T8											
24	BR-V	R8											
50	V-S	SPARE											
25	S-V	SPARE											

NOTE: Position 12 can be used for lines, trunks or receiver #4 card.
- For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads.

SECTION MITL9105/9110-090-200-NA

BACKPLANE TRANSLATOR BOARD INSTALLATION
MAP200- 605
Issue 1, September 1983
Sheet 8 of 9

**TABLE 605-2 BACKPLANE TRANSLATOR BOARD CONNECTIONS (SHELF 2)
TO CROSS-CONNECT FIELD**

Pin	Pair Color	Line and Trunk Connections				Shelf 2 Translator Board Plug Numbers							
		Extn	CO	DID/Tie	E&M+	P7	P8	P9	P10				
26	W-BL	T1	T1	T1	T1	181	185	209	233				
1	BL-W	R1	R1	R1	R1	Equipment Numbers Card Position 1	Equipment Numbers Card Position 4	Equipment Numbers Card Position 7	Equipment Numbers Card Position 10				
27	W-O	T2	XT2		TR1					182	186	210	234
2	O-W	R2	XT1		RR1					183	187	211	235
28	W-G	T3	T2		E1					184	188	212	236
3	G-W	R3	R2		M1					185	189	213	237
29	W-BR	T4	T3	T2	T2					186	190	214	238
4	BR-W	R4	XT3		RR2					187	191	215	239
30	W-S	T5	R3	R2	R2					188	192	216	240
5	S-W	R5	R3	R2	R2	Equipment Numbers Card Position 2	Equipment Numbers Card Position 5	Equipment Numbers Card Position 8	Equipment Numbers Card Position 11				
31	R-BL	T6	XT4		TR2					189	193	217	241
6	BL-R	R6	XT3		RR2					190	194	218	242
32	R-O	T7	T4		E2					191	195	219	243
7	O-R	R7	R4		M2					192	196	220	244
33	R-G	T8	T3	T2	T2					193	197	221	245
8	G-R	R8	XT3		RR2					194	198	222	246
34	R-BR	T1	T1	T1	T1					195	199	223	247
9	BR-R	R1	R1	R1	R1	196	200	224	248				
35	R-S	T2	XT2		TR1	Equipment Numbers Card Position 3	Equipment Numbers Card Position 6	Equipment Numbers Card Position 9	Equipment Numbers Card Position 12 (See Note)				
10	S-R	R2	XT1		RR1					197	201	225	249
36	BK-BL	T3	T2		E1					198	202	226	250
11	BL-BK	R3	R2		M1					199	203	227	251
37	BK-O	T4	T3	T2	T2					200	204	228	252
12	O-BK	R4	XT3		RR2					201	205	229	253
38	BK-G	T5	R3	R2	R2					202	206	230	254
13	G-BK	R5	R3	R2	R2					203	207	231	255
39	BK-BR	T6	XT4		TR2	204	208	232	256				
14	BR-BK	R6	XT3		RR2	205	209	233	257				
40	BK-S	T7	T4		E2	206	210	234	258				
15	S-BK	R7	R4		M2	207	211	235	259				
41	Y-BL	T8	T3	T2	T2	208	212	236	260				
16	BL-Y	R8	XT3		RR2	209	213	237	261				
42	Y-O	T1	T1	T1	T1	210	214	238	262				
17	O-Y	R1	R1	R1	R1	211	215	239	263				
43	Y-G	T2	XT2		TR1	212	216	240	264				
18	G-Y	R2	XT1		RR1	213	217	241	265				
44	Y-BR	T3	T2		E1	214	218	242	266				
19	BR-Y	R3	R2		M1	215	219	243	267				
45	Y-S	T4	T3	T2	T2	216	220	244	268				
20	S-Y	R4	XT3		RR2	217	221	245	269				
46	V-BL	T5	R3	R2	R2	218	222	246	270				
21	BL-V	R5	R3	R2	R2	219	223	247	271				
47	V-O	T6	XT4		TR2	220	224	248	272				
22	O-V	R6	XT3		RR2	221	225	249	273				
48	V-G	T7	T4		E2	222	226	250	274				
23	G-V	R7	R4		M2	223	227	251	275				
49	V-BR	T8	T3	T2	T2	224	228	252	276				
24	BR-V	R8	XT3		RR2	225	229	253	277				
50	V-S	SPARE											
25	S-V	SPARE											

NOTE: Position 12 can be used for lines, trunks or receiver #4 card.
 * For 2-Wire E&M Trunk operation DO NOT connect RR and TR leads.

HARDWARE/EQUIPMENT NUMBERING

HARDWARE POSITION NUMBER	PLUG 7			PLUG 8			PLUG 9			PLUG 10		
	161	169	177	185	193	201	209	217	225	233	241	249
	162	170	178	186	194	202	210	218	226	234	242	250
	163	171	179	187	195	203	211	219	227	235	243	251
	164	172	180	188	196	204	212	220	228	236	244	252
	165	173	181	189	197	205	213	221	229	237	245	253
	166	174	182	190	198	206	214	222	230	238	246	254
	167	175	183	191	199	207	215	223	231	239	247	255
	168	176	184	192	200	208	216	224	232	240	248	256
	1	2	3	4	5	6	7	8	9	10	11	12

SHELF 2 (SX-200)

HARDWARE POSITION NUMBER	PLUG P1			PLUG P2			PLUG P3			PLUG P4		
	001	009	017	025	033	041	049	057	065	073	081	089
	002	010	018	026	034	042	050	058	066	074	082	090
	003	011	019	027	035	043	051	059	067	075	083	091
	004	012	020	028	036	044	052	060	068	076	084	092
	005	013	021	029	037	045	053	061	069	077	085	093
	006	014	022	030	038	046	054	062	070	078	086	094
	007	015	023	031	039	047	055	063	071	079	087	095
	008	016	024	032	040	048	056	064	072	080	088	096
	1	2	3	4	5	6	7	8	9	10	11	12

SHELF 1 SX-100/SX-200


NOTE: EQUIPMENT POSITION 001 IS RESERVED FOR THE TEST LINE AND MUST THEREFORE BE EQUIPPED WITH A LINE CARD. TRUNK EQUIPMENT NUMBER IS SAME AS INDIVIDUAL TRUNK ACCESS CODE.
EQUIPMENT NUMBERS ASSIGNED TO SUPERSET 4
LINE CARDS CAN ONLY BE USED WITH SUPERSET 4
ELECTRONIC TELEPHONE SETS.

X1318


Fig. 605-2 Backplane Translator Board Plug Appearances

INSTALLATION OF RCP CARD
MAP200-606
Issue 1, September 1983
Sheet 1 of 5

NOTE
The RCP card provides a remote access facility. See Section MITL9105/9110-098-101-NA Remote Maintenance, Administration and Test Description for details.



INSTALLATION OF RCP CARD
MAP200- 606
Issue 1, September 1983
Sheet 2 of 5



INSTALLATION OF RCP CARD


MAP200-606

Issue 1, September 1983


Sheet 3 of 5

NOTE

Switch settings Step (10A) must remain at 7772 to allow RMAP center to enter programming mode.



INSTALLATION OF RCP CARD
MAP200- 606
Issue 1, September 1983
Sheet 4 of 5



NOTE
 If AL2 LED is lit at Step (11D) replace the RCP card.

INSTALLATION OF RCP CARD

MAP200-606

Issue 1, September 1983

Sheet 5 of 5

TABLE 606-1
RCP LED INDICATIONS


DESIGNATION	DESCRIPTION OF INDICATIONS
DATA	<ol style="list-style-type: none"> 1. LED lit when the RCP is connected to the RMAT Controller and data is being transmitted. 2. LED lit during diagnostic tests. Tests consist of three 10 second periods followed by 17 seconds during which LED is off.
TERM	LED is lit when the RCP answers the RMAT Controller
AL1	Alarm LED AL1 is lit when alarm is activated by the watchdog timer
AL2	Alarm LED flashes if failure occurs during the RCP self-test diagnostics. The LED is lit steadily if a checksum or RAM failure occurs during initialization.

RESERVE POWER SUPPLY INSTALLATION (SX-100)
MAP200-607
Issue 1, September 1983
Sheet 1 of 12


NOTE
This MAP applies only to SX-100 equipment.

CAUTION
Check that the BATTERY switch on the reserve battery pack is set to OFF. Check that the three switches on the battery charging unit are set to OFF.

- (1A) Unpack reserve power supply equipment
- (1B) Inspect items for physical damage
- (1C) Check item types against invoice



RESERVE POWER SUPPLY INSTALLATION (SX-100)
MAP200- 607
Issue 1, September 1983
Sheet 2 of 12




RESERVE POWER SUPPLY INSTALLATION (SX-100)

MAP200-607

Issue 1, September 1983

Sheet 3 of 12



X952R3

Fig. 607-1 Cable Connections

RESERVE POWER SUPPLY INSTALLATION (SX-100)
MAP200- 607
Issue 1, September 1983
Sheet 4 of 12




Fig. 607-2 Cable Harness Interconnections

RESERVE POWER SUPPLY
INSTALLATION (SX-100)


MAP200-607

Issue 1, September 1983

Sheet 5 of 12

NOTE

The Reserve Power Supply should be installed in a location which affords protection against mechanical or environmental damage and which requires an interconnecting cable run of no more than 50 feet.




RESERVE POWER SUPPLY
INSTALLATION (SX-100)

MAP200-607

Issue 1, September 1983

Sheet 6 of 12



RESERVE POWER SUPPLY
INSTALLATION (SX-100)

MAP200-607


Issue 1, September 1983

Sheet 7 of 12


NOTES

1. The SX-100, when used with the Reserve Power Supply is mounted on top of the Reserve Power Supply (Fig. 607-3). If sufficient slack in cables exist to permit new configuration proceed as in Step 13. If a new location is selected or the SX-100 otherwise requires new connectorized cables proceed as in Step 14.

2. Refer to all instructions in MAP200-305 regarding marking, identification and cable locations for review and reference prior to proceeding with Step 14.



RESERVE POWER SUPPLY INSTALLATION (SX-100)
MAP200- 607
Issue 1, September 1983
Sheet 8 of 12



X1472R1


Fig. 607-3 Combined SX-100/Reserve Power Supply Grouping

RESERVE POWER SUPPLY
INSTALLATION (SX-100)

MAP200-607

Issue 1, September 1983

Sheet 9 of 12




RESERVE POWER SUPPLY
INSTALLATION (SX-100)

MAP200- 607

Issue 1, September 1983

Sheet 10 of 12



NOTE

Alarm contacts are provided by the charging unit. These are available for customer-provided alarm indicating equipments to indicate power-fail conditions. Fig. 607-2 shows the normal operational condition; i.e. a power-fail condition causes the normally open (NO) and common (COM) contacts to close. The alarm contact electrical ratings are as follows:

Resistive Load
2A, 28 Vdc
1A, 40 Vdc

RESERVE POWER SUPPLY INSTALLATION (SX-100)


MAP200-607

Issue 1, September 1983


Sheet 11 of 12

NOTE

Ensure SX-100 circuit breakers are off (Step (4A)) prior to Step (29A).
--




RESERVE POWER SUPPLY INSTALLATION (SX-100)
MAP200- 607
Issue 1, September 1983
Sheet 12 of 12



PRINTER INSTALLATION
MAP200- 608
Issue 1, September 1983
Sheet 1 of 7

NOTE
 Do not run cables close to:
 AM/FM transmission lines,
 large AC/DC transmission lines,
 close to any electrical equipment or in
 hallways.




PRINTER INSTALLATION

MAP200- 608

Issue 1, September 1983

Sheet 2 of 7




PRINTER INSTALLATION


MAP200-608

Issue 1, September 1983

Sheet 3 of 7



PRINTER INSTALLATION
MAP200- 608
Issue 1, September 1983
Sheet 4 of 7



X5435


Fig. 608-1(a) SX-100 Rear View

PRINTER INSTALLATION

MAP200-608

Issue 1, September 1983

Sheet 5 of 7



X952R3

Fig. 608-1(b) SX-100 Top View

PRINTER INSTALLATION
MAP200- 608
Issue 1, September 1983
Sheet 6 of 7




Fig. 608-2(a) SX-200 Rear View

X611R1

PRINTER INSTALLATION
MAP200-608
Issue 1, September 1983
Sheet 7 of 7





Fig. 608-2(b) SX-200 Interconnect Board

STATIC WRIST STRAP INSTALLATION
MAP200-609
Issue 1, September 1983
Sheet 1 of 2



STATIC WRIST STRAP INSTALLATION
MAP200- 609
Issue 1, September 1983
Sheet 2 of 2





Fig. 609-1 Wrist Strap Installation

CUSTOMER DATA DUMP/LOAD


MAP200-610

Issue 1, September 1983

Sheet 1 of 6



CUSTOMER DATA DUMP/LOAD
MAP200- 610
Issue 1, September 1983
Sheet 2 of 6




CUSTOMER DATA DUMP/LOAD


MAP200-610

Issue 1, September 1983

Sheet 3 of 6



CUSTOMER DATA DUMP/LOAD
MAP200- 610
Issue 1, September 1983
Sheet 4 of 6




- [12A] Open front door and set the thumbwheel switches on the Tone Control Card to 4648
- [12B] Press the Auto Load button on the IPC - system will reset, LED 3 on the IPC card will be lit for the duration of the dump (see also Table 610-1).

CUSTOMER DATA DUMP/LOAD

MAP200-610

Issue 1, September 1983

Sheet 5 of 6



**TABLE 610-2
CUSTOMER DATA BLOCKS**

Data Block Number	Customer Data Block Information
1	All Standard Programming and Superset Customer Data
3	ARS
5	Station Information (extension meters, room status, etc.)
6	Alarm Call
7	System Speed Call
8	Superset Speed Call


**TABLE 610-1
LOAD ERRORS**

Display	Meaning
A#	Number of records written inconsistent with the number on the tape.
B#	Checksum line does not verify.
C#	Checksum line does not verify. If the display is CO, it is a label error. If the error is a C + a number, it is a Data Block error.
D#	Data Block found but not on label.
EO	Data block requested not on tape.
FO	Load attempted but no Data Block numbers entered.


INSTALLATION OF RAC CARD
MAP200-611
Issue 1, September 1983
Sheet 1 of 4

CAUTION
When handling shelf cards or similar modules ensure that the procedures noted in paragraph 12.02 are followed.


- [1A] Unpack cards from containers
- [1B] Inspect cards for physical damage
- [1C] Check card types and quantities against invoice



INSTALLATION OF RAC CARD
MAP200- 611
Issue 1, September 1983
Sheet 2 of 4



INSTALLATION OF RAC CARD
MAP200-611
Issue 1, September 1983
Sheet 3 of 4



INSTALLATION OF RAC CARD
MAP200- 611
Issue 1, September 1983
Sheet 4 of 4




Fig. 611-1 Recorded Announcement Card

**SX-100®/SX-200®
SUPERSWITCH®
AUTOMATIC CALL DISTRIBUTION SYSTEM
SYSTEM PROGRAMMING
GENERIC ACD**

CONTENTS

PAGE

1. GENERAL	1
Introduction	1
Reason for Issue	1
Purpose	2
2. PROGRAM DESCRIPTION	2
General	2
System Options	3
Class-of-Service Options	3
Feature Access Codes	17
Extensions	18
Hunt Groups	28
Trunks	29
Trunk Groups	31
3. PROGRAMMING	32
General	32
Error/Confirm Codes	32
Supervisor Function Access Codes	33
Maintenance Function Access Codes	33
Supervisor Function Codes	33
Time-Out Information	33
APPENDIX 1 MITEL ACTION PROCEDURES	A1-1
APPENDIX 2 SYSTEM PROGRAMMING PROCEDURES	A2-1/2
System Programming (MAP210-201)	A2-7
Select Programming Mode (MAP210-202)	A2-11
Program System Options (MAP210-203)	A2-15
Program COS Options (MAP210-204)	A2-23
Assign Feature Access Codes (MAP210-205)	A2-31
Program Extensions (MAP210-206)	A2-37
Program Extension Hunt Groups (MAP210-207)	A2-49
Program Non-Dial-In Trunks (MAP210-208)	A2-59
Program Dial-In Trunks (MAP210-209)	A2-71
Program DID Trunks (MAP210-210)	A2-83
Program Trunk Groups (MAP210-211)	A2-93

Copyright of MITEL Corporation 1983

SX-100, SX-200, SUPERSWITCH and
SUPERSET 4 are Trademarks of MITEL Corporation

CONTENTS	PAGE
Range Programming for Extensions (MAP210-212)	A2-105
Terminating Standard Programming Mode (MAP210-213)	A2-111
Selection of Extended Programming (MAP210-221)	A2-115
Absorb Plan (MAP210-222)	A2-117
Control Plan (MAP210-223)	A2-123
Trunk Group Class of Restriction (MAP210-224)	A2-131
Restriction Tables (MAP210-225)	A2-137
Add an Entry (MAP210-226)	A2-145
Displaying Sequential Entries (MAP210-227)	A2-147/148
Search for an Entry (MAP210-228)	A2-149
Delete an Entry (MAP210-229)	A2-151
Programming Personal Tables (MAP210-242)	A2-153
Convert Table from Personal to Common-Use (MAP210-243)	A2-165
Code Table Quantity Selection or Change (MAP210-250)	A2-169
Area Code Table Programming (MAP210-251)	A2-171
Review Area Code Table Programming (MAP210-252)	A2-175
Delete an Area Code Table (MAP210-253)	A2-177
Area Code/Office Code Programming (MAP210-254)	A2-183
Review or Delete Part or All Area Code/Office Code (MAP210-255)	A2-187
Program Modify Digits (MAP210-256)	A2-191
To Review or Delete Modify Digit Tables (MAP210-257)	A2-195
Route Table Programming (MAP210-258)	A2-199
To Review or Delete a Route Table (MAP210-259)	A2-205
Review or Delete Routes (MAP210-260)	A2-209
Program a Prime Key (MAP210-270)	A2-213
Program a Non-Prime Key (MAP210-271)	A2-223
Delete a Non-Prime Key (MAP210-272)	A2-229
Delete a Prime Key (MAP210-273)	A2-233
Changing Any Key (MAP210-274)	A2-237
Moving a SUPERSET 4 (MAP210-275)	A2-243
Review SUPERSET Programming (MAP210-276)	A2-247
Terminating Programming (MAP210-284)	A2-253/254

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
2-1	Equipment Number	27
2-2A	Busy Lamp Position Numbering	28
A1-1	Typical MAP Page	A1-2
A2-1	Standard Programming Overlay	A2-1
A2-2	Extended Programming Overlay	A2-5
A2-3	ARS Overlay	A2-5
A2-4	SUPERSET Overlay	A2-6

LIST OF TABLES

TABLE	TITLE	PAGE
2-1	System Options	4
2-2	System Option Conflicts	17
2-3	Class-of-Service Options	20
2-4	Feature Assignments	26
2-5	Trunk Group Type Codes	34
3-1	Programming Error Codes	35
3-2	Standard Confirm Codes	38
3-3	Extended Programming Error Codes - Toll Control	39
3-4	Extended Programming Error Codes - Speed Call	40
3-5	Extended Programming Error Codes - Automatic Route Selection	41
3-6	Extended Programming Error Codes - SUPERSET Programming	42
3-7	Supervisor Function Access Codes	46
3-8	Maintenance Function Access Codes	49
3-9	Supervisor Function Codes	50
3-10	System Time-Out Information	53
A2-1	Standard Programming	A2-1
A2-2	Multi-Digit Toll Control	A2-2
A2-3	Speed Call	A2-2
A2-4	Automatic Route Selection	A2-2
A2-5	SUPERSET Programming	A2-3
A2-6	Button Descriptions	A2-3
A2-7	Programming Overlays	A2-4

1. GENERAL

Introduction

1.01 The SX-100/SX-200 are processor-controlled Automatic Call Distribution (ACD) systems. In order to process calls, the central processor needs to know certain information about the calling and called equipment. This information is described by blocks of data held in the system memories. A number of service change programs are provided to allow additions, deletions and changes to be made to the equipment configuration. The seven service change programs provided are:

- **System Options.** Describes the options which may be enabled on a system basis.
- **Class-of-Service Options.** Each class of service specifies the features which may be used by stations assigned that Class of Service (COS). A maximum of 16 different classes of service may be specified for each system.
- **Feature Access Codes.** A number of features within the system are accessed by dialing a special access code. This program allows the access codes for the features to be defined.
- **Extensions.** This program allows the equipment number, extension number, Class of Service (features allowed), toll access, Busy Lamp Field assignment and Pickup Group assignment, for each extension to be made.
- **Hunt Groups.** This program allows the extensions within each Hunt Group to be specified, together with the Hunt Group master number (access code).
- **Trunks.** This program allows each trunk to be described in terms of the equipment number, trunk type, listed directory number, day and night numbers, busy lamp number, COS and toll access.
- **Trunk Group.** This program allows the trunks within each group to be specified, together with trunk group type, access code and overflow group.

Reason for Issue

1.02 This Section is issued to provide the ACD programming information for SX-100/SX-200 ACD Systems.

1.03 Other additional service programs, dependent upon the type of software Generic installed in the system, may be implemented. These are listed below and include relevant MITEL Practice references, which should be consulted for descriptions and programming requirements.

- (a) Traffic Measurement: see Section MITL9105/9110-090-450-NA.
- (b) Multi-Digit Toll Control: see Section MITL9105/9110-090-212-NA.
- (c) Station Message Detail Recording: see Section MITL9105/9110-090-451-NA.
- (d) Speed Call: see Section MITL9105/9110-090-220-NA.
- (e) Automatic Route Selection: see Section MITL9105/9110-090-213-NA.
- (f) Automatic Call Distribution: see Section MITL9105/9110-090-222-NA.

Purpose

1.04 This Section consists of three parts, each part explaining a different facet of the system programming.

Part 1 General - general description of system programming contents and purpose of the programming manual.

Part 2 Program Description - a description of each program and definition of each entry and possible response.

Part 3 Programming - a general introduction to the system programming and MITEL Action Procedures (MAPs), which detail how to use each program. When entering data, the system checks each entry to ensure that the codes entered are correct, and if an error is detected, it sounds the console ringer and displays the required error code. These codes and their meaning are defined in this Part.

2. PROGRAM DESCRIPTION

General

2.01 Because the system is controlled by a processor, data describing each extension, trunk, feature etc. must be entered into the system. This is done by pressing keys and dialing codes. The codes dialed are held in the system memories and used by the system during call processing. Seven basic programs are provided which allow data to be entered into the system as equipment is added, or existing data to be changed or removed as the system configuration changes. The following paragraphs describe the seven programs (see 1.01). These programs specify the keys to be pressed and explain the entries that may be made. The Appendices to this Section contain an introduction to MITEL Action Procedures (MAPs) and the actual MAPs which detail each step in system programming. A complete description of each feature and option is given in Section MITL9105/9110-090-105-NA, Features and Services Description. Other types of programs are referenced in 1.03.

System Options

2.03 The system options are selected by the console keys, as described below:

- **OPTION.** This key selects the option program which allows the system to set-up or change the active option list. The code entered (Table 2-1) after selecting the option program, defines the option to be added or removed from the active option list; see Table 2-2 for possible option conflicts.
- **ADD.** When pressed, this key adds the option code to the active system option list, making the option available for use by the system.
- **DELETE.** Pressing the DELETE Key, after dialing an option code, removes the code from the active option list inhibiting further use of that option.
- **CANCEL.** As entries are made during the option program, they are stored in a temporary memory. If after making a number of entries, an error is discovered, all new entries may be removed by pressing the CANCEL Key.
- **ENTER.** After all entries have been made to the system option, they may be moved from the temporary storage to permanent storage by pressing the ENTER Key. Additional changes may be made by reentering the option program.

Class-of-Service Options

2.04 Each system may contain up to 16 different Classes of Service (COS). The COS defines which of the available options (Table 2-3) are active, and therefore available for use by any extensions assigned that COS.

2.05 The individual Classes of Service (COS) are selected by the console keys, as described below:

- **COS DEFINE.** This key selects the Class-of-Service program which permits changes to be made to any of the 16 individual COS. The entry made after selecting the program identifies which COS is to be modified.
- **OPTION.** The code entered (Table 2-3), after pressing the OPTION key, defines the extension option which is to be added or removed from the COS specified.
- **ADD.** Add the option to this COS.
- **DELETE.** Remove the option from the COS.

TABLE 2-1
SYSTEM OPTIONS

n1

Option Number	Option	Description
100	BELL OFF Enable	Enables the BELL OFF button. If this option is not selected, the "BELL OFF" button is ineffective; i.e., the console ringer cannot be turned off.
101	BOTH Button Enable	Enables the "BOTH" button. If this feature is not selected, the supervisor will be able to split between source and destination, but will not be able to speak to both source and destination at the same time.
102	Both Mode Standard	Causes the supervisor to be normally connected to both the Source and Destination of calls through the console. Manual splitting can be achieved using the SOURCE and DEST buttons. If this option is not selected, the console will operate in an automatic split mode; i.e., the supervisor will always be split toward the source upon answering calls, and will be split toward the destination as soon as the destination number is dialed. Manual splitting can still be achieved using the SOURCE and DEST buttons.
103	Supervisor Busy Override	Allows supervisor override.
104	CALLBACK Button Enable	Enables the "CALLBACK" button; i.e., gives the supervisor access to the callback feature.
105	Controlled Station-to-Station Restriction Setup	Enables the CALL BLOCK button; i.e., allows the supervisor to inhibit calls between stations with "H/M Station-Station Restrict Applies" feature in their Class of Service. If this feature is selected, supervisor HOLD 4 button is unavailable.
106	SUPERSET 4™ Sub-Supervisor	This option, when enabled, allows the SUPERSET 4 to be a Sub-Supervisor position. All calls handled by the SUPERSET will recall to the SUPERSET.
106	Supervisor Camp-On	Allows supervisor camp-on. If this option is not selected, pressing the RELEASE button when attempting to connect a call to a busy station, will release the call. See "Supervisor-Timed Recall Camp-On" options.
107	Supervisor CO Trunk - CO Trunk Connect Enable	Allows the supervisor to make CO trunk to CO trunk connections via the console.
108	Supervisor CO Trunk - Non-CO Trunk Connect Enable	Allows the supervisor to make CO trunk to non-CO trunk connections via the console.
109	Supervisor Non-CO Trunk - Non-CO Trunk	Allows the supervisor to connect non-CO trunks together via the console.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
110	Supervisor Conference	Allows supervisor conference.
111	Supervisor DISA Code Setup Enable	Allows the supervisor to change the Direct Inward Systems Access (DISA) security code from the console.
112	Do Not Disturb and Message Waiting Display	Enable the supervisor to display which extensions have Do Not Disturb active and extensions that have a message waiting active.
113	GUEST ROOM Button Enable	Allows use of the GUEST ROOM button which allows the supervisor to display and change the feature in use by a hotel room.
115	Lockout Alarm Enable	Causes a minor alarm when an extension is locked out.
116	New Call Tone Enable	Causes the first incoming call to signal the supervisor with a single tone ringer burst, if the supervisor is already busy on another call. If the option is not selected, incoming calls which arrive while the supervisor is handling another call, will not provide any audible signal, until the supervisor releases from that call.
117	PAGE Button Enable	Allows the supervisor access to the paging equipment by pressing the PAGE button.
118	Supervisor Printer Control Enable	This option allows the supervisor to control the printer from the console.
119	ROOM STATUS Button Enable	Allows the supervisor to display and change status of a hotel room.
120	Supervisor Serial Call	Allows supervisor serial call. If this option is selected, hotel/motel guest room capability is unavailable unless the FLASH button is programmed as the SERIAL CALL button (System Option 121).
121	Serial Call Override Flash Button	This option allows both the Guest Room feature and the Serial Call feature to be used in the same system. This is done by enabling the FLASH button as the SERIAL CALL button.
122	Supervisor Station Busy-Out Enable	Enables the supervisor to make an extension inoperative and to also remove the busy-out condition.
123	Supervisor-Timed Recall Camp-On 20 seconds	Causes Supervisor-Timed Recall Camp-On after 20 seconds.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
124	Supervisor-Timed Recall Camp-On 40 seconds	Causes Supervisor-Timed Recall Camp-On after 40 seconds. If neither of these two options is selected, the Supervisor Camp-On Recall time-out will be 30 seconds. These time-outs are only effective if the "Supervisor Camp-On" feature has been selected.
125	Supervisor-Timed Recall - Don't Answer 10 s	This option, when set, recalls supervisor-handled calls (to the supervisor that are not answered within 10 s) to the Supervisor Console.
126	Supervisor-Timed Recall Don't Answer - 20 seconds	Causes Supervisor-Timed Recall Don't Answer after 20 seconds.
127	Supervisor-Timed Recall Don't Answer - 40 seconds	Causes Supervisor-Timed Recall Don't Answer after 40 seconds. If neither of these two options is selected, Supervisor Timed Recall Don't Answer will be 30 seconds.
128	Supervisor-Timed Recall Hold, 20 seconds	Causes Recall Hold after 20 seconds.
129	Supervisor-Timed Recall Hold, 40 seconds	Causes Recall Hold after 40 seconds. If neither of these two options is selected, Supervisor Recall Hold time will be 30 seconds.
130	Trunk Busy-out Enable	Allows the supervisor to "busy-out" and "debusy" individual trunks. If this option is not selected, the supervisor will still be able to access individual trunks, but will not be able to busy them out or remove a busy-out condition.
131	MONITOR Override FLASH Key	If this option is enabled the FLASH will become the MONITOR Key.
133	DID, CCSA to Non-CO Trunks via Supervisor Inhibit	Prevents DID trunks from being connected to Non-CO trunks via the supervisor.
134	End of Dial Signal for Outgoing Trunks (#)	Enables the use of the octothorp (#) button to signal end of dialing to the system on outgoing trunk calls from the supervisor console or extension.
135	DID/Dial-In/CCSA Vacant/Illegal Intercept to Supervisor	This option causes calls on DID/Dial-In and CCSA trunk calls that attempt access to a vacant or not-allowed number, to intercept to the supervisor.
136	Illegal Access Intercept to Supervisor	Causes all calls, other than DID or Dial-In Tie Trunk calls to unauthorized access codes, to be routed to the supervisor for intercept. If this option is not selected, such calls will receive reorder tone.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
137	Vacant Number Intercept to Supervisor	Causes all calls, other than DID or Dial-In Tie Trunk calls to vacant levels and numbers, to be routed to the supervisor for intercept. If this option is not selected, such calls will receive reorder tone.
138	Do Not Disturb Intercept to the Supervisor	Causes calls directed to extensions with Do Not Disturb active to be routed to the supervisor.
150	24-Hour Clock	Enables the console digital clock to display 24-hour time. If this option is not selected, the clock will display 12-hour time.
151	Data Demultiplexer Enable	This option allows the RS232 information to be output to four different recording devices through a Data Demultiplexer see Section MITL9160-080-300-NA.
152	DID Intercept to the Supervisor	This option, when set, allows vacant or illegal DID calls to be intercepted to the supervisor.
153	Digit Translation Plan 1	If this option is selected the digit: 1 produces 2 pulses, 2 produces 3 pulses, 3 produces 4 pulses, 4 produces 5 pulses, 5 produces 6 pulses, 6 produces 7 pulses, 7 produces 8 pulses, 8 produces 9 pulses, 9 produces 10 pulses, 0 produces 1 pulse.
154	Digit Translation Plan 2	If this option is selected the digit: 1 produces 9 pulses, 2 produces 8 pulses, 3 produces 7 pulses, 4 produces 6 pulses, 5 produces 5 pulses, 6 produces 4 pulses, 7 produces 3 pulses, 8 produces 2 pulses, 9 produces 1 pulse, 0 produces 1 pulse.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
155	Digit Translation Plan 3	If this option is selected the digit: 1 produces 10 pulses, 2 produces 9 pulses, 3 produces 8 pulses, 4 produces 7 pulses, 5 produces 6 pulses, 6 produces 5 pulses, 7 produces 4 pulses, 8 produces 3 pulses, 9 produces 2 pulses, 0 produces 1 pulse.
156	Flexible Night Service	Enables flexible night service.
157	Identified Trunk Group Enable	This option allows trunks to be programmed as identified trunks.
158	Incoming to Outgoing Call Forwarding Enable	This option allows incoming calls to be forwarded (by speed call) to an external number.
159	Inhibit Automatic Supervision	This option allows an incoming tie to dial a CO trunk through the system. This allows any supervisions from the CO to be passed on to the tie trunk.
160	Limited Wait for Dial Tone	Limits the "Wait for Dial Tone" Trunk Group option to wait a maximum of 5 seconds and then, cut through even if no dial tone is detected. If this option is not selected, there is no time limit on the "Wait for Dial Tone" Trunk Group option.
161	Music on Hold Disable	If Music on Hold is not provided, this option should be selected.
162	Night Bell 3 with Minor Alarm Enable	This option allows Night Bell 3 to be rung in the event of a minor system alarm.
163	Night Service Automatic Switching	Enables night service automatic switching.
164	Night Service Time-Out 20 seconds	Sets night service automatic switching at 20 seconds.
165	Night Service Time-Out 40 seconds	Sets night service automatic switching time-out at 40 seconds. If neither of these two options is selected, the night service automatic switching time-out will be 30 seconds. These time-outs are only effective if the night service automatic switching option has been selected.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
166	Remote System Reset - Protection Override	This option allows the system to be reset from the test line on the console, without setting the thumbwheel switches on the Tone Control card to 777n.
167	Final Ring Time-Out: 1 minute	If this option is selected, the ringing time-out will be reduced to 1 minute (from 5 minutes).
168	System ID Enable	This option allows the System ID to be printed with all Traffic Measurements, Data Dumps and SMDR reports.
169	Station Transfer Security Partial Inhibit	Sets the minimum switchhook flash time as 250 ms.
171	Digits Store and Forward	This option when enabled causes the system to store all digits dialed before seizing a trunk and outpulsing.
172	Receiver Time-Out 15 seconds	This option changes the receiver time-out on trunk calls to 15 seconds.
180	Can Flash if Talking to Station	Allows extensions to switchhook flash on extension calls.
181	Can Flash if Talking to an Incoming Trunk	Allows extensions to switchhook flash on incoming trunk calls.
182	Can Flash if Talking to an Outgoing Trunk	Allows extensions to switchhook flash on outgoing trunk calls.
183	Cannot Dial a Trunk After Flashing	Inhibits dialing a trunk after flashing. This option does not apply to dialing a trunk for broker's call.
184	Cannot Dial a Trunk After Flashing if Holding or in Conference with a Trunk	Inhibits dialing a trunk after flashing, only if the existing call has a trunk party. This option does not apply to broker's call.
185	Discriminating Dial Tone	An extension having Do Not Disturb or Call Forwarding Follow Me in effect, will receive a distinct dial tone.
186	Discriminating Ringing	Enables discriminating ringing for trunk and supervisor-handled calls.
187	Controlled Station Restriction Setup	Enables the (DO NOT DISTB) button; i.e., allows the supervisor to use the controlled station restriction feature.
188	Extension Non-Co Trunk to Trunk Connect Enable	This option allows an extension to connect a non-CO trunk to a CO trunk, then go on-hook and leave the two trunks connected.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
189	Flash Timer - 0.7 second	Sets the switchhook flash recognition time to lie between 190 ms and 700 ms.
190	Flash Timer - 0.9 second	Sets the switchhook flash recognition time to lie between 190 ms and 900 ms.
191	Flash Timer - 1.1 second	Set the switchhook flash recognition time to lie between 190 ms and 1100 ms.
192	Message Registration Enable	Allows the system to keep count of the number of completed local Central Office calls made from each extension.
193	Message Registration Count Additional Supervisions	Counts all real (pseudo answer supervisions are ignored) answer supervisions received during each call.
194	Message Registration Timer 20 seconds	Causes a single pseudo answer supervision signal to be generated after 20 seconds if the serving CO does not provide answer supervision.
195	Message Registration Timer 40 seconds	Causes a pseudo answer supervision signal to be generated after 40 seconds, if the serving CO does not provide answer supervision. If neither of these two options are selected, the pseudo answer supervision signal is generated after 30 seconds. If both options are enabled the answer supervision is generated after 60 seconds.
196	Message Registration Multiplier - 2 units	Multiplies the Message Register count by 2.
197	Message Registration Multiplier - 3 units	Multiplies the Message Register count by 3.
198	Message Registration Multiplier - 4 units	Multiplies the Message Register count by 4.
199	Message Registration Surcharge - 1 unit	Adds a surcharge of 1 unit to the FIRST answer supervision signal received.
200	Message Registration Surcharge - 2 units	Adds a surcharge of 2 units to the FIRST answer supervision signal received.
201	Message Registration Surcharge - 3 units	Adds a surcharge of 3 units to the FIRST answer supervision signal received.
202	Message Registration Surcharge - 4 units	Adds a surcharge of 4 units to the FIRST answer supervision signal received.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
203	Message Registration Surcharge - 5 units	Adds a surcharge of 5 units to the FIRST answer supervision signal received on each call.
204	Message Registration Surcharge - 6 units	Adds a surcharge of 6 units to the FIRST answer supervision signal received on each call.
205	Message Registration Surcharge - 7 units	Adds a surcharge of 7 units to the FIRST answer supervision signal received on each call.
206	Message Registration Surcharge - 8 units	Adds a surcharge of 8 units to the FIRST answer supervision signal received on each call.
207	Discriminating Ringing All Calls	This option provides discriminating ringing on all calls - internal and external.
208	Outgoing Trunk Camp-On	Allows station camp-on feature to be used on trunks. If station camp-on is not enabled, this option is ineffective on trunks.
209	Outgoing Trunk Callback	Allows busy callback feature to be used on trunks.
210	Call Park Recall - 2 minutes	Sets the Call Park and Call Hold Recall time-out at 2 minutes.
211	Call Park Recall - 4 minutes	Sets the Call Park and Call Hold Recall time-out at 4 minutes. If neither of these two options is selected, the Call Park and Call Hold Recall timer will be 3 minutes. These time-outs are only effective if the "Call Park" or "Call Hold" stations feature has been selected.
212	Range Programming Enable	This option enables the Range Programming feature.
213	Single Digit Dialing Enable	Allows single digit codes to be used for special services even if the codes conflict with the numbering plan.
214	Single Digit Dialing Time-Out - 3 seconds	Completes a single digit dialed call after 3 seconds.
215	Single Digit Dialing Time-Out - 5 seconds	Completes a single digit dialed call after 5 seconds. If neither of these options are selected, single-digit calls are completed after 4 seconds.
217	Repeated Camp-On Tones - 5 seconds	This option, when enabled with the COS Option 107, specifies the repeated Camp-On to occur every 5 seconds. The call will not recall to the supervisor.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
218	Repeated Camp-on Tones 15 seconds	This option when enabled with the COS Option 107 specifies the repeated camp-on to occur every 15 seconds. The call will not recall to the supervisor.
219	TAFAS Available During Day	Enables TAFAS during day.
220	Transfer Dial Tone	Enables transfer dial tone.
230	Account Code Enable	This option enables the Account Code Feature.
232	Account Code Length: - 4 Digits	This option specifies the Account Code length to be 4 digits.
233	Account Code Length: - 8 Digits	This option specifies the Account Code length to be 8 digits.
234	Account Code Length: - 12 Digits	This option specifies the Account Code length to be 12 digits.
235	Variable Length Account Codes	This option allows Account Codes to be of a variable length up to 12 digits.
238	ARS Enable	This option enables the ARS feature.
239	ARS: Return Dial Tone	If this option is selected, dial tone will be returned after dialing the ARS code. This will encourage the user to continue dialing, after the ARS code has been dialed.
240	ARS Dial Tone Time-Out 5 seconds	If this option is selected, "Dial 0" long-distance calls are subject to a 5 second time-out (on first digit zero).
241	ARS Dial Tone Time-Out 10 seconds	If this option is selected, "Dial 0" long-distance calls are subject to a 10 second time-out (on first digit zero).
242	ARS Interchangeable Office Code Enable	Allows area and office codes to be used interchangeably.
245	Automatic Wake-Up Enable	Allows the supervisor to enable the system to ring an extension at a prearranged time.
246	Wake-Up Alarm Enable	This option allows an extension to set its own Wake-Up alarm.
247	Automatic Wake-Up Music on Hold	This option allows an extension answering a Wake-Up call to receive Music on Hold.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
248	Automatic Wake-Up Print	This option enables all Wake-Ups that are attempted, not answered and answered, to be printed.
253	Call Forwarding Busy (System DID, Dial-In CCSA)	Enables the DID, Dial-In, or CCSA Trunk Call Forwarding - Busy feature.
254	Call Forwarding - Don't Answer Time-Out (System, DID, Dial-In, CCSA)	Enables the DID, Dial-In, or CCSA trunk Call Forwarding - Don't Answer feature. See Call Forwarding - Don't Answer Time-Out system options.
255	Call Forwarding Don't Answer Time-Out - 10 seconds	This option limits the Call Forwarding Don't Answer Time-Out to 10 seconds.
256	Call Forwarding - Don't Answer Time-Out - 20 seconds	Causes Call Forwarding Don't Answer to forward after 20 seconds of ringing.
257	Call Forwarding - Don't Answer Time-Out - 40 seconds	Causes Call Forwarding Don't Answer to forward after 40 seconds of ringing. If neither of these two options is selected, the Call Forwarding Don't Answer time-out will be 30 seconds. These time-outs are only effective, if the "Call Forwarding Don't Answer" features are selected. The time-out selected will apply to both the station and system features.
258	Controlled Outgoing Restriction Setup	Enables the (ROOM RESTR) button; i.e., allows the supervisor to set up the controlled outgoing restriction feature. If this feature is selected, Night Service 2 is not available.
259	Customer Print-out Enable	This option allows the Customer RAM data to be output in a logical format on a printer.
260	Customer Programming Enable	This option enables programming from the supervisor console by the supervisor.
261	Customer Programming of ARS Enable	This option enables ARS definition by the supervisor.
262	Customer Programming of COS Definitions Enable	This option enables COS definition by the supervisor.
263	Customer Programming of Extensions Enable	This option enables Extension definition by the supervisor.
264	Customer Programming of Features Enable	This option enables Feature definition (of access codes) by the supervisor.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
265	Customer Programming of Hunt Groups Enable	This option enables Hunt Group definition by the supervisor.
266	Customer Programming of Speed Call Enable	This option enables Speed Call definition by the supervisor.
267	Customer Programming of System Options Enable	This option enables System Option programming by the supervisor.
268	Customer Programming of Toll Control Enable	This option enables Toll Control definition by the supervisor.
269	Customer Programming of Trunk Groups Enable	This option enables Trunk Group definition by the supervisor.
270	Customer Programming of Trunks Enable	This option enables Trunk definition by the supervisor.
271	Customer Range Programming Enable	This option enables Range programming.
272	Customer Programming of SUPERSET 4 Enable	This option, when set, allows the supervisor to program equipment as SUPERSET 4s or change the programming of a SUPERSET 4.
273	External Call Forwarding Enable	This option enables the External Call - Forwarding feature.
274	Hands-free Enable	This option enables the Hands-free feature.
275	Message Waiting Setup (Bell)	Enables the "MSGE WAIT" button and allows the supervisor to cause the system to distinctively ring extension every 20 minutes, to signal a "message waiting" condition.
276	Message Waiting Setup (Lamp)	Enables the "MSGE WAIT" button and allows the supervisor to cause the system to light "message waiting" lamps on extension.
277	Station Message Detail Recording Outgoing Calls	This option when activated initiates SMDR on outgoing calls.
278	Station Message Detail Recording Incoming Calls	This option when enabled initiates SMDR on all incoming calls.
279	SMDR: Record Only Incoming CO Calls (CCSA & Non-Dial Tie Trunks)	This option records all incoming calls in the switch.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
280	SMDR: Record Meter Pulses	This option allows the system to record all meter pulses from the CO.
281	SMDR: Drop Incomplete Outgoing Call	If this option is selected, outgoing calls that are not complete are not recorded.
282	SMDR: Drop Calls of Less than 8 Digits	This option will eliminate all trunk calls of eight digits or less from the SMDR records.
283	SMDR Extended Record	This option allows the length of the SMDR record to be extended from 80 to 88 characters. This allows the last four digits to 12-digit Account Codes and the system ID to be printed.
284	SMDR: Indicate Long Calls	This option flags all calls that are longer than 5 minutes.
285	SMDR Overwrite Enable	If this option is enabled SMDR record buffers will be written over when the printer has been suspended (*14*) and all the buffers are full.
286	Special ANI Feature	This option enables the special Automatic Number Identification feature.
287	Speed Call Enable	This option enables the system Speed Call feature.
288	Speed Call Programming Enable	This option allows the supervisor to program a Common Use table.
289	Speed Call Confidential Number Display	This option allows the supervisor to observe a Common Use number.
291	First Digit Toll Deny	Causes toll denial if the first digit dialed is 1, 0, * or #. If this option is not selected, toll denial will be on the first or second digit.
292	Multi-Digit Toll Control Enable	This option enables the Multi-Digit Toll Control feature.
295	Traffic Measurement Autoprint	This option allows traffic data to be output automatically at the end of each hour.
296	Traffic Measurement: Compact Traffic Report	This option causes the Traffic Measurements to be output in a compact format.
297	Traffic Measurement: Console Function Enable	If this option is selected, the Traffic Measurement may be controlled from the Supervisor Console.
298	Traffic Measurement Enable	This option enables the Traffic Measurement feature.

TABLE 2-1 (CONT'D)
SYSTEM OPTIONS

Option Number	Option	Description
299	Traffic Measurement: Extreme Value Mode	This option allows an active register's contents to be transferred to a storage register, if the active register is greater than the storage register.
300	Traffic Measurement Polling	This option allows traffic data to be polled by an external device.
310	MITEL Printer Condensed SMDR Print	This option when used with the MITEL printer will condense the print-out from 132 to 88 characters.
311	Ignore Print Enable	Allows the supervisor to dial a code that will purge and ignore the RS232 output.
312	Message Register & Message Waiting Change Print Enable	This option allows all Message Registers and Message Waiting to be printed.
313	Printer Carriage Return Delay	This option allows additional time for the printer carriage to return.
314	Printer Transmit Additional Nulls	This option allows the transmission of additional nulls to the printer.
315	Print-outs: Extra Line Feeds	This option allows for two extra line feeds for the printer in Hotel/Motel applications.
316	Room Message Register Audit Enable	This option allows an audit of all extension Message Registers that have any contents.
317	Room Status Audit Enable	This option will allow the Room Status of all rooms to be printed.
318	Zero Message Register After Room Register Audit	If this option is selected, the Message Registers will be zeroed after an audit.
330	SUPERSET Disconnect Alarm	This option raises a minor alarm at the Supervisor Console if a SUPERSET 4 is disconnected.
331	SUPERSET Immediate Line Selection Enable	This option allows the SUPERSET 4 user to always have a free line to access.
332	SUPERSET 4 Last Number Redial Enable	This option allows the SUPERSET 4 user to use a softkey on the SUPERSET as a last number redial.
334	SUPERSET 4 Auto-Hold Disable	This option disables the auto-hold button on the SUPERSET 4.

TABLE 2-2
SYSTEM OPTION CONFLICTS

RT

The following System Options are mutually exclusive; i.e., they cannot be simultaneously enabled on the same system.

208 and 286	Outgoing Trunk Camp-On & Special ANI Feature.
209 and 286	Outgoing Trunk Callback & Special ANI Feature.
209 and 230	Outgoing Trunk Callback & Account Code Enable.
120 and 113	Supervisor Serial Call & GUEST ROOM Button Enable.
120 and 119	Room Status Enable & Supervisor Serial Call.
296 and 275	Message Waiting Setups (lamp or bell).
248 and 300	Automatic Wake-Up Print & Traffic Measurement Polling.
316 and 300	Room Audit Enable & Traffic Measurement Polling.
317 and 300	Message Register Print & Traffic Measurement Polling.
312 and 300	Message Register and Message Waiting Change Print Enable & Traffic Measurement Polling.
300 and 295	Traffic Measurement Polling & Traffic Measurement Autoprint.

In addition to the above system options, some console service features are mutually exclusive. These features are listed below:

ROOM RESTRICT and NIGHT 2

ROOM STATUS and NIGHT 2

CALL BLOCK and HOLD 4

SERIAL CALL and GUEST ROOM (Unless System Option 121 is enabled)

Note: The Room Restriction and Room Status features utilize the same button, but are not mutually exclusive, as the Room Status feature can be arranged to include the Room Restriction function, if System Option 258 is selected.

- **CANCEL.** If, after entering a number of codes for a COS, an error is discovered, the new entries may be removed from the system by pressing the CANCEL Key.
- **ENTER.** After all entries have been made for the COS, the entries may be transferred to permanent storage by pressing the ENTER Key.

Feature Access Codes

2.06 A number of features (Table 2-4) require access codes to allow the extension users to select and use the features. Each feature access code must be unique within the system. The feature access codes are programmed from the console keys as described below:

- **FEATURE.** This key selects the feature program and allows the access codes to be defined. The number dialed (Table 2-4), after pressing the FEATURE Key, specifies the feature to which the access code is to be assigned.
- **ACCESS CODE.** After pressing this key, the number dialed (1 to 4 digits) is assigned as the access code of the feature selected. The system, automatically, checks to see if the code is assigned

to any other equipment or feature within the system, and if a match is found, displays an error message.

- **CANCEL.** The access just assigned to a feature may be removed by pressing the CANCEL Key. The new access code may be assigned immediately.
- **DELETE.** Pressing this key deletes the access code assigned to the feature, rendering the feature inoperative.
- **ENTER.** Transfers all new entries to permanent memory.

Extensions

2.07 The extension program allows all data associated with extensions to be specified, changed, or removed from the system memories. The extension program is selected by the console keys as described below:

- **RANGE.** To enable faster programming, extensions may be programmed in a range (i.e., extension numbers 200-250). The following information must be common for the range: Hunt Group, COS and Toll Control. A starting and ending point must be defined for equipment numbers, and a starting point must be defined for busy lamp numbers and extension access codes. No conflicts are allowed with equipment numbers, extension access codes busy lamp numbers and Hunt Groups.
- **EXTN.** Pressing this key enables the extension program, which allows new data to be entered or existing data to be changed or removed.
- **EQPT NUMBER.** The number (1-112, 161-256), entered after pressing the EQPT NUMBER Key, defines the equipment number of the line circuit serving the extension (Figure 2-1).
- **EXTN NUMBER.** The 1-, 2-, 3- or 4-digit number entered after pressing the EXTN NUMBER Key specifies the extension number of the telephone set being added or changed. This number must not conflict with other extension numbers or access codes. If nonconflicting single digit dialing is required, enter $N\#$, where N is the single digit.
- **COS NUMBER.** The number (1-16) entered after pressing the COS NUMBER Key, specifies the Class of Service, and therefore the features, that may be accessed by the extension (see 2.04 Class-of-Service Option).
- **TOLL DENY.** Each extension may be defined as TOLL-ALLOWED - allowed to originate calls to the toll network; or TOLL-DENIED - not allowed to make calls to the toll network. To make the extension TOLL-ALLOWED, press the TOLL DENY Key, then the DELETE Key. To make the extension TOLL-DENIED, press the

TOLL DENY Key, then the ADD Key. The extension will be TOLL-DENIED, only if the extension and the Trunk Group are TOLL-DENIED. This allows Toll Denial on a Trunk Group basis if System Option 292 was enabled. See also Section MITL9105/9110-096-212-NA, Multi-Digit Toll Control.

- **BUSY LAMP NUMBER.** After pressing this key, the number entered (1-200) defines the position (Figure 2-2) of the busy lamp to be associated with the extension. If the extension is not to be assigned a busy lamp, no entry is required.
- **DELETE.** Pressing the DELETE Key removes the existing busy lamp assignment.
- **PICKUP GROUP.** The system may hold up to 30 independent Call Pickup Groups. An extension may be made a member of any group, by entering the Pickup Group number after pressing the PICKUP GROUP Key. Any number of extensions may be assigned to a Pickup Group, but an extension may only be a member of one group at any time.
- **CANCEL.** Pressing the CANCEL Key, prior to the operation of the ENTER Key, removes any data entered during the foregoing Extension Program sequence.
- **ENTER.** Transfer all new data for the extension to permanent memory.

TABLE 2-3
CLASS-OF-SERVICE OPTIONS

n1

Option Number	Option	Description
33	Automatic Callback	Allows Automatic Callback - Busy and Automatic Call-back - Don't Answer. See system option Outgoing Trunk Callback.
34	Call Forwarding - Busy	Allows Call Forwarding - Busy.
35	Call Forwarding - Don't Answer	Allows Call Forwarding - Don't Answer.
36	Call Forwarding - Follow Me	Allows Call Forwarding - Follow Me.
37	Call Park	Allows Call Park. See "Park Recall" system options.
38	Never a Forwardee	Prevents calls being forwarded to this line.
39	Directed Call Pickup	Allows Directed Call Pickup - this is required for remote access of Call Park.
40	Executive Busy Override	Allows Executive Busy Override.
41	Data Security	Provides security against any audio intrusion.
42	Station Override Security	Provides security against Executive Busy Override.
43	Inward Restriction (DID)	Denies Direct-In-Dial calls.
44	Originate Only	Denies all incoming calls.
45	Receive Only	Denies all outgoing calls.
46	Flash Disable	Inhibits recognition of switchhook flash.
47	Never a Consultee	Denies incoming calls that originated from a Consultation Hold.
48	Broker's Call	Allows Broker's Call. Denies transfer and add-on. Cannot be provided together with Station Conference, or Flash for Supervisor.
49	Station Conference	Allows Station-Controlled Conference.
50	Meet-Me Conference	Allows access to Meet-Me Conference.
51	Camp-On	Allows Station Camp-On. See system option "Outgoing Trunk Camp-On".
52	Do Not Overflow	Prevents an extension from accessing trunk groups via overflow.

TABLE 2-3 (CONT'D)
CLASS-OF-SERVICE OPTIONS

Option Number	Option	Description
53	Pager Access	Allows access to both paging amplifiers.
54	TAFAS Access	Allows Trunk Answer From Any Station access.
55	Hold Pickup	Allows access to the Hold Pickup feature.
56	Account Code Access	Allows an extension to use an account code on trunk calls.
57	Manual Line	Routes all originating calls directly to the supervisor for completion.
58	Contact Monitor	Allows the line to be used for contact monitoring and to call the supervisor upon detection of contact closure.
59	Non-CO Trunk via Supervisor Inhibit	Denies access to non-CO trunks via the supervisor.
60	CO Trunks via Supervisor Inhibit	Denies access to CO trunks via the supervisor.
61	No Dial Tone	Denies dial tone to originating calls from incoming tie-lines.
62	Flash for Supervisor	Provides automatic connection to the Supervisor Console when the switchhook is flashed (Supervisor Transfer). Cannot be provided together with Broker's Call, Consultation Hold, Transfer and Add-On, or Station Conference.
63	H/M Stn-Stn Restrict Applies	Allows controlled station-to-station restriction to apply, when activated by the supervisor. See system option "Controlled Station-to-Station Restriction".
64	Message Register	Allows the system to keep count of the local call units made from this extension.
65	Trunk Group 1	Allows access to individual trunk groups.
66	Trunk Group 2	Allows access to individual trunk groups.
67	Trunk Group 3	Allows access to individual trunk groups.
68	Trunk Group 4	Allows access to individual trunk groups.
69	Trunk Group 5	Allows access to individual trunk groups.
70	Trunk Group 6	Allows access to individual trunk groups.

**TABLE 2-3 (CONT'D)
CLASS-OF-SERVICE OPTIONS**

Option Number	Option	Description
71	Trunk Group 7	Allows access to individual trunk groups.
72	Trunk Group 8	Allows access to individual trunk groups.
73	Trunk Group 9	Allows access to individual trunk groups.
74	Trunk Group 10	Allows access to individual trunk groups.
75	Trunk Group 11	Allows access to individual trunk groups.
76	Trunk Group 12	Allows access to individual trunk groups.
77	Message Waiting Applies	Allows the supervisor to set a message waiting indication at the extension.
78	Room Do Not Disturb Setup Enable	Allows the extension user to set up and cancel Do Not Disturb for the extension - by dialing appropriate access codes.
79	Call Hold and Retrieve Access	Allows the extension access to the Call Hold and Retrieve feature.
80	Room Status Applies	Allows the Room Status of the extension to be displayed at the Supervisor Console.
81	Call Forwarding System Inhibit	The system Call Forwarding options 149 and 150 are inactive on extensions with this Class-of-Service option.
82	Alarm Call Setup Enable	Allows either the extension to change or cancel its own wake-up time.
83	Forced Account Code Entry	An extension, with this option in its COS, must dial a 1- to 12-digit Account Code before dialing a client's number.
84	No SMDR Record Applies	An extension with this option in its COS will not be recorded by Station Message Detail Recording.
85	Speed Call Table 1 & 2 Access	Allows access to common-use Speed Call tables specified.
86	Speed Call Table 3 & 4 Access	Allows access to common-use Speed Call tables specified.
87	Speed Call Table 5 & 6 Access	Allows access to common-use Speed Call tables specified.
88	Speed Call Table 7 & 8 Access	Allows access to common-use Speed Call tables specified.

TABLE 2-3 (CONT'D)
CLASS-OF-SERVICE OPTIONS

Option Number	Option	Description
89	Speed Call Table 9 & 10 Access	Allows access to common-use Speed Call tables specified.
90	Speed Call Table 11 & 12 Access	Allows access to common-use Speed Call tables specified.
91	Speed Call Table 13 & 14 Access	Allows access to common-use Speed Call tables specified.
92	Speed Call Table 15 & 16 Access	Allows access to common-use Speed Call tables specified.
93	Speed Call Table 17 & 18 Access	Allows access to common-use Speed Call tables specified.
94	Cannot Dial a Trunk After Flashing	An extension, with this option in its COS, will not be able to dial a trunk after flashing.
95	Incoming Trunk Rotary Dial Only	An incoming trunk, with this option in its COS, will ignore DTMF signaling.
96	ARS Restricted	An extension, with this option in its COS, will not have access to the last route selected by ARS.
97	External Call Forwarding Connect Enable	An extension must have this option in its COS, in order to have a call it makes to an extension with External Call Forwarding in effect completed.
98	Transfer with Privacy	An extension with this option in its COS will be able to: put a call on hold, dial a new number and consult privately or hang up and the call on hold and the new number will be connected.
99	Hands-free Station	An extension with this option in its COS need not go off-hook to answer a call since it should be in the off-hook position.
100	ARS Allowed	An ARS user with this option will be able to access a Trunk Group, even though the user's COS was not enabled for that Trunk Group. This will occur when the ARS feature finds that the only Trunk Group free is not in the user's COS but will force a connection. This option must be enabled for an extension to use ARS.
101	Earth Ground Button	This option allows the use of a Earth Ground button on an extension's telephone set. Note: A special line card is required when using this COS option.

**TABLE 2-3 (CONT'D)
CLASS-OF-SERVICE OPTIONS**

Option Number	Option	Description
102	Call Announce Port	This COS option allows a SUPERSET 4 user to use an alternate equipment number as an announcement port.
103	Extension Call Forwarding Reset	This option allows an extension to clear Call Forwarding at another extension by using the access code for feature number 48.
106	SUPERSET Sub-Supervisor Enable	This COS option allows a SUPERSET 4 to be used as sub-supervisor position. All calls handled to the sub-supervisor will recall to the sub-supervisor.
107	Repeated Camp-On Beeps	This COS option, when enabled in an extension or trunk's COS, will enable the trunk or extension to camp-on to a party and not recall. The camped-on to party will receive continuous camp-on tones at 5, 10 or 15 second intervals (as programmed). If neither System Options 217 or 218 are programmed, the repeated tones will be every 10 seconds.
108	SUPERSET Background Music	This option, when enabled, allows the SUPERSET 4 user to access the Music on Hold path and listen to the music by pressing the softkey indicating the musical note.
109	SUPERSET 4 Sub-Supervisor Programming of Messages	This option allows only the sub-supervisor to program the SUPERSET messages.
110	Special DISA Access Code	If this option is enabled in a DISA trunk's COS the incoming caller need only dial the Verifiable Account code to dial back out of the system. If this option is not enabled both the DISA code and the Account Code would have to be dialed.
111	DISA/Extension Routing Direct to ARS	If this option is enabled in a DISA or extension's COS routes all calls are made on the trunk or extension through the ARS feature.
112	Off-Premise Extension	This option must be enabled for any off-premise extension.
113	ARS Disallow Schedule A	This option when enabled restricts access to ARS Schedule A.
114	ARS Disallow Schedule B	This option when enabled restricts access to ARS Schedule B.
115	ARS Disallow Schedule C	This option when enabled restricts access to ARS Schedule C.

**TABLE 2-3 (CONT'D)
CLASS-OF-SERVICE OPTIONS**

Option Number	Option	Description
116	ARS Limited Access	This option when enabled restricts access to trunks routed by ARS to trunks in the caller's COS.
117	Agent Call Distribution	This option when enabled specifies that the extension is an Agent in Agent Group.
118	ARS Most Expensive Route Warning Tone	This option when enabled provides an audible tone indication to SUPERSET 3 and standard telephones and a visual note (EXPENSIVE ROUTE) to SUPERSET 4 users when the last ARS route is used.
119	Low Conference Gain Enable	This option enables the low gain feature of the system during conferencing. If this option is not enabled high gain will be employed.
120	Privacy Disable	This Option disables privacy on Key Line appearances.
CLASS-OF-SERVICE Option Conflicts		
45	Receive Only	and 58 Contact Monitor
46	Flash Disable	and 48 Broker's Call
46	Flash Disable	and 49 Station Conference
46	Flash Disable	and 62 Flash for Supervisor
48	Broker's Call	and 49 Station Conference
62	Flash for Supervisor	and 49 Station Conference
62	Flash for Supervisor	and 48 Broker's Call

TABLE 2-4
FEATURE ASSIGNMENTS

R1

Feature Number	Description
1	Supervisor Access
2	Callback - Don't Answer
3	Call Forwarding - Busy
4	Call Forwarding - Don't Answer
5	Call Forwarding - Follow Me
6	Call Park
7	Dial Call Pickup
8	Directed Call Pickup
9	Meet-Me Conference
10	Pager 1
11	Pager 2
12	Hold Pickup Access
13	Pager 1 and 2
14	TAFAS-All
15	TAFAS-1
16	TAFAS-2
17	TAFAS-3
18	Supervisor Function
19	Maintenance Function
20	DID Supervisor Access Code
21	Direct Inward System Access
22	Executive Busy Override (Single Digit)†
23	Callback - Busy (Single Digit)†
24	Room Do Not Disturb Setup and Cancel
25	Call Hold
26	Call Retrieve (Local)
27	Call Retrieve (Remote)
28	Room Status Update (Maid in Room)
29	Programming Security Code
30	Alarm Call
31	Account Code
32	Speed Call
33-42	Assign access codes features 33-42 for Trunk Group 1 if necessary
43	Customer Programming Security Code
44	ARS Access Code
45	Hands-free Activation
46	Call Forwarding Busy/Don't Answer
47	Extension Reset
48	SUPERSET 4 Loopback Test
49	ACD Agent

† First digit conflicts between these codes and other access codes are allowed. See Section MITL9105/9110-090-105-NA for complete description of feature operation.




Figure 2-2A Busy Lamp Position Numbering

Hunt Groups

2.08 The system can hold up to 12 different Hunt Groups. Each Hunt Group may contain an unlimited number of members and be specified as:

- **TERMINAL HUNTING.** The Hunt Group sequence starts at the first equipment number and ends at the last number in the hunt chain. The call is completed at the first idle number encountered.
- **CIRCULAR HUNTING.** Hunting starts at the last equipment number reached and hunts over all members of the Hunt Group. The call is completed at the first idle number found.
- **SECRETARIAL HUNTING.** This is terminal hunting where the last number is common to two or more extension Hunt Groups.
- **DUAL NUMBER ACCESS.** An extension may be programmed to allow it to be accessed by two different numbers. The first number is assigned when programming the extension and the second number is assigned when programming a Hunt Group with the extension as the only member. The extension may therefore be accessed by dialing the extension number or the Hunt Group

master number (see Section MITL9105/9110-090-105-NA Single Digit Dialing).

Note: When changing the list of members of a Hunt Group in any way, all members of the Hunt Group must be reentered.

2.09 The following console keys are activated to program the Hunt Groups:

- **HUNT GROUP.** Allows the Hunt Group required to be selected by dialing the Hunt Group number (1-12).
- **ACCESS CODE.** Allows the 1-, 2-, 3- or 4-digit code identifying the Hunt Group master number to be entered.
- **DELETE.** Pressing this key deletes the Hunt Group from the system memory.
- **EQPT NUMBER.** This key must be pressed before dialing the equipment number of each extension in the Hunt Group. If circular hunting is to be defined, the last entry in the hunt group must be the same as the first entry. Membership in a Hunt Group is mutually exclusive with "message registration" and "room status" for this extension.
- **CANCEL.** Deletes all new data entered associated with the Hunt Group.
- **ENTER.** Transfers all new data for the Hunt Group to permanent memory.

Trunks

2.10 This program allows the type console appearances, day and night assignment, COS and toll deny codes of each trunk to be specified.

2.11 The following console keys are employed to enter this program:

- **TRUNK.** Selects the trunk program
- **EQPT NUMBER.** The number entered (10-112; 162-256, even numbers only) specifies the equipment number of the trunk circuit serving this trunk (Figure 2-1).
- **TYPE.** The code entered, defines the type of trunk being specified.
 - Code 1 - CO trunk + VNL
 - Code 2 - DISA trunk + VNL
 - Code 3 - DID trunk + VNL

- Code 4 - Dial-In tie trunk + VNL
 - Code 5 - Non Dial-in tie trunk + VNL
 - Code 6 - CCSA trunk + VNL
 - Code 11 - CO trunk + NON VNL
 - Code 21 - DISA trunk + NON VNL
 - Code 31 - D ID trunk + NON VNL
 - Code 41 - Dial-In tie trunk + NON VNL
 - Code 51 - Non Dial-In tie trunk + NON VNL
 - Code 61 - CCSA trunk + NON VNL
- **DELETE.** If this key is pressed, the information associated with this trunk is removed from the system memory.
 - **BUSY LAMP NUMBER.** The number (1-200) defines the position (Figure 2-2) of the busy lamp to be associated with this trunk. If the trunk is not to be assigned, a busy lamp no entry is required.
 - **DELETE.** If this key is pressed, the busy lamp assignment for this trunk is deleted.
 - **LDN NUMBER (Types 1, 5, 11, 51 only).** This single digit entry defines the Listed Directory Number Key (LDN 1, 2, 3 or 4) on the Supervisor Console which is to be associated with the trunk. If the trunk is not to appear on the supervisor console, no entry is required. DID trunk calls to the supervisor always appear on LDN 4.
 - **DAY NUMBER (Types 1, 5, 11, 51 only).** The code entered for Day Number specifies any special assignments of the trunk during normal daytime service. These assignments may be:
 - no assignment to bells, extensions or Hunt Groups, console appearance only (Default code #0)
 - assigned to ring bell 1, code #1
 - assigned to ring bell 2, code #2
 - assigned to ring bell 3, code #3
 - assigned to one extension - enter equipment number of extension
 - assigned to a Hunt Group, codes 1 to 12.

- **I/C (Types 3, 6, 31, 61 only).** This 2- or 3-digit entry for DID or CCSA trunks defines the number of incoming digits, the number of digits to be absorbed; and the digit to be added to the incoming number after absorption.
- **NIGHT 1 (Types 1, 5, 11, 51 only).** This entry defines the assignment of the trunk during Night Service 1. Assignment is made in the same manner as for DAY NUMBER assignment.
- **NIGHT 2.** The entry defines the assignment of the trunk during Night Service 2. This assignment is made in the same manner as for DAY NUMBER assignment.
- **COS NUMBER (Types 2, 4, 21, 41 only).** The number (1-16) entered, after pressing this key, specifies the Class of Service and therefore the features, that may be accessed by the dial-in trunk. See 2.04 Class-of-Service Option.
- **TOLL DENY (Types 2, 4, 21, 41 only).** Each dial-in trunk may be defined as TOLL-ALLOWED - allowed to originate calls to the toll network; or TOLL-DENIED - not allowed to make calls to the toll network. To make the tie trunk TOLL-ALLOWED, press the TOLL DENY Key, then the DELETE Key. To make the tie trunk TOLL-DENIED, press the TOLL DENY Key, then the ADD Key. If System Option 292 is enabled, see also Section MITL9105/9110-090-212-NA Multi-Digit Toll Control.
- **CANCEL.** Pressing this key, prior to the operation of the ENTER Key, removes any data entered in the temporary storage.
- **ENTER.** Deletes previous data associated with this trunk and stores the new data.

Trunk Groups

2.12 The Trunk Group program specifies the trunks forming the Trunk Group, the restrictions and options common to all trunks in the group. The Trunk Group may employ terminal or circular hunting (see 2.08). When making any change to the list of members of a Trunk Group, all members of the group must be reentered. The following console keys are activated to program the Trunk Groups:

- **TRUNK GROUP.** The number (1-12) entered specifies the Trunk Group to be set up or changed.
- **ACCESS CODE.** Allows the 1-, 2-, 3- or 4-digit code identifying the Trunk Group to be specified.
- **DELETE.** Pressing this key deletes the Trunk Group from the system memory.
- **TYPE.** The 4-digit code entered after pressing the TYPE Key specifies the Trunk Group type parameters as detailed in Table 2-5.

- **TOLL DENY.** Each Trunk Group may be specified as TOLL-ALLOWED - allowed to originate calls to the toll network, or TOLL-DENIED - not allowed to make calls to the toll network. To make the Trunk Group TOLL-ALLOWED, press the TOLL DENY Key, then the DELETE Key. To make the Trunk Group TOLL-DENIED, press the TOLL DENY Key, then the ADD Key. Toll Denial is effective only when both the Trunk Group and the extension or dial-in trunk involved are TOLL DENIED and are ignored by the System. This prevents circumvention of the toll denial by dialing a fast valid digit before CO dial tone is received.
- **OVERFLOW.** The number entered (1-12) specifies the trunk overflow group number. If all trunks within the Trunk Group being defined are busy, any additional calls directed to the Trunk Group will be rerouted to the overflow group. Overflow arrangements which direct the callback to the original group must NOT be specified.
- **EQPT NUMBER.** This key must be pressed before dialing the equipment number (2-112; 162-256) of each trunk in the group. If circular hunting is to be defined, the last entry in the Hunt Group must be the same as the first entry. If circular hunting is not required, the Trunk Group is terminal hunting (see 2.08).
- **CANCEL.** Pressing the CANCEL Key removes all new data entered for the Trunk Group, leaving any existing data unchanged.
- **ENTER.** Removes all old data associated with the Trunk Group and transfers the new data entered to permanent memory.

3. PROGRAMMING

General

3.01 After all installation procedures have been completed in accordance with Section MITL9105/9110-090-200-NA, the system should be programmed as detailed in the MITEL Action Procedures (MAPs) contained in Appendices 1 and 2. Each MAP in Appendix 2 also contains a sample programming form pertinent to the MAP.

Error/Confirm Codes

3.02 During standard system programming, the console DESTINATION display may show "error" or "confirm" codes, with the meanings indicated in Tables 3-1 and 3-2, respectively. These tables also indicate required action when the code is displayed. In the extended programming mode, errors may also be displayed at the console. Tables 3-3, 3-4, 3-5 and 3-6 show the meanings of these errors.

Supervisor Function Access Codes

3.03 Table 3-7 is a listing of the supervisor function access codes. To select any of the supervisor functions, the access code for feature 18 must have been dialed. The code * is used in Table 3-7.

Maintenance Function Access Codes

3.04 Table 3-8 lists the maintenance function access codes. To select any of the maintenance functions, the access code assigned for the maintenance function must be dialed (Feature Number 19). The code 555 is used in Table 3-8, for the maintenance code and may be dialed from the test line or console.

Supervisor Function Codes

3.05 The Supervisor Function Codes (Table 3-9) outline all the function codes necessary for the implementation of ACD.

Time-Out Information

3.06 During programming, it may be necessary to know the time-out information with regard to certain functions. Table 3-10 is such a listing of the time-out information.

TABLE 2-5
TRUNK GROUP TYPE CODES

RT

First Digit (Note 1)	Second Digit	Third Digit (Note 2)	Fourth Digit
1. No supervision	1. No Message Register	†1. Dial pulse, no wait for dial tone	1. CO trunk
2. Answer supervision	2. Message Register	†2. Dial pulse, wait for dial tone	2. Non-CO trunk
3. Toll Reversal	3. SMDR Enable and no Message Register	3. DTMF, no wait for dial tone	3. Identified Trunk Group (Type XX13) only is valid)
4. Outgoing audio inhibited until answer supervision	4. SMDR Enable and Message Register Enable	4. DTMF, wait for dial tone	

† If extensions are DTMF, the trunk will convert to dial pulse. Early line split is not provided. Trunks will repeat DTMF or dial pulse signals unless outgoing audio is inhibited.

Notes:

1.
 - If answer supervision is not required (or not provided by the CO), then use 1 (No supervision).
 - If trunks provide answer supervision and tandem trunking or message registration is used, then specify 2 (Answer supervision).
 - If supervision is used to indicate toll calls, and this feature is required, then use 3 (Toll supervision).
 - If audio cut-through on tie-trunk tandem calls is required only after receipt of answer supervision, then use 4 (Outgoing audio inhibit until answer supervision). In addition the audio is inhibited until timed out or unless a # is dialed.
2.
 - If "wait for dial tone" is selected, then any digits dialed prior to receipt of CO dial tone

TABLE 3-1
PROGRAMMING ERROR CODES

R1

Error Code	Cause	Key Affected	Key Flashing	Meaning	Action Required
E0	Invalid key pressed.	ALL	NONE	The last key pressed is invalid at this time.	Check procedure and press correct key.
E1	Invalid number.	ALL	None	The number entered is out of range or contains corrupted data.	Press key associated with entry and re-entry number.
E2	Key other than ENTER, CANCEL pressed.	LAMP TEST COS OPTION FEATURE EXTN NUMBER, TRUNK HUNT GROUP TRUNK GROUP NEXT, EQPT NUMBER	ENTER, CANCEL	An attempt was made to leave the current mode, after some parameters were changed, but before ENTER or CANCEL was pressed. ENTER may be used to write the new programming information back to the non-volatile RAM, or use CANCEL to ignore all programming changes made, since the last time ENTER was pressed.	Press ENTER to transfer the data to permanent or CANCEL to remove the data from the temporary store.
E3	Access code has not been entered.	HUNT GROUP, TRUNK GROUP	ACCESS CODE	Attempting to enter members into a Hunt or Trunk Group before an access code has been assigned to the group.	Press ACCESS CODE Key and enter required access code.
E4	The extension number or access code entered is already assigned.	EXTN, ACCESS CODE	None	The extension number of access code entered is already assigned to an extension, feature, Hunt Group or Trunk Group. In Trunk mode, an attempt is made to delete a member of a Trunk Group. Equipment numbers desired must be entered. In Trunk Group mode, an attempt is made to place a trunk into a Trunk Group while that trunk is currently programmed into another Trunk Group. Callback and Executive Override conflict, i.e., trying to enter a Callback code while same code is assigned to Executive Busy Override and vice versa.	Check code entered. 1. If code is correct, terminate entry, remove other appearance of code and reenter all new data. 2. If code is incorrect, press key associated with entry and reenter extension number or access code.
E5	Number entered contains incorrect number of digits or conflicting option enabled in this COS.	EXTN NUMBER, ACCESS CODE	None	The extension number or access code is in conflict with the existing numbering plan. Attempting to add an option to a COS in which a conflicting option is enabled. Attempting to add a System Option when a conflicting option exists.	Check entry. Press key associated with entry and reenter number.

TABLE 3-1 (CONT'D)
PROGRAMMING ERROR CODES

11

Error Code	Cause	Key Affected	Key Flashing	Meaning	Action Required
E6				During trunk or extension programming and attempting to assign an equipment number as a line or a trunk when other equipment numbers previously programmed for that slot identify the slot as other than the type being programmed (i.e., line, trunk, or SUPERSET)	
E6				During trunk programming an attempt has been made to change the programming for the trunk and the trunk has an appearance on a SUPERSET 4. The trunk appearance must be deleted from any SUPERSET 4 keys before changing the trunk.	
E6				During extension programming an attempt has been made to delete an extension which has an appearance on a SUPERSET 4. The extension appearance must be deleted from any SUPERSET 4 keys before deleting the extension.	
E6	Incorrect equipment number entered.	EQPT NUMBER	None	Attempting to assign an equipment number that is: - undefined - defined as a trunk to an extension Hunt Group or extension - defined as an extension to a Trunk Group or a trunk - an extension with message registration to Hunt Group or Pickup Group. An equipment number assigned to an extension must be deleted as an extension, before being programmed as a trunk. An equipment number assigned to a trunk must be deleted as a trunk, before being programmed as an extension.	Remove conflicting option: (a) Assign equipment number correctly. (b) Enter new equipment number.
E6	In extension mode the equipment number assigned as a call announce port, programmed SUPERSET or a single line set with appearances.	EQPT NUMBER	None	The equipment number selected to be programmed has already been programmed in SUPERSET programming as: a SUPERSET, single line set with appearances or an announce port.	Enter correct equipment number or delete conflicting SUPERSET programming.

TABLE 3-1 (CONT'D)
PROGRAMMING ERROR CODES

RT

Error Code	Cause	Key Affected	Key Flashing	Meaning	Action Required
E6	In trunk mode the trunk selected has appearances on a SUPERSET.	EQPT NUMBER	None	The trunk equipment number already has an appearance on a SUPERSET.	Delete appearances on SUPERSET.
E7	System is busy.	ENTER	None	(a) Attempting to initialize a system while System is in use. (b) Attempting to change data of an extension or trunk while that extension or trunk is in use. It must be idle or busied-out.	(a) Wait until system is idle. (b) Wait until extension or trunk is idle
	Extension has a message register that is not zeroed or has a message waiting, or has Do Not Disturb set.	ENTER	None	- A valid message register exists for this extension. - Extension has a message waiting or Do Not Disturb set.	Zero message register, reset message waiting or Do Not Disturb and reprogram.
E8	Trunk or equipment number already assigned.	ENTER	None		(a) Enter proper trunk or equipment number. (b) Press ENTER.
E9	Non-volatile RAM error	ENTER	None	Ones and Zeros test failed.	
E020			None		Non-volatile RAM must be initialized and/or reprogrammed.
E022 -20	At Power Up		None		Non-volatile RAM must be initialized and/or reprogrammed.
E023 -20	At Power Up	None	None	RAM battery switches not enabled.	Turn RAM battery switches on.

**TABLE 3-2
STANDARD CONFIRM CODES**

R1

Confirm Code	Cause	Key Affected	Flashing Lamp	Action Required
C0	Attempting to assign an equipment number for an extension to a slot containing a trunk card	EQPT NUMBER	CONFIRM	Check assignment: - If correct, press CONFIRM key. Equipment number entered is accepted as the number for the equipment type being programmed. All data associated with the original appearance of the equipment number is removed.
C0	Attempting to assign an equipment number for a trunk to an empty slot or a slot containing an extension card	EQPT NUMBER	CONFIRM	- If incorrect, press EQPT NUMBER and reenter new equipment number.
C1	Attempting to assign an extension that already exists	EXTN NUMBER	CONFIRM	Check assignment: - if correct, press CONFIRM key. The extension number entered is accepted as the extension number for the equipment being defined. All data associated with the original appearance of the extension number is removed. - If incorrect, press EXTN NUMBER and reenter extension number.
C2	The busy lamp assignment already exists	BUSY LAMP	CONFIRM	Check assignment: - If correct, press CONFIRM Key. Busy lamp assignment is accepted for this equipment. All data associated with original assignment is removed. - If incorrect, press BUSY LAMP and reenter busy lamp assignment.

AUTOMATIC ROUTE SELECTION CONFIRM CODE

R1

Error	Applies to:	Meaning
C6	Area Code	A request has been made to delete all entries in a table.

TOLL CONTROL PROGRAMMING CONFIRM CODES

R1

Error	Applies to:	Meaning
C5	Control Plan mode Table mode	An attempt was made to assign a table which is currently assigned elsewhere. Pressing the confirm key will deassign the table from wherever it was previously assigned to assign it to the specified place.
C6	Table Mode	A request has been made to delete all entries in a table. If CONFIRM is pressed all entries will be deassigned. The old data in the non-volatile RAM will not be destroyed until the ENTER Key is pressed, and the table itself can be reprogrammed as desired before the ENTER Key is used.

TABLE 3-3
EXTENDED PROGRAMMING ERROR CODES - TOLL CONTROL

R1

Error	Applies to:	Meaning
E0	All modes	Invalid key pressed. Consult MAP for correct procedure. System Option 292 may not be enabled.
E1	Trunk Group mode Control Plan mode	Number is not within the range of the parameter being defined. Reenter parameter key defined.
E2	All modes	An attempt was made to leave the current mode after some parameters were changed but before ENTER or CANCEL was pressed. ENTER may be used to write the new programming information back to the non-volatile RAM, or use CANCEL to ignore all programming changes made since the last time ENTER was pressed.
E3	Control Plan mode	The number entered is not valid. Reenter a number which is valid.
E4	Table mode	The table entry code is invalid for the table programmed. This occurs in the following situation: 1. A code of more than 3 digits in the length for an 800-entry or 20-range table. 2. A code not in the range of 200-999 for an 800-entry table. 3. A code which already exists or a code which would be ambiguous in conjunction with the existing table entries, for a 4-entry table.
E5	Table mode	The table is full and cannot hold the entry.
E7	Configuration mode	Initialization is not allowed because the Tone Control card switches are not 7776 or the system is not idle.
E9	Configuration mode	A hardware failure was detected while clearing the extended customer non-volatile RAM.

TABLE 3-4
EXTENDED PROGRAMMING ERROR CODES - SPEED CALL

R1

Error Code	Key Involved	Explanation
E1	EQPT NUMBER	The Equipment Number entered is outside the range of valid numbers. Check procedures and press key, then redial proper digits.
E1	ACCESS NUMBER	The Access Number entered is not the first of the 5-number group. Enter the proper Access Number.
E1	NUMBER REDIAL	An invalid Number Redial value was entered. Enter the proper redial value.
E2	All modes	An attempt was made to leave the current mode after some parameters were changed but before ENTER or CANCEL was pressed. ENTER may be used to write the new programming information back to the non-volatile RAM, or use CANCEL to ignore all programming changes made since the last time ENTER was pressed.
E3	TABLE	The Table number entered is not allowed.
E4	ACCESS NUMBER	An attempt was made to enter an Access Number for a common-use table.
E4	NUMBER REDIAL	An attempt was made to enter a Number Redial digit for a common-use table.
E5	ACCESS NUMBER	The Access Number entered already exists for another table assigned to the same equipment number.
E5	NUMBER REDIAL	Number Redial already exists for another table assigned to the same equipment number (only 1 Number Redial attribute per user is allowed).
E6	SPEED CALL	Speed Call feature not enabled.

TABLE 3-5
EXTENDED PROGRAMMING ERROR CODES - AUTOMATIC ROUTE SELECTION

R1

Error Code	Key Involved	Explanation
E0	All modes	Invalid key pressed.
E1	Area Code Table mode Office Code Table mode Routing Table mode Local Area mode Table Quantity mode	Number is not within range.
E2	All modes	An attempt was made to leave the current mode after parameters were changed, but before ENTER or CANCEL was pressed.
E3	Office Code mode	The Office Code table number is not valid for this configuration.
E4	Routing Table mode	An attempt was made to enter a trunk group number that is not defined.
E5	Office Code Table mode	The 9-entry Office Code Table is full and cannot hold the entry.
E6	Routing Table mode	Schedule A hours and Schedule B hours are not mutually exclusive.
E7	Configuration mode	Initialization is not allowed because the Tone Control card switches are not 7776 or the system is not idle.
E9	Configuration mode	A hardware failure was detected while clearing the extended customer non-volatile RAM.

TABLE 3-6
EXTENDED PROGRAMMING ERROR CODES - SUPERSET PROGRAMMING

n1

Error Code	Key Involved	Explanation
E0		This error is given when entering SUPERSET programming if either the SUPERSETs are not enabled, or the supervisor attempts to use Customer Programming of SUPERSET and System Option 272 is not enabled. This error is also given throughout SUPERSET programming when an invalid key is pressed.
E1	PRIME KEY	Entering a SUPERSET equipment number as slot 1 (equipment numbers 001-008).
E1	PRIME KEY	Number out-of-range error. Given in PRIME KEY mode when attempting to enter COS number, Toll Deny, Busy Lamp number, Pickup Group number, or Call Announce Port number.
E3	SET EQPT NUMBER	Given when entering a SUPERSET equipment number if the number supplied is defined within the system as something other than a SUPERSET. Also given if the key type supplied is not valid.
E3	PRIME KEY	Attempting to assign an equipment number as a SUPERSET when other equipment numbers previously programmed for that slot identify the slot as other than a SUPERSET Line card.
E4	SET KEY NUMBER	Given if the key number supplies is invalid (other than 2-15).
E10	LISTED NUMBER	Directory number was not entered when attempting to define a Prime Key.
E11	TYPE	Type was not entered when attempting to define a Non-Prime Key.
E12	LISTED NUMBER	Directory number was not entered before defining a Non-Prime Key.
E13	TRUNK EQPT NUMBER	Trunk equipment number was not entered when required when defining a Non-Prime Key.
E20	LISTED NUMBER	The directory number supplied is conflicting with an existing system access code. This error is also given when attempting to add a key line appearance of a single line set. The appearance of a single line set must be multiple call.
E21	LISTED NUMBER	The directory supplied is invalid, because it would result in mixing key line and multiple call appearances with the same directory number. This error occurs when attempting to add a Non-Prime Key, and the directory number exists as either a prime with the wrong type of appearances or a primeless list of the wrong type (i.e., key line or multiple call).

TABLE 3-6 (CONT'D)
EXTENDED PROGRAMMING ERROR CODES - SUPERSET PROGRAMMING

Error Code	Key Involved	Explanation
E22	PRIME KEY	<p>This occurs when attempting to add a prime, but the directory number supplied exists, and does not exist as a primeless list.</p> <p>This error is also given if the directory number supplied (when adding a prime) does not exist, but conflicts with an existing system access code.</p>
E23	REVIEW	<p>This is given in Review mode, when the directory number supplied does not exist, or is in conflict with an existing system access code.</p>
E24	REVIEW	<p>This is given in Review mode, when the directory number supplied exists, but not as either a prime line access code or the access code for a primeless appearance list. This error indicates in the first three digits of the SOURCE display who the actual owner is.</p> <p>If the first digit is 0:</p> <ul style="list-style-type: none"> -000 - 135 equipment numbers 1 to 136 -136 - 147 Trunk Group numbers 1 to 12 -148 - 159 Hunt Group numbers 1 to 12 -160 - 255 equipment numbers 161 to 256 <p>If the first digit is a 1:</p> <ul style="list-style-type: none"> 000 - 063 service routines 1 to 64 (features)
E25	LISTED NUMBER	<p>An attempt has been made to change the DN of a Prime Key, but the new directory number (listed number) is in use or is in conflict with an existing access code. The new listed number for a Prime Key must be unique, and cannot be that of a primeless list even.</p>
E26	TRUNK EQPT NUMBER	<p>The equipment number entered (after pressing TRUNK EQPT NUMBER) is not that of a defined CO trunk or Dial-In trunk. The equipment number entered here must have been defined in Standard Programming as a trunk. Also, if in Review mode, this error means that the equipment number entered (after pressing TRUNK EQPT NUMBER) has not been used for either a DTS or private line key.</p>
E27		<p>The trunk is currently assigned to a DTS appearance list. An attempt has been made to use it for a private line key.</p>
E28		<p>An attempt has been made to assign a port for call announce use but the port is currently programmed for another function. The call announce port must be dedicated to the call announce function.</p>

TABLE 3-6 (CONT'D)
EXTENDED PROGRAMMING ERROR CODES - SUPERSET PROGRAMMING

Error Code	Key Involved	Explanation
E28	ANNOUNCE EQPT NUMBER	Attempting to assign an equipment number as a Call Announce Port when other equipment numbers previously programmed for that slot identify the slot as other than a Line card.
E30		An attempt has been made to delete a Prime Key (this is equivalent to deleting the set) and a Non-Prime Key on the set was defined. Before a set can be deleted, all Non-Prime keys must be undefined (deleted).
E31		An attempt has been made to define a Non-Prime Key when the prime for the equipment number has not yet been defined (the set itself has not been defined). The Prime Key must be the first key defined for a set.
E32	NEW SET EQPT NUMBER	When attempting to move a set the equipment number specified cannot be moved as it is not programmed as a SUPERSET.
E33	NEW SET EQPT NUMBER	When attempting to move a set to a new equipment number that has been programmed already.
E33	NEW SET EQPT	Attempting to move a SUPERSET to an equipment number when other equipment numbers previously programmed for that slot identify the slot as other than a SUPERSET Line card.
E40		A Prime Key is being added, and the listed number is the same as an existing primeless list. This can normally be done, but in this case the primeless list is not idle, so the addition of the prime cannot be performed.
E41		Addition of a key line appearance is attempted, but cannot be performed because the listed number is not idle. Or, addition of a DTS or private line was attempted, but cannot be performed because the trunk chosen for the key is not idle.
E42		An attempt has been made to delete a Prime Key, but the listed number is not completely idle. Note: All multiple call appearances of a prime must be idle if the prime is to be deleted, i.e., when a multiple call appearance 'somewhere' is busy it will prevent prime deletion although the prime appears idle. When this happens, use the REVIEW mode to find where all the appearances are, then delete each individually. The busy one will cause an error.

TABLE 3-6 (CONT'D)
EXTENDED PROGRAMMING ERROR CODES - SUPERSET PROGRAMMING

Error Code	Key Involved	Explanation
E43		An attempt was made to delete a prime, but the set has a message waiting, and deletion is not allowed.
E44		An attempt was made to delete a prime, but the set has a non-zero message register, and deletion is not allowed.
E45		An attempt was made to delete a Non-Prime Key, but the key was not idle, and deletion is not allowed. Also given when one of the Non-Prime keys is not idle when a deletion is attempted.
E50		An attempt was made to add a Prime Key, but 64 sets have already been defined.
E51		An attempt was made to add a Non-Prime which requires an internal system resource, of which all have been used. If any multiple call key, or an entire primeless key line list is deleted, one (1) resource will be freed.
E52		An attempt was made to add a Non-Prime Key which requires an internal system resource. This time, if either a complete DTS or private line list is deleted, one (1) internal resource will be freed.

Special set error numbers are arranged in groups, each numerical group having a general significance. The groups are:

- E0 - E9 No special significance.
- E10 - E19 The required parameters were not entered.
- E20 - E29 There are incompatibilities with the data base values and the parameter values being entered to define or change a key.
- E30 - E39 There are prerequisites to the operation being attempted which have not been satisfied.
- E40 - E49 The desired operation cannot be performed due to system activity involving the set or key selected.
- E50 - E59 The desired operation cannot be performed due to internal system limitations.

Note: An E5 error will be given when entering (or moving) a SUPERSET equipment number to a slot that would indicate more than eight slots programmed.

TABLE 3-7
SUPERVISOR FUNCTION ACCESS CODES

103

These codes assume the use of * as the Supervisor Function code (Feature Number 18). For Supervisor Function codes used in Traffic Measurement see Section MITL9105/9110-090-450-NA.

To cancel all call forwarding:

- a) Dial *1, or *11
- b) Dial #
- c) Press RELEASE button

To access an individual trunk:

- a) Dial *20
- b) Dial individual trunk access number (equipment number)
- c) Dial #
- d) Press RELEASE button

To force-release an individual trunk:

- a) Dial *20
- b) Dial individual trunk access number (equipment number)
- c) Dial # #
- d) Press RELEASE button

To make flexible night service assignments (Note 3):

- a) Dial *3
- b) Dial individual trunk access number (equipment number)
- c) Press NIGHT 1 or NIGHT 2
- d) Dial extension number
- e) Press RELEASE button

To cancel all system callbacks:

- a) Dial *4
- b) Dial #
- c) Press RELEASE button

To set the clock time:

- a) Dial *5
- b) Dial time (2-digit hour plus 2-digit minutes)
- c) Dial * for p.m., otherwise a.m.
- d) Press RELEASE button

To make Trunk Group supervisor access only:

- a) Dial *6
- b) Dial Trunk Group (1 through 10)
- c) Dial *
- d) Press RELEASE button

To make Trunk Group extension and supervisor access:

- a) Dial *6
- b) Dial trunk group (1 through 10)
- c) Dial #
- d) Press RELEASE button

To change the Direct Inward System Access Code:

- a) Dial *7
- b) Dial DISA code
- c) Press RELEASE button

To cancel a minor alarm (Note 1):

- a) Dial *8
- b) Dial #
- c) Press RELEASE button

To busy out an individual trunk (Note 3):

- a) Dial *9
- b) Dial individual access number (equipment number)
- c) Dial *
- d) Press RELEASE button

To de-busy an individual trunk (Note 3):

- a) Dial *9
- b) Dial individual trunk access number (equipment number)
- c) Dial #
- d) Press RELEASE button

To change the status of all occupied clean rooms to occupied and needs cleaning:

- a) Dial *10
- b) Dial *
- c) Press RELEASE button

To change the status of all occupied rooms in the need of cleaning to occupied clean:

- a) Dial *10
- b) Dial #
- c) Press RELEASE button

TABLE 3-7 (CONT'D)
SUPERVISOR FUNCTION ACCESS CODES

<p>To set up call forwarding:</p> <ol style="list-style-type: none"> Dial *11nnn, where nnn is the extension number of the forwarding extension Dial call forwarding code (1-4) Dial mmm, where mmm is the number to which the calls are to be forwarded Press RELEASE button 	<p>To purge and ignore the printer (Note 3):</p> <ol style="list-style-type: none"> Dial *14 00 Press RELEASE button
<p>To cancel call forwarding for an extension:</p> <ol style="list-style-type: none"> Dial *11nnn, where nnn is the extension number of the forwarding extension Dial # Press RELEASE button 	<p>To enable the printer (Note 3):</p> <ol style="list-style-type: none"> Dial *14 # Press RELEASE button
<p>To display call forwarding set for an extension:</p> <ol style="list-style-type: none"> Dial *11nnn, where nnn is the extension number of the forwarding extension Press RELEASE button 	<p>To change the date:</p> <ol style="list-style-type: none"> Dial *15 and 3- or 4-digit date (1- or 2-digit month, 2-digit day) Press RELEASE button
<p>To cancel all call forwarding:</p> <ol style="list-style-type: none"> Dial *1# or *11# Press RELEASE button 	<p>To print the room register audit (Notes 2 & 3):</p> <ol style="list-style-type: none"> Dial *16 Press RELEASE button
<p>To busy out an extension (Note 3):</p> <ol style="list-style-type: none"> Dial *12nnn, where nnn is the number of the extension to be busied out Dial * Press RELEASE button 	<p>To change the system identity (Note 3):</p> <ol style="list-style-type: none"> Dial *17nnn (1- to 3-digit ID, 0-999) Press RELEASE button
<p>To de-busy an extension (Note 3):</p> <ol style="list-style-type: none"> Dial *12nnn, where nnn is the number of the extension to be de-busied Dial # Press RELEASE button 	<p>To display current system identity:</p> <ol style="list-style-type: none"> Dial *17 Press RELEASE button
<p>To suspend the printer (Note 3):</p> <ol style="list-style-type: none"> Dial *14* Press RELEASE button 	<p>To print the "room status" audit (Note 2):</p> <ol style="list-style-type: none"> Dial *18 Press RELEASE button
	<p>To print stored customer data (Note 4):</p> <ol style="list-style-type: none"> Dial *19 + n, where n is: <ol style="list-style-type: none"> 0 A complete print (Note 5) 1 System Options, Feature Access Codes, Classes of Service, Hunt Groups and Extensions 2 Trunk and Trunk Group Data 3 Special Set Data 4 Toll Control Data 5 Speed Call Data 6 Automatic Route Selection Data * System-Wide Data (Note 6) Press RELEASE button

TABLE 3-7 (CONT'D)
SUPERVISOR FUNCTION ACCESS CODES

Notes

1. The errors will be sequentially stacked in the memory and may be recalled sequentially (most recent first) by repeating the above procedure.
2. Printer starts after RELEASE button is pressed.
3. Requires system option programming.
4. The customer must have programming access to the features in order to request a print-out.
5. This prints all sections provided the customer has programming access to the features.
6. This will print only the system-wide speed call tables and the system special set messages.

<p>To print the room number after each (Notes 1 & 2)</p> <p>a) Dial *18 b) Press RELEASE button</p>	<p>To display call forwarding call in extension</p> <p>a) Dial *17 b) Press RELEASE button</p>
<p>To change the system quantity (Note 3)</p> <p>a) Dial *19 b) Press RELEASE button</p>	<p>To cancel all call forwarding</p> <p>a) Dial *16 b) Press RELEASE button</p>
<p>To print the room number after each (Note 2)</p> <p>a) Dial *12 b) Press RELEASE button</p>	<p>To display call forwarding (Note 3)</p> <p>a) Dial *15 b) Press RELEASE button</p>
<p>To print stored customer data (Note 4)</p> <p>a) Dial *11 b) Press RELEASE button</p>	<p>To be busy in extension (Note 5)</p> <p>a) Dial *14 b) Press RELEASE button</p>
<p>0 A complete list (Note 6)</p> <p>1 System Control Feature Access Codes</p> <p>2 Control Data</p> <p>3 Toll Control Data</p> <p>4 Speed Control Data</p> <p>5 Automatic Note Selection Data</p> <p>6 System-Wide Data (Note 5)</p> <p>b) Press RELEASE button</p>	<p>To suspend the printer (Note 7)</p> <p>a) Dial *13 b) Press RELEASE button</p>

TABLE 3-8
MAINTENANCE FUNCTION ACCESS CODES (NOTE 1)

To select any of the functions, the access code assigned for the maintenance function must be dialed (Feature Number 19). The code 555 is used in the following part for the maintenance code. This may be dialed from the test line or console.

Clear all errors:	To initiate system dump (from console):
a) Dial 555 + 1	a) Dial 555 + 7
Direct trunk or station access:	b) Dial *14#
a) Dial 555 + 20	c) Press RELEASE button
b) Dial individual equipment number (3-digit equipment number for trunk or station)	To suspend printer (Note 3):
Busy out of a receiver:	a) Dial 555 + 8 + * (or 1), or
a) Dial 555 + 3	b) Dial *14* console only
b) Dial equipment number of receiver	To enable printer (Note 3):
Busy out of a speech path:	a) Dial 555 + 8 + * (or 2), test line
a) Dial 555 + 33	b) Dial *14# console only
b) Dial speech path number (01-31)	c) Press RELEASE button
De-busy a receiver:	To purge and ignore printer (Note 3):
a) Dial 555 + 4	a) Dial 555 + 8 + 00, test line
b) Dial equipment number of receiver	b) Dial *1400 console only
De-busy a speech path:	c) Press RELEASE button
a) Dial 555 + 43	To print stored Customer Data:
b) Dial speech path number (01-31)	a) Dial 555 + 9 + n, where n is:
Initialize card slot:	0 A complete print (Note 4)
a) Dial 555 + 5	1 System Options, Feature Access Codes, Classes of Service, Hunt Groups and Extensions
b) Dial card slot number (01-17, 31-42)	2 Trunk and Trunk Group Data
System reset (Notes 2 and 3):	3 Special Set Data
a) Dial 555 + 6	4 Toll Control Data
To initiate system dump (from test line):	5 Speed Call Data
a) Dial 555 + 7 and hang up	6 Automatic Route Selection Data
b) Go off-hook	* System-Wide Data (Note 5)
c) Dial 555 + 8 + # (or 2)	b) Press RELEASE button

Notes:

- For Traffic Measurement Access Codes see MITL9105/9110-090-450-NA.
- The thumbwheel switches on the Tone Control card should be set to XXYX, where X = any digit 0 - 9 and Y cannot be the digit 7.
- Requires System Option Programming.
- This prints all sections.
- This will print only the system-wide speed call tables and the system special set messages.

TABLE 3-9
SUPERVISOR FUNCTION CODES

To specify the maximum MTTA for each Agent Group, and at the same time the overflow destination for all incoming calls when the MTTA exceeds this maximum:

Dial *246
Dial Agent Group Access Code
Dial maximum time to answer, in seconds
Dial overflow Access Code (Agent/Recording Group, Supervisor)
Dial * to enter another Agent Group number or press the RELEASE button.

To display the current maximum time to answer and overflow code:

Dial *246
Dial Agent Group Access Code
Dial #
Press the RELEASE button to terminate display.

To specify the after-call work time applicable to all Agents in each Agent Group:

Dial *245
Dial Agent Group Access Code
Dial work time, in 2-digit seconds
Dial * to enter another Agent Group number or
Press the RELEASE button when finished.

To program a RAD:

Dial *230
Dial the RAD equipment number
Dial * to proceed to the next equipment
Press the RELEASE button.

To program a RAC:

Dial *231
Dial the RAC equipment number
Dial * to proceed to the next equipment
Press the RELEASE button.

To delete a RAD:

Dial *230
Dial the RAD equipment number
Dial #
Press the RELEASE button.

TABLE 3-9 (CONT'D)
SUPERVISOR FUNCTION CODES

To delete a RAC:

Dial *231
Dial the RAC equipment number
Dial #
Press the RELEASE button.

To review all defined RADs/RACs:

Dial *232* - the first RAD/RAC equipment number programmed will appear in the SOURCE display in the left corner and a 0 in the right corner to indicate a RAD or 1 in the right corner to indicate a RAC
Dial * to advance to next RAD/RAC or press the RELEASE button to terminate.

To record a message on the RAC:

Dial *240
Dial RAC equipment number
Dial *
Supervisor waits until a 50 msec 'beep' is heard
Supervisor speaks message (up to 8 seconds in duration) into handset
Press the RELEASE button when finished.

To playback a message from a RAC:

Dial *241
Dial RAC equipment number
Dial *
Message will be heard with handset, otherwise busy tone will be heard if the recording is currently in use
Press the RELEASE button to terminate.

To specify the length of the message:

Dial *242
Dial the Recording Group Access Code
Dial the recording duration, in 2-digit seconds.

To specify the recordings and delay times for an Agent Group:

Dial *243
Dial Agent Group Access Code
Dial recording number (1-4)
Dial Access Code
Dial time delay, in 2-digit seconds
Dial * to enter another recording number or
Press the RELEASE button.

TABLE 3-9 (CONTD)
SUPERVISOR FUNCTION CODES

To review recording assignments:

Dial *244
Dial Agent Group Access Code
Dial recording number (1-4)
Dial * to review another recording assignment or
Press the RELEASE button.

To delete all data associated with an Agent Group (maximum MTTA, overflow specification, Recording Group and delay time assignments):

Dial *243
Dial Agent Group Access Code
Dial #
Press the RELEASE button.

To define which Recording Group a DID Intercept will be routed to:

Dial *233
Dial Recording Group Access Code
Press the RELEASE button.

To delete DID intercept routing:

Dial *233
Dial #
Press the RELEASE button.

To define which Recording Group an Automatic Wake-Up will be routed to:

Dial *234
Dial Recording Group Access Code
Press the RELEASE button.

To delete which Recording Group an Automatic Wake-Up will be routed to:

Dial *234
Dial #
Press the RELEASE button.

To examine the current status of an Agent Group:

Dial *247
Dial Agent Group Access Code
Press the RELEASE button to terminate.

**TABLE 3-10
SYSTEM TIME-OUT INFORMATION**

R1

Description	Time-Out
Supervisor Timed Recall (Don't Answer)	10 s, 20 s, 30 s, or 40 s
Supervisor Timed Recall (Camp-On)	20 s, 30 s, or 40 s
Supervisor Timed Recall (Hold)	20 s, 30 s, or 40 s
Automatic Night Switching	20 s, 30 s, or 40 s
Dial Tone Time-Out	15 s
Interdigit Time-Out (Extensions)	15 s
Interdigit Time-Out (Trunks)	10 s
Lockout Time-Out	45 s
Callback Clear Time-Out	8 hours
Callback Don't Answer Reset	6 rings
Call Park Recall	2, 3 or 4 minutes
Call Hold Recall	2, 3 or 4 minutes
Call Forwarding - Don't Answer Time-Out	10 s, 20 s, 30 s, or 40 s
Call Forwarding Busy - Don't Answer Time-Out	10 s, 20 s, 30 s, or 40 s
Switchhook Flash	Min. 200 ms Max. 0.7 s, 0.9 s, 1.1 s or 1.5 s
Ringing Time-Out	5 minutes, 1 minute programmable
Automatic Wake-Up Ringing	6 rings, 3 s each
Automatic Wake-Up Attempts	3 at 5 minute intervals

APPENDIX 1

MITEL ACTION PROCEDURES

GENERAL

- A1.01** Task-oriented functions in this Section are implemented using MITEL Action Procedures (MAPs).
- A1.02** A MAP is a step-by-step procedure using a flow chart principle, written and illustrated where necessary to a level of detail that allows both experienced and inexperienced personnel to carry out the tasks detailed. A MAP contains two levels of information as follows:
- (a) For experienced personnel, a series of steps (level one) each numbered (n) and annotated with minimal information.
 - (b) For inexperienced personnel, each step referred to in (a) above is amplified by a connected series of numbered substeps (nA) (level two).
- A1.03** A typical example of a MAP is shown in Figure A1-1, with the two levels detailed.

MAP SYMBOLS


- A1.04** There are four basic symbol shapes which may be used in a MAP, and are defined as follows.
- A1.05 AND Block:** Used to indicate a level one step that must be performed. Consists of a square with the word AND centered in the block.
- A1.06 OR Block:** Used to indicate a choice of level one steps, one of which must be performed. Consists of a rectangle, with the text centered in the block, and the word OR appearing between the alternative operations.
- A1.07** The rectangle is also used to border instructions which imply that the operator must perform a task outside the scope of the MAP. The text is centered in the rectangle.
- A1.08 DECISION Block:** Used to indicate a decision within the level one steps which must be made. The symbol is based on a hexagon with the top and bottom sides extended. Decision text is centered in the symbol.
- A1.09 START/FINISH/JUMP TO Block:** Used to indicate the start and finish of a MAP. Also used to indicate "jump to" points within the MAP, for example "go to (n)" or "from (n)" or "return to (n)". The

ANSWER DID TRUNK CALL

MAP215-152

Issue 1, January 03

Sheet 1 of 2



M110

Figure A1-1 Typical MAP Page

symbol is a rectangle with semicircular ends. Text is centered in the symbol.

THE OPERATOR'S USE OF MAPS

Experienced Operator

A1.10 For the experienced operator to complete a task using a MAP, reference to the sequential short form level one step is usually all that is necessary. Using Figure A1-1 as an example, the experienced operator would proceed as follows.

A1.11 At (1) the operator makes a decision based on the information within the block. If the answer is YES, the operator must proceed to a different MAP. If the answer is NO, the operator is faced with another decision at block (2).

A1.12 At (2) if the decision is NO, there is no requirement to proceed further and the test is abandoned. This naturally results in a FINISH block. If the decision is YES, the operator proceeds to (3) and (4) in succession, i.e., dials the DID station number and completes the call to the check extension.

A1.13 The description of the instructions, carried out in A1.05 and A1.06 have assumed the level of competence of the operator, is such that short form level one steps contain sufficient information, and therefore, the operator reads only the center column of the MAP, top to bottom of the page.

A1.14 Using Figure A1-1 as an example, the path followed should be:

- (a) At (1) and (2), make the decisions called for at these steps as before.
- (b) At step (3), dial the DID station number by performing substeps (3A), (3B) and (3C).

TOOLS, TEST EQUIPMENT AND SPECIAL INSTRUCTIONS

A1.15 Any tools, test equipment or special instructions that the operator requires or needs to know are stated on the first page of each MAP. If the MAP is long, and contains a number of sub-procedures, these are listed in synopsis form on the first page.

APPENDIX 2

SYSTEM PROGRAMMING PROCEDURES

GENERAL

A2.01 This Appendix details the preferred order in which the SX-100/SX-200 system should be programmed for features and options required by the customer. This Appendix also includes procedures for programming Multi-Digit Toll Control, Speed Call and Automatic Route Selection.

A2.02 Table A2-1 details the order of the standard system programming procedures. Table A2-2 details the order of the Multi-Digit Toll Control programming procedures. Table A2-3 details the order of Speed Call programming of the system. Table A2-4 details the order of Route Selection programming of the system. Table A2-5 lists all SUPERSET 4 programming MAPs.

TABLE A2-1
STANDARD PROGRAMMING

Step	Title	MAP
1	System Programming	210-201
2	Select Programming Options	210-202
3	Program System Options	210-203
4	Program COS Options	210-204
5	Assign Feature Access Codes	210-205
6	Program Extensions	210-206
7	Program Extension Hunt Groups	210-207
8	Program Non-Dial-In Trunks	210-208
9	Program Dial-In Trunks	210-209
10	Program DID Trunks	210-210
11	Program Trunk Groups	210-211
12	Range Programming for Extensions	210-212
13	Terminating Standard Programming Mode	210-213

**TABLE A2-2
MULTI DIGIT TOLL CONTROL**

Order	Option	MAP No.
1	Selection of Extended Programming	210-221
2	Absorb Plan	210-222
3	Control Plan	210-223
4	Trunk Group Class of Restriction	210-224
5	Restriction Tables	210-225
6	Add an Entry	210-226
7	Displaying Sequential Entries	210-227
8	Search for an Entry	210-228
9	Delete an Entry	210-229
10	Terminating Programming	210-284

**TABLE A2-3
SPEED CALL**

Order	Option	MAP No.
1	Selection of Extended Programming	210-221
2	Programming Personal Tables	210-242
3	Convert Table from Personal to Common Use	210-243
4	Terminating Programming	210-284

**TABLE A2-4
AUTOMATIC ROUTE SELECTION**

Order	Option	MAP No.
1	Code Table Quantity Selection or Change	210-250
2	Area Code Table Programming	210-251
3	Review Area Code Table Programming	210-252
4	Delete an Area Code Table	210-253
5	Area Code/Office Code Programming	210-254
6	Review or Delete Part or All Area Code/Office Code	210-255
7	Program Modify Digits	210-256
8	To Review or Delete Modify Digit Tables	210-257
9	Route Table Programming	210-258
10	To Review or Delete a Route Table	210-259
11	Review or Delete Routes	210-260
12	Terminate Programming	210-284

**TABLE A2-5
SUPERSET PROGRAMMING**

Order	Option	MAP No.
1	Program a Prime Key	210-270
2	Program a Non-Prime Key	210-271
3	Delete a Non-Prime Key	210-272
4	Delete a Prime Key	210-273
5	Changing Any Key	210-274
6	Moving a SUPERSET 4	210-275
7	Review SUPERSET Programming	210-276

Button Definition

A2.03 For a description of buttons in each programming mode consult Table A2-6.

**TABLE A2-6
BUTTON DESCRIPTIONS**

Feature	Practice
Standard Programming	MITL9105/9110-090-315-NA
Multi Digit Toll Control	MITL9105/9110-090-315-NA MITL9105/9110-090-212-NA
Speed Call	MITL9105/9110-090-315-NA MITL9105/9110-090-220-NA
Automatic Route Selection	MITL9105/9110-090-315-NA MITL9105/9110-090-213-NA
SUPERSET 4	MITL9105/9110-090-315-NA

Programming Overlays

A2.04 The appropriate programming overlay must be used to program each feature. To ensure using the correct overlay see Table A2-7.

**TABLE A2-7
PROGRAMMING OVERLAYS**

Feature	Refer to Figure
Standard Programming	Figure A2-1
Multi Digit Toll Control	Figure A2-2
Speed Call	Figure A2-2
Automatic Route Selection	Figure A2-3
SUPERSET 4	Figure A2-4

**PROGRAMMING CONSOLE OVERLAY
(LAMP TEST LED LIT)**

LAMP TEST	RANGE	OPTION	COS DEFINE	FEATURE	EXTN	TRUNK	HUNT GROUP	TRUNK GROUP	CANCEL
--------------	-------	--------	---------------	---------	------	-------	---------------	----------------	--------

TYPE	LDN NMBR	DAY NUMBER	NIGHT 1	NIGHT 2	I/C	OVFLO GROUP	ACCESS CODE	ADD	ENTER
------	-------------	---------------	------------	------------	-----	----------------	----------------	-----	-------

EQPT NUMBER	EXTN NMBR	COS NUMBER	TOLL DENY	BUSY LAMP NMBR	PICKUP GROUP	CONFIRM	DELETE	NEXT
----------------	--------------	---------------	--------------	----------------------	-----------------	---------	--------	------

X5875A

Figure A2-1 Standard Programming Overlay

EXTENDED PROGRAMMING OVERLAY
TOLL CONTROL AND SPEED CALL
(LAMP TEST LED FLASHING)

LAMP TEST	CONFIG	TOLL CONTROL	SPEED CALL	CANCEL		
DENY TOLL REV	TRUNK GROUP	ABSORB PLAN	CONTROL PLAN	TABLE	EQPT. NUMBER	ACCESS NUMBER REDIAL
COR NUMBER	BASIC COND	DISPLAY ENTRY	ABSORB REPEAT	ABSORB UNLOCK	CONFIRM DELETE NEXT	

X5875B

Figure A2-2 Extended Programming Overlay


EXTENDED PROGRAMMING OVERLAY
AUTOMATIC ROUTE SELECTION
(LAMP TEST LED FLASHING)

LAMP TEST	CONFIG	ARS					CANCEL		
TABLE QTY	CODE TABLE	AREA CODE	ROUTE TABLE	OFFICE CODE	SCHED A	SCHED B	SCHED C	ADD	ENTER
CHOICE NUMBER	ROUTE NMBR	TRUNK GROUP	MODIFY DIGITS	DIGITS DELETE	DIGITS ADD	LOCAL AREA			

X5875C

Figure A2-3 ARS Overlay

SYSTEM PROGRAMMING
MAP210-201
Issue 1, September 1983
Sheet 1 of 4




SYSTEM PROGRAMMING

MAP210- 201

Issue 1, September 1983

Sheet 2 of 4




SYSTEM PROGRAMMING

MAP210-201

Issue 1, September 1983

Sheet 3 of 4



SYSTEM PROGRAMMING
MAP210- 201
Issue 1, September 1983
Sheet 4 of 4

TABLE 201-1
STANDARD PROGRAMMING

Step	Title	MAP
1	Select Programming Mode	210-202
2	Program System Options	210-203
3	Program COS Options	210-204
4	Assign Feature Access Codes	210-205
5	Program Extensions	210-206
6	Program Extension Hunt Groups	210-207
7	Program Non-Dial-In Trunks	210-208
8	Program Dial-In Trunks	210-209
9	Program DID Trunks	210-210
10	Program Trunk Groups	210-211
11	Range Programming	210-212
12	Terminate Programming Mode	210-213



SELECT PROGRAMMING MODE

MAP210-202

Issue 1, September 1983

Sheet 1 of 3

CAUTION

Equipment must be in nonprogram mode at start. See MAP210-201 Step (2).

NOTE

To use Programming Security Access Code the following criteria must apply: Feature 29 (MAP210-205) is programmed with the code

NOTE

When using the maintenance console, plug it in to the maintenance connector on the cabinet maintenance panel.

PLACE CONSOLE IN PROGRAMMING MODE

- (3A) Place programming console overlay over console faceplate
- (3B) Set thumbwheel switches on Tone Control card (card position 18, yellow) to appropriate position (Table 202-1)
- (3C) Press LAMP TEST button LAMP TEST lamp lit. The second LED on the RAM-COS card will be lit for the duration of programming. If the system is not idle an E7 error will be presented





TABLE 202-1

CODE	CONSOLE
7770	Maintenance Supervisor No. 1
7771	Supervisor No. 2
7772	

SELECT PROGRAMMING MODE
MAP210- 202
Issue 1, September 1983
Sheet 2 of 3



SELECT PROGRAMMING MODE

MAP210-202

Issue 1, September 1983


Sheet 3 of 3

TABLE 202-2

NUMBER	DATA BLOCK INFORMATION
1	All Standard Programming and Customer Data
3	ARS
4	Toll Control
5	Station Information (Msgs/Register, Room Status)
6	Alarm Call
7	System Speed Call
8	SUPERSET Speed Call

(10A) Press the NEXT button
* LAMP TEST LED flashes

(11A) Go to relevant programming
MAPs as per paragraph A2.02.



PROGRAM SYSTEM OPTIONS

MAP210-203

Issue 1, September 1983

Sheet 1 of 8

NOTES


- (1) All entries are made from the console dial pad.
 (2) OPTION lamp lit throughout procedure.
 (3) A display of ED indicates that an incorrect key had been pressed. Press the button specified.


SYNOPSIS

Select option mode.
 Enter required system codes, (100-339)
 Press ADD or DELETE buttons.
 Press ENTER button.

SELECT SYSTEM OPTION

- (3A) Press OPTION button
 * OPTION lamp lit
 * SOURCE display shows 100 and 0 if no options enabled, or the number of the first option enabled and 1.
 (3B) Dial option number required (100-393) (Figure 203-1).
 * SOURCE display shows number dialed and 1 if the option is enabled or 0 if the option is not enabled





OPTION

SYSTEM OPTIONS

OPTION NAME	OPTION NUMBER	DIAL OPTION NUMBER (100-339)	ADD	OPTION NAME	OPTION NUMBER	DIAL OPTION NUMBER (100-339)	ADD
ATTENDANT RELATED OPTIONS							
ATTENDANT BELL OFF BUTTON ENABLE	100	/		ATTENDANT TIMED RECALL - DORF ANSWER 10S	125	0	
ATTENDANT BOTH BUTTON ENABLE	101	/		ATTENDANT TIMED RECALL - DORF ANSWER 20S	126	0	
ATTENDANT BOTH MORE STANDARD	102	0		ATTENDANT TIMED RECALL - DORF ANSWER 40S	127	0	
ATTENDANT BUST OVERRIDE	103	/		ATTENDANT TIMED RECALL - HOLD 20S	128	0	
ATTENDANT CALL BACK BUTTON ENABLE	104	0		ATTENDANT TIMED RECALL - HOLD 40S	129	/	
ATTENDANT CALL-BLOCK ENABLE HOLD BUTTON 4)	105	0		ATTENDANT TRUNK BUSY OUT ENABLE	130	/	
ATTENDANT CAMP ON	106	/		RESERVED	131	0	
ATTENDANT CD TRUNK-CO TRUNK CONNECT ENABLE	107	/		RESERVED	132	0	
ATTENDANT CD TRUNK-NON CD TRUNK CONNECT ENABLE	108	/		DD TO NON-CD TRUNK VIA ATTENDANT INHIBIT	133	0	
ATTENDANT NON CD TRUNK-NON CD TRUNK CONNECT ENABLE	109	/		END OF DIAL SIGNAL FOR OUTGOING TRUNKS (M)	134	/	
ATTENDANT CONFERENCE ENABLE	110	/		INTERCEPT TO ATT - DID DUAL - IN CCSA VACANT/ILLEGAL	135	0	
ATTENDANT DISA CODE SET-UP ENABLE	111	0		INTERCEPT TO ATT - ILEGAL ACCESS	136	0	
ATTENDANT DO NOT DISTURB AND MESSAGE WAITING DISPLAY	112	/		INTERCEPT TO ATT - VACANT NUMBER	137	0	
ATTENDANT GUEST ROOM BUTTON ENABLE	113	0		INTERCEPT TO ATT - DO NOT DISTURB	138		
RESERVED	114	0		RESERVED	139		
ATTENDANT LOCK OUT ALARM ENABLE	115	0		RESERVED	140		
ATTENDANT NEW CALL TONE ENABLE	116	/		RESERVED	141		
ATTENDANT PAGE BUTTON ENABLE	117	/		RESERVED	142		
ATTENDANT PRINTER CONTROL ENABLE	118	/		RESERVED	143		
ATTENDANT ROOM STATUS BUTTON ENABLE & DISPLAY ENABLE	119	0		RESERVED	144		
ATTENDANT SERIAL CALL	120	/		RESERVED	145		
ATTENDANT SERIAL CALL OVERRIDE FLASH BUTTON ENABLE	121	0		RESERVED	146		
ATTENDANT STATION BUSY OUT ENABLE	122	0		RESERVED	147		
ATTENDANT TIMED RECALL - CAMP ON 20S	123	0		RESERVED	148		
ATTENDANT TIMED RECALL - CAMP ON 40S	124	/		RESERVED	149		
				SYSTEM RELATED OPTIONS			
				24 HOUR CLOCK	150	0	
				DATA DEMULTIPLEX ENABLE	151	0	
				RESERVED	152	/	


Fig. 203-1

SYSTEM OPTIONS		OPTION		ADD	
OPTION NUMBER	OPTION NAME	OPTION NUMBER	OPTION NAME	DIAL OPTION NUMBER (100-330)	DIAL OPTION NUMBER (133-330)
152	DIGIT TRANSLATION PLAN 1	183	CANNOT DIAL TRUNK AFTER FLASH		
154	DIGIT TRANSLATION PLAN 2	184	CANNOT DIAL TRUNK AFTER FLASH IF HOLDING ON IN CONFERENCE WITH TRUNK		
155	DIGIT TRANSLATION PLAN 3	185	DISCRIMINATING DIAL TONE		
158	IDENTIFIED TRUNK GROUP ENABLE	186	DISCRIMINATING RINGING		
159	INCOMING TO OUTGOING CALL FORWARD ENABLE	187	DO NOT DISTURB ENABLE		
160	INHIBIT AUTOMATIC SUPERVISION	188	EXTENSION HON - CO TRUNK TO TRUNK CONNECT ENABLE		
161	INHIBIT WAIT FOR DIAL TONE BS	189	FLASH TIMING = 7 SECONDS		
162	MUSIC ON HOLD DISABLE	190	FLASH TIMING = 8 SECONDS		
163	NIGHT BELL 3 WITH MIRROR ALARM ENABLE	191	FLASH TIMING = 11 SECONDS		
164	NIGHT SERVICE AUTOMATIC SWITCHING	192	MESSAGE REGISTRATION ENABLE		
165	NIGHT SERVICE TIMEOUT = 2SS	193	MESSAGE REGISTRATION COUNT ADDITIONAL SUPERVISIONS		
166	NIGHT SERVICE TIMEOUT = 4SS	194	MESSAGE REGISTRATION TIMER = 20 SECONDS		
167	REAROTE SYSTEM RESET - PROTECTION OUTSIDE RINGING TIMEOUT 1 MINUTE	195	MESSAGE REGISTRATION TIMER = 40 SECONDS		
168	SYSTEM ID ENABLE	196	MESSAGE REGISTRATION MULTIPLIER = 2 UNITS		
169	TRUNK RE-CALL PARTIAL WARRIT	197	MESSAGE REGISTRATION MULTIPLIER = 3 UNITS		
170	RESERVED	198	MESSAGE REGISTRATION MULTIPLIER = 4 UNITS		
171	STORE AND FORWARD	199	MESSAGE REGISTRATION SURCHARGE = 1 UNITS		
172	15 SEC EXTERNAL INTEROFF TIMEOUT	200	MESSAGE REGISTRATION SURCHARGE = 2 UNITS		
173	TRUNK ALARM ENABLE; NO SEIZE ACKNOWLEDGE	201	MESSAGE REGISTRATION SURCHARGE = 3 UNITS		
174	TRUNK ALARM ENABLE; NO RELEASE ACKNOWLEDGE	202	MESSAGE REGISTRATION SURCHARGE = 4 UNITS		
175	RESERVED	203	MESSAGE REGISTRATION SURCHARGE = 5 UNITS		
176	RESERVED	204	MESSAGE REGISTRATION SURCHARGE = 6 UNITS		
177	RESERVED	205	MESSAGE REGISTRATION SURCHARGE = 7 UNITS		
178	RESERVED	206	MESSAGE REGISTRATION SURCHARGE = 8 UNITS		
179	RESERVED	207	DISCRIMINATING RINGING - ALL CALLS		
	STATION RELATED OPTIONS	208	OUTGOING TRUNK CALL - BACK		
180	CAN FLASH IF TALKING TO A STATION	209	OUTGOING TRUNK CAMP ON		
181	CAN FLASH IF TALKING TO A INCOMING TRUNK	210	PARK AND CALL - HOLD RECALL - 2 MINUTES		
182	CAN FLASH IF TALKING TO A OUTGOING TRUNK	211	PARK AND CNL - HOLD RECALL - 4 MINUTES		



SYSTEM OPTIONS

OPTION



OPTION NUMBER	OPTION NAME	OPTION NUMBER	OPTION NAME	OPTION NUMBER	DIAL OPTION NUMBER (100-313)	OPTION NUMBER	DIAL OPTION NUMBER (100-313)
212	RAMZ PROGRAMMING ENABLE	212	AMS DIAL 0 TIMEOUT 10 SEC	241		241	
213	SINGLE DIGT DIALING ENABLE	213	AMS UNRESTRICTED OFFICE CODE ENABLE	242		242	
214	SINGLE DIGT DIALING TIME OUT - 3 S	214	RESERVED	243		243	
215	SINGLE DIGT DIALING TIME OUT - 5 S	215	RESERVED	244		244	
216	RESERVED	216	AUTOMATIC WAKE - UP ENABLE	245		245	
217	REPEATED CAMP ON BEEP - 5 SECONDS	217	AUTOMATIC WAKE - UP ALARM TO SUPERVISOR ENABLE	246		246	
218	REPEATED CAMP ON BEEP - 15 SECONDS	218	AUTOMATIC WAKE - UP MUSIC ON HOLD	247		247	
219	TAFAS AVAILABLE DURING DAY	219	AUTOMATIC WAKE - UP PRINT	248		248	
220	TRANSFER DIAL TONE	220	RESERVED	249		249	
221	RESERVED	221	RESERVED	250		250	
222	RESERVED	222	RESERVED	251		251	
223	RESERVED	223	RESERVED	252		252	
224	RESERVED	224	ADD LABEL	253		253	
225	RESERVED	225	RESERVED	254		254	
226	RESERVED	226	CALL FORWARDING - BUSY (SYSTEM DIAL IN THE TRUNK - 0534)	255		255	
227	RESERVED	227	CALL FORWARDING - DONT ANSWER 375, DND, DIAL - IN THE TL, CCSA	256		256	
228	RESERVED	228	CALL FORWARDING - DONT ANSWER TIMEOUT - 10 SECONDS	257		257	
229	RESERVED	229	CALL FORWARDING - DONT ANSWER TIMEOUT - 20 SECONDS	258		258	
230	ACCOUNT CODE ENABLE	230	CALL FORWARDING - DONT ANSWER TIMEOUT - 40 SECONDS	259		259	
231	VARIABLE ACCOUNT CODES	231	CONTROLLED OUTGOING RESTRICTION SET - UP	260		260	
232	ACCOUNT CODE LENGTH 4 DIGITS	232	CUSTOMER DATA PRINT OUT ENABLE	261		261	
233	RESERVED	233	CUSTOMER PROGRAMMING ENABLE	262		262	
234	ACCOUNT CODE LENGTH 8 DIGITS	234	CUSTOMER PROGRAMMING OF AFS ENABLE	263		263	
235	ACCOUNT CODE LENGTH 12 DIGITS	235	CUSTOMER PROGRAMMING OF COS DEFINITIONS ENABLE	264		264	
236	VARIABLE LENGTH ACCOUNT CODES	236	CUSTOMER PROGRAMMING OF EXTENDING ENABLE	265		265	
237	RESERVED	237	CUSTOMER PROGRAMMING OF FEATURES ENABLE	266		266	
238	AMS ENABLE	238	CUSTOMER PROGRAMMING OF 1800 GROUPS ENABLE	267		267	
239	AMS RETURN DIAL TONE	239		268		268	
240	AMS DIAL 0 TIMEOUT 5 SECONDS	240		269		269	

325
142

SYSTEM OPTIONS

OPTION NAME	OPTION NUMBER	DIAL OPTION NUMBER (000-319)	OPTION NAME	OPTION NUMBER	OPTION	ADD
CUSTOMER PROGRAMMING OF SPEED CALL EMU BEE	266		RESERVED	293		ADD
CUSTOMER PROGRAMMING OF SYSTEM OPTIONS ENABLE	267		RESERVED	294		
CUSTOMER PROGRAMMING OF TOLL CONTROL ENABLE	268		TRAFFIC MEASUREMENT AUDIOPRINT	295		
CUSTOMER PROGRAMMING OF TRUNK GROUPS ENABLE	269		TRAFFIC MEASUREMENT COMPACT REPORT	296		
CUSTOMER PROGRAMMING OF TRUNKS ENABLE	270		TRAFFIC MEASUREMENT CONSOLE FUNCTION ENABLE	297		
CUSTOMER RANGE PROGRAMMING ENABLE	271		TRAFFIC MEASUREMENT ENABLE	298		
CUSTOMER PROGRAMMING OF SUPERSET 4 ENABLE	272		TRAFFIC MEASUREMENT EXTREME VALUE MODE	299		
EXTERNAL CALL FORWARDING ENABLE	273		TRAFFIC MEASUREMENT FOLLING	300		
HANDS FREE ENABLE	274		RESERVED	301		
MESSAGE WAITING SET - UP (BELL)	275		RESERVED	302		
MESSAGE WAITING SET - UP (BAMP)	276		RESERVED	303		
SMR RECORD OUTGOING CALLS	277		RESERVED	304		
SMR RECORD INCOMING CALLS	278		RESERVED	305		
SMR RECORD ONLY INCOMING CO CALLS	279		RESERVED	306		
SMR RECORD MULTIPLEX	280		RESERVED	307		
SMR DROP INCOMPLETE OUTGOING CALLS	281		RESERVED	308		
SMR DROP CALLS OF LESS THAN 8 DIGITS	282		RESERVED	309		
SMR EXTENDED RECORD	283		PRINTER RELATED OPTIONS			
SMR INDICATE LONG CALLS	284		CONDENSED SMR PRINT ENABLE	310		
SMR OVERWRITE ENABLE	285		EXTENDED 710 - 3 PRINTER			
RESERVED	286		SMR PRINT ENABLE	311		
SPEED CALL ENABLE	287		MESSAGE REGISTER & MESSAGE WAITING CHANGE PRINT ENABLE	312		
SPEED CALL PROGRAMMING ENABLE	288		PRINTER CARRIAGE RETURN DELAY	313		
SPEED CALL CONFIDENTIAL NUMBER DISPLAY ENABLE	289		PRINTER TRANSMIT ADDITIONAL BELLS	314		
RESERVED	290		PRINTOUTS EXTRA LINE FEEDS (HOTEL/MOTEL ONLY)	315		
TOLL CONTROL - FIRST DIGIT	291		ROOM MESSAGE REGISTER ADRPT ENABLE	316		
TOLL CONTROL - NINETH DIGIT	292		ROOM STATUS ADRPT ENABLE	317		

SYSTEM OPTIONS

OPTION NUMBER	OPTION NAME	DIAL OPTION NUMBER 100 - 310	OPTION NUMBER	OPTION NAME	DIAL OPTION NUMBER 110 - 315
318	ZERO MESSAGE REGISTER AFTER ROOM REGISTER ALERT				
319	RESERVED				
320	RESERVED				
321	RESERVED				
322	RESERVED				
323	RESERVED				
324	RESERVED				
325	RESERVED				
326	RESERVED				
327	RESERVED				
328	RESERVED				
329	RESERVED				
SUPERSET RELATED OPTIONS					
330	SUPERSET DISCONNECT ALARM				
331	SUPERSET IMMEDIATE LINE SELECTION ENABLE				
332	SUPERSET LAST NUMBER REDIAL ENABLE				
333	SUPERSET AUTO HOLD DISABLE				
334	RESERVED				
335	RESERVED				
336	RESERVED				
337	RESERVED				
338	RESERVED				
339	RESERVED				

NOTES TO DELETE SYSTEM OPTIONS: OPTION, DIAL OPTION NUMBERS, DELETE


AFTER ALL REQUIRED OPTIONS HAVE BEEN REMOVED: ENTER

AFTER ALL OPTIONS ARE ADDED PRESS: ENTER


TO REVIEW SYSTEM OPTIONS: OPTION, NEXT, NEXT

INTEL

PROGRAM SYSTEM OPTIONS
MAP210- 203
Issue 1, September 1983
Sheet 7 of 8



PROGRAM SYSTEM OPTIONS
MAP210-203
Issue 1, September 1983
Sheet 8 of 8



PROGRAM COS OPTIONS

MAP210-204

Issue 1, September 1983


Sheet 1 of 8

NOTES

- (1) All entries are made from the console dial pad
 (2) COS DEFINE lamp remains lit through procedure
 (3) A display of EO indicates that an incorrect key was pressed; press key specified

SYNOPSIS

- Define COS group (1-16)
 Enter all option codes (33-120)
 Press ADD or DELETE keys
 Press ENTER key




SELECT COS PROGRAM

- (3A) Press COS DEFINE key
 * COS DEFINE lamp lit
 * SOURCE display shows current COS
 (3B) Dial Class-of-Service number to be defined (1-16)
 * DESTINATION display shows COS number dialed

PROGRAM COS OPTIONS
MAP210- 204
Issue 1, September 1983
Sheet 2 of 8

- (4A) Press OPTION key
- OPTION lamp lit
 - SOURCE display shows COS number dialed followed by 33 and 0 (no options assigned) or first option assigned to the COS followed by a 1.




PROGRAM COS OPTIONS

MAP210-204

Issue 1, September 1983

Sheet 3 of 8



SECTION MITL9105/9110-090-210-NA

SHORT NO. 302 14-2001
 EXT. 112544
 UNIT NUMBER 7 2001
 6 5 10-12

31-1001

MITEL																		
PRESS <input type="checkbox"/> COS DEFINE DIAL COS NUMBER 1-16 TO CHANGE ANY OPTION FOR A COS 1-16 PRESS <input type="checkbox"/> OPTION DIAL OPTION NUMBER 33-120 PRESS <input type="checkbox"/> ADD TO ENABLE OR PRESS <input type="checkbox"/> DELETE TO REMOVE																		
OPTION NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	OPTION NO.	OPTION NAME
33																	33	AUTOMATIC CALLBACK
34																	34	CALL FORWARDING - BUSY
35																	35	CALL FORWARDING - DON'T ANSWER
36																	36	CALL FORWARDING - FOLLOW ME
37																	37	CALL PARK
38																	38	NEVER A FORWARDER
39																	39	DIRECTED CALL PICKUP
40																	40	EXECUTIVE BUSY OVERRIDE
41																	41	DATA SECURITY
42																	42	STATION OVERRIDE SECURITY
43																	43	INWARD RESTRICTION CODE
44																	44	ORIGINATE ONLY
45																	45	RECEIVE ONLY
46																	46	FLASH DISABLE
47																	47	NEVER A CONSULTEE
48																	48	BROKERS CALL
49																	49	STATION CONFERENCE
50																	50	MEET ME CONFERENCE
51																	51	CAMP-ON
52																	52	DO NOT OVERFLOW
53																	53	PAGING ACCESS
54																	54	TAXES ACCESS
55																	55	HOLD PICKUP
56																	56	ACCOUNT CODE ACCESS
57																	57	MANUAL LINE
58																	58	CONTACT MONITOR
59																	59	NON-COS TRUNKS VIA SUPERVISOR INHIBIT
60																	60	COS TRUNKS VIA SUPERVISOR INHIBIT
61																	61	NO DIAL TONE
62																	62	FLASH FOR SUPERVISOR
63																	63	HUM STN-STN RESTRICT APPLIES
64																	64	MESSAGE REGISTER
65																	65	TRUNK GROUP 1 ACCESS
66																	66	TRUNK GROUP 2 ACCESS
67																	67	TRUNK GROUP 3 ACCESS
68																	68	TRUNK GROUP 4 ACCESS
69																	69	TRUNK GROUP 5 ACCESS
70																	70	TRUNK GROUP 6 ACCESS
71																	71	TRUNK GROUP 7 ACCESS
72																	72	TRUNK GROUP 8 ACCESS
73																	73	TRUNK GROUP 9 ACCESS
74																	74	TRUNK GROUP 10 ACCESS
75																	75	TRUNK GROUP 11 ACCESS
76																	76	TRUNK GROUP 12 ACCESS



CLASS OF SERVICE OPTIONS

PRESS DIAL COS NUMBER 1-18 PRESS DIAL OPTION NUMBER 20-120 PRESS TO ENABLE OR PRESS TO REMOVE


REPEAT FOR EACH OPTION IN THE COS

OPTION NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	OPTION NO.	OPTION NAME
77	1	1	1	1	1												77	MESSAGE WAITING APPLIES
78	1	1	1	1	1												78	NSOM DO NOT DISTURB ENABLE
79	1	1	1	1	1												79	CALL HOLD AND RETRIEVE ACCESS
80	1	1	1	1	1												80	NSOM STATUS APPLIES
81	1	1	1	1	1												81	CALL FORWARDING SYSTEM INHIBIT
82	1	1	1	1	1												82	ALARM CALL ENABLE
83	1	1	1	1	1												83	FORCED ACCOUNT CODE ENTRY
84	1	1	1	1	1												84	NO SWOR RECORD APPLIES
85	1	1	1	1	1												85	SPEED CALL TABLE 1A-7 ACCESS
86	1	1	1	1	1												86	SPEED CALL TABLE 2A-7 ACCESS
87	1	1	1	1	1												87	SPEED CALL TABLE 3A-7 ACCESS
88	1	1	1	1	1												88	SPEED CALL TABLE 7A-8 ACCESS
89	1	1	1	1	1												89	SPEED CALL TABLE 8A-10 ACCESS
90	1	1	1	1	1												90	SPEED CALL TABLE 11A-17 ACCESS
91	1	1	1	1	1												91	SPEED CALL TABLE 13A-14 ACCESS
92	1	1	1	1	1												92	SPEED CALL TABLE 15A-16 ACCESS
93	1	1	1	1	1												93	SPEED CALL TABLE 17A-18 ACCESS
94	0	0	0	0	0												94	CANNOT DIAL A TRUNK AFTER FLASHING
95	0	0	0	0	0												95	INCOMING TRUNK ROTARY DIAL ONLY
96	0	0	0	0	0												96	ARS RESTRICTED
97	1	1	1	1	1												97	EXTERNAL CALL FORWARDING ENABLE
98	0	0	0	0	0												98	TRANSFER WITH PRIVACY
99	1	1	1	1	1												99	HANDS - FREE STATION
100	1	1	1	1	1												100	ARS ALLOWED
101	0	0	0	0	0												101	EARTH GREENING BUTTON
102	1	1	1	1	1												102	CALL ANNOUNCE PORT
103	1	1	1	1	1												103	EXTENSION RESET
104	0	0	0	0	0												104	RESERVED
105	0	0	0	0	0												105	RESERVED
106	0	0	0	0	0												106	SUPERSET 4 SOB - ATTENDANT
107	0	0	0	0	0												107	REPEATED CAMP - ON BEEPS

TO COPY COS PRESS DIAL 1-18 SOURCE DIAL 1-18 DEST. PRESS

TO REVIEW THE OPTIONS WITHIN A COS DIAL COS NUMBER

NOTES YOU CANNOT CHANGE AN EXTENSION OR TRUNK IF THE EXTENSION OR TRUNK IS BUSY, HAS MESSAGE WAITING OR DO NOT DISTURB SET. IT ALSO CANNOT BE CHANGED UNLESS MESSAGE REGISTER IS CLEARED.



EXTENDED AUTO MESSAGES
 1001-012345
 1002-012345
 1003-012345
 1004-012345

1001

CLASS OF SERVICE OPTIONS

PRESS DIAL COS NUMBER 1-16 TO CHANGE ANY OPTION FOR A COS 1-16 PRESS DIAL OPTION NUMBER 10-120 PRESS TO ENABLE OR PRESS TO REMOVE


REPEAT FOR EACH OPTION IN THE COS

OPTION NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	OPTION NO.	OPTION NAME
108																	108	BACKGROUND MUSIC
109																	109	SUPERSET 4 SUB ATTENDANT MESSAGE PROGRAM
110																	110	SPECIAL DISA
111																	111	DIRECT TO ARS
112																	112	OFF PRESESE EXTENSION
113																	113	DISALLOW ARS SCHEDULE A
114																	114	DISALLOW ARS SCHEDULE B
115																	115	DISALLOW ARS SCHEDULE C
116																	116	ARS LIMITED ACCESS
117																	117	ACS AGENT
118																	118	ARS MOST EXPENSIVE ROUTE BEEP
119																	119	LOW GAIN COMPENSATION TUNING
120																	120	PRIVACY DISABLE

PRESS TO ENTER ALL INFORMATION IN THAT COS AFTER ALL OPTIONS IN THAT COS HAVE BEEN DEFINED

TO REVIEW THE OPTIONS WITHIN A COS

NOTES YOU CANNOT CHANGE AN EXTENSION OR TRUNK IF THE EXTENSION OR TRUNK IS BUSY, HAS MESSAGE WAITING OR DO NOT DISTURB SET. IT ALSO CANNOT BE CHANGED UNLESS MESSAGE REGISTER IS CLEARED.



1001


1001

PROGRAM COS OPTIONS

MAP210- 204

Issue 1, September 1983

Sheet 6 of 8

**REMOVE OPTION FROM COS**

(13A) Press OPTION key

(13B) Dial option code (33-120) to

- SOURCE display shows COS number, option code, and 1 (option active)


PROGRAM COS OPTIONS

MAP210-204


Issue 1, September 1983

Sheet 7 of 8

- [14A] Press DELETE key
 * DELETE lamp lit
 * SOURCE display shows COS number, option code, and 0 (option inactive)



PROGRAM COS OPTIONS
MAP210- 204
Issue 1, September 1983
Sheet 8 of 8



ASSIGN FEATURE ACCESS CODES

MAP210-205

Issue 1, September 1983


Sheet 1 of 5

NOTES

- (1) All entries are made from the console dial pad.
 (2) FEATURE lamp lit throughout procedure.
 (3) A display of EO indicates that an incorrect key was pressed, check procedure and press correct key.

SYNOPSIS

Enter feature number. (1-49)
 Assign or delete access code.
 Press ENTER key.
 Repeat for all required features.



SELECT FEATURE ACCESS CODE PROGRAM


- (3A) Press FEATURE key.
 * SOURCE display shows feature number and its assigned access code, or the feature number and ----, no access code assigned to the feature.
- (3B) Dial number of feature to be added or changed (Figure 205-1)
 * SOURCE display shows feature number and its assigned access code, or the feature number and ----, no access code assigned to the feature.
 * DESTINATION display shows feature number dialed.

ASSIGN FEATURE ACCESS CODES

MAP210- 205

Issue 1, September 1983

Sheet 2 of 5




ASSIGN FEATURE ACCESS CODES

MAP210-205


Issue 1, September 1983

Sheet 3 of 5



ASSIGN FEATURE ACCESS CODES
MAP210- 205
Issue 1, September 1983
Sheet 5 of 5

(11A) Press LAMP TEST key
• All lamps dark



PROGRAM EXTENSIONS

MAP210-206

Issue 1, September 1983


Sheet 1 of 11

NOTES

- (1) All entries are made from the console dial pad.
 (2) EXTN lamp lit throughout procedure.
 (3) A display of E0 indicates that an incorrect key has been pressed. Press the key specified in the MAP.
 (4) Refer to Figure 206-3 for an example of the form.

SYNOPSIS


Enter EXTN programming.
 Enter extension equipment number.
 Enter extension number.
 Enter COS number.
 Enter toll allow/deny or COR 1, 2, 3.
 Enter busy lamp position number.
 Enter pickup group number.
 Press ENTER key.



SELECT EXTENSION PROGRAM

- (3A) Press EXTN key
 • EXTN lamp lit

PROGRAM EXTENSIONS
MAP210- 206
Issue 1, September 1983
Sheet 2 of 11




PROGRAM EXTENSIONS

MAP210-206

Issue 1, September 1983

Sheet 3 of 11



SECTION MITL9105/9110-090-210-NA

HARDWARE POSITION NUMBER	PLUG 7					PLUG 9					PLUG 11					EXTENSION UNIT NO.	TRUNK UNIT NO. (4 TRUNK)	TRUNK UNIT NO. (2 TRUNK)						
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15				16	17	18			
161	169	177	185	193	201	209	217	225	233	241	249							1						
162	170	178	186	194	202	210	218	226	234	242	250							2	1	1				
163	171	179	187	195	203	211	219	227	235	243	251							3						
164	172	180	188	196	204	212	220	228	236	244	252							4	2					
165	173	181	189	197	205	213	221	229	237	245	253							5						
166	174	182	190	198	206	214	222	230	238	246	254							6	3	2				
167	175	183	191	199	207	215	223	231	239	247	255							7						
168	176	184	192	200	208	216	224	232	240	248	256							8	4					
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	CARD POSITION						
31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	SLOT NUMBER		
	PLUG 8					PLUG 10					PLUG 12													

SHELF 2 (SX-200 ONLY)

HARDWARE POSITION NUMBER	PLUG 1					PLUG 3					PLUG 5					EXTENSION UNIT NO.	TRUNK UNIT NO. (4 TRUNK)	TRUNK UNIT NO. (2 TRUNK)						
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15				16	17	18			
001	009	017	025	033	041	049	057	065	073	081	089	097	105	113				1						
002	010	018	026	034	042	050	058	066	074	082	090	098	106	114				2	1	1				
003	011	019	027	035	043	051	059	067	075	083	091	099	107	115				3						
004	012	020	028	036	044	052	060	068	076	084	092	100	108	116				4	2					
005	013	021	029	037	045	053	061	069	077	085	093	101	109	117				5						
006	014	022	030	038	046	054	062	070	078	086	094	102	110	118				6	3	2				
007	015	023	031	039	047	055	063	071	079	087	095	103	111	119				7						
008	016	024	032	040	048	056	064	072	080	088	096	104	112	120				8	4					
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	CARD POSITION						
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	SLOT NUMBER		
	PLUG 2					PLUG 4					PLUG 6													

SHELF 1

- NOTES:
1. DUAL AND OR QUAD RECEIVER EQUIPMENT NUMBERS ARE 090, 098, 106, 114, 092, 100, 108 AND 116.
 2. QUAD RECEIVER EQUIPMENT NUMBERS ARE 054, 102, 110, 118, 096, 104, 112 AND 120.
 3. EQUIPMENT POSITION 001 IS RESERVED FOR THE TEST LINE AND MUST THEREFORE BE EQUIPPED WITH A LINE CARD.
 4. TRUNK EQUIPMENT NUMBER IS SAME AS INDIVIDUAL TRUNK ACCESS CODE.
 5. SLOT 15 IS RESERVED FOR RECEIVER NO. 1.
 6. MAXIMUM NUMBER OF SUPERSET 4_s = 64


Figure 206-1 Hardware/Equipment Number

PROGRAM EXTENSIONS

MAP210-206

Issue 1, September 1983

Sheet 5 of 11



PROGRAM EXTENSIONS
MAP210- 206
Issue 1, September 1983
Sheet 6 of 11

Note 1: An extension maybe subject to either 0/1 Toll-Allowal or Multi-Digit Toll Control but not both.

ASSIGN TOLL ACCESS

(14A) Press DELETE key

- * DELETE lamp lit
- * SOURCE display shows equipment number and existing Toll-Allow-Deny code (0 = Allow, 1 = Deny).
- * If Multi-Digit Toll Control is enabled 0 = Allow, 1 = COR1, 2 = COR2, 3 = COR3.
- * DESTINATION display shows 0 = Toll-Allow.

(17) of 11

From (12)

(13)
Is this extension
to be
Toll-Allowed

YES

NO

(14)
AND

(15)
AND

PRESS
DELETE KEY

PRESS
ADD KEY

(15A) Press ADD key

- * ADD lamp lit
- * SOURCE display shows equipment number and the existing toll access code.
- * DESTINATION display shows code 1 (Deny).

(16)
Press BUSY
LAMP NUMBER
key. Does bell
ring

YES

NO

DESTINATION display shows
Toll-Allow or Deny code and
error code. E1, bad data received
by CPU.

Return to (11)

Go to (17)

PROGRAM EXTENSIONS

MAP210-206

Issue 1, September 1983

Sheet 7 of 11

NOTE

See CAUTION at start of MAP210-206.

ASSIGN EXTENSION TO BUSY LAMP FIELD

- (17A) Dial BUSY LAMP NUMBER (1-200) to be assigned to extension (See Figure 206-2)
- BUSY LAMP NUMBER lamp lit.
 - SOURCE display shows equipment number and existing Busy Lamp assignment.
 - DESTINATION display shows new Busy Lamp Number.

From (16)

AND

DIAL REQUIRED
BUSY LAMP
NUMBER (Figure
206-2)

[18]

Press PICKUP
GROUP key.
Does bell ring

YES

NO

DESTINATION display shows Busy Lamp Number and error code. E1 - number entered out of range (1-200). Check entry and return to (13). C2 - position dialed already assigned. If this is a valid change press the CONFIRM key and continue, noting that this will eliminate the assignment that was there before. If Busy Lamp position is in error return to (13).

ASSIGN EXTENSION TO PICKUP GROUP


- (19A) Dial Pickup Group number to which extension is assigned
- PICKUP GROUP lamp lit
 - SOURCE display shows equipment number, and current pickup group assignment 0 is displayed if no assignment is made
 - DESTINATION display shows new pickup group assignment

AND

DIAL PICKUP
GROUP NUMBER

Go to (20)

PROGRAM EXTENSIONS
MAP210- 206
Issue 1, September 1983
Sheet 8 of 11



PROGRAM EXTENSIONS
MAP210-206
Issue 1, September 1983
Sheet 9 of 11




Figure 206-2 Busy Lamp Position Numbering

EXTENSION

TO ENTER EXTENSION PROGRAMMING PRESS

EXTN

NAME	EQPT NUMBER	EXTN NUMBER	DIAL CODE OR SEE NOTES 2,3, OR 4	EQS NUMBER	DIAL 1-18	TOLL DENY	ADD	BUSY LAMP NUMBER	DIAL BUSY LAMP NUMBER 1-200	PICKUP GROUP	DIAL 1-30 OR	ENTER
	DIAL 1-112 OR 181-258 (SEE NOTE 1)					TOLL DENY	TOLL ALLOW	DELETE	DELETE	DELETE	DELETE	

NOTES

- 1. EQUIPMENT NUMBERS 181-258 APPLIES TO SX-200 ONLY
- 2. TO ASSIGN NON CONFLICTING SINGLE DIGIT DIRECTORY NUMBER, ENTER MN WHERE N IS THE SINGLE DIGIT
- 3. TO REMOVE EXTENSION PROGRAMMING
- 4. TO SEE THE NEXT EQPT. NUMBER ASSIGNED AS AN EXTENSION
- 5. OR 1-3 APPLIES ONLY IF MULTI DIGIT TOLL CONTROL IS USED

EQPT NUMBER **NEXT**

EXTN **EQPT NUMBER** **DIAL EQUIPMENT NUMBER** **EXTN NUMBER** **DELETE**

EXTENSION MUST BE REMOVED FROM ANY HUNT GROUP BEFORE REMOVING THE EXTENSION PROGRAMMING!



PROGRAM EXTENSION HUNT GROUPS

MAP210-207

Issue 1, September 1983


Sheet 1 of 9

NOTES


- (1) All entries are made from the console dial pad.
 (2) HUNT GROUP lamp remains lit throughout procedure.
 (3) A display of E0 indicates that an incorrect key has been pressed. Press the key specified in the MAP.
 (4) If any equipment number is to be changed within a hunt group, the hunt group must be reentered.
 (5) Refer to Figure 207-1 for an example of the programming form.

SYNOPSIS

Enter hunt group number (1-12).
 Enter master hunt number.
 Enter all required equipment numbers.
 Determine type of hunting.
 Press ENTER key.



PROGRAM EXTENSION HUNT GROUPS
MAP210- 207
Issue 1, September 1983
Sheet 2 of 9



SELECT HUNT GROUP PROGRAM

(4A) Press HUNT GROUP key

- SOURCE display shows hunt group 1 and access code if assigned

(4B) Dial required hunt group number (1-12)

- SOURCE display shows hunt group 1 and master number if assigned
- DESTINATION display shows new hunt group number

- NOTE**
1. EACH HUNT GROUP MUST CONSIST OF EITHER AGENTS ONLY, OR RECORDING ONLY.
 2. ALL RECORDINGS IN THE SAME HUNT GROUP SHOULD HAVE THE SAME MESSAGE.

HUNT GROUPS AGENT/RECORDING GROUPS

TO ENTER HUNT GROUP PROGRAMMING PRESS



EXTENSIVE OR TRUNK INFORMATION MUST BE ENTERED BEFORE TRUNK GROUP DATA



EXTENSIVE INFORMATION MUST BE ENTERED BEFORE TRUNK GROUP DATA

 DIAL 1-12 SEE NOTE 1 AND 2	DIAL CODE OR 	DELETE 	PRESS 	BEFORE DIALING EACH EQUIPMENT NUMBER ENTRY												

TO SEE EQUIPMENT NUMBERS CURRENTLY IN A GROUP

TO MAKE A CHANGE TO A GROUP, THE LIST OF MEMBERS MUST BE RE-ENTERED. INDIVIDUAL MEMBERS CANNOT BE DELETED OR CHANGED. THE EXISTING GROUP LIST IS AUTOMATICALLY DELETED WHEN YOU START TO ENTER A NEW ONE.

FOR CIRCULAR GROUPS FIRST AND LAST NUMBERS MUST BE IDENTICAL

TO SEE ALL GROUPS

TO DELETE A GROUP




PROGRAM EXTENSION HUNT GROUPS


MAP210-207

Issue 1, September 1983

Sheet 5 of 9



PROGRAM EXTENSION HUNT GROUPS	
MAP210- 207	TRM-012744
Issue 1, September 1983	1 of 9
Sheet 6 of 9	1 of 9




PROGRAM EXTENSION HUNT GROUPS

MAP210-207

Issue 1, September 1983

Sheet 7 of 9




PROGRAM EXTENSION HUNT GROUPS

MAP210- 207

Issue 1, September 1983

Sheet 8 of 9




PROGRAM EXTENSION HUNT GROUPS

MAP210-207

Issue 1, September 1983

Sheet 9 of 9



PROGRAM NON-DIAL-IN TRUNKS

MAP210-208

Issue 1, September 1983


Sheet 1 of 11

NOTES


- (1) All entries are made from the console dial pad.
 (2) TRUNK lamp remains lit throughout procedure.
 (3) A display of E0 indicates that an incorrect key was pressed. Press the key specified in MAP and proceed.
 (4) For an example of the programming form refer to Figure 208-3.

SYNOPSIS

- Enter Trunk type number (10-112/162-256)
 Enter Trunk type number (1 or 5, 11 or 51)
 Enter LDN assignment
 Enter DAY assignment
 Enter NIGHT 1 assignment
 Enter NIGHT 2 assignment
 Enter Busy Lamp Position number
 Press ENTER key



PROGRAM NON-DIAL-IN TRUNKS
MAP210- 208
Issue 1, September 1983
Sheet 2 of 11




PROGRAM NON-DIAL-IN TRUNKS
MAP210- 208
Issue 1, September 1983
Sheet 4 of 11

NOTE
 The equipment number dialed is either assigned to an extension or does not contain a trunk card. Check equipment number and card slot. If you wish to remove the previous assignment and assign this equipment position to the trunk press CONFIRM key and return to (3). If you wish to change the equipment entry, return to (3).

- ASSIGN TRUNK TO LDN KEY (8A)** Dial LDN key number (1-4) to be assigned to trunk
- LDN lamp lit
 - SOURCE display shows equipment number and current LDN key assignment
 - DESTINATION display shows new LDN assignment

Code	Type
1	Both way CO trunk VNL
5	Non Dial-In Trunk VNL
11	Both way CO Trunk Non VNL
51	Non Dial-In Tie Trunk Non VNL



PROGRAM NON-DIAL-IN TRUNKS	
MAP210-208	
Issue 1, September 1983	
Sheet 5 of 11	


Code Assignment	Display
#0 Supervisor	0
#1 Bell 1 plus Supervisor	1
#2 Bell 2 plus Supervisor	2
#3 Bell 3 plus Supervisor	3
nnn Equipment Number of extension	nan
* as Hunt Group number 1-12	Laa

NOTE
The # Key is displayed as --1 on the console display. The * Key is displayed as L on the console display.

ENTER DAY ASSIGNMENT
(10A) Dial DAY assignment of trunk (see Table 208-2)
 * DAY lamp lit
 * SOURCE display shows equipment number and current day assignment (Table 208-2)
 * DESTINATION display shows new day assignment (Table 208-2)

Faint bleed-through text from reverse side of page.

(11) or (12)




ENTER NIGHT 1 ASSIGNMENT
(13A) Dial code of equipment to which trunk is to be connected (Table 208-3)
 * NIGHT 1 lamp lit
 * SOURCE display shows current assignment of trunk
 * DESTINATION display shows code dialed

Faint bleed-through text from reverse side of page.

PROGRAM NON-DIAL-IN TRUNKS
MAP210- 208
Issue 1, September 1983
Sheet 6 of 11

Code Assignment	Display
#0 Supervisor Console	0
#1 Bell 1 plus Supervisor	1
#2 Bell 2 plus Supervisor	2
#3 Bell 3 plus Supervisor	3
nnn Equipment Number of extension	nnn
* nn Hunt Group number 1-12	Lnn

NOTE
 The # Key is displayed as --1 on the console display. The * Key is displayed as L on the console display.




ENTER NIGHT 2 ASSIGNMENT (16A) Dial code of equipment to which trunk is to be connected (Table 208-4)

- * NIGHT 2 lamp lit
- * SOURCE display shows current assignment of trunk
- * DESTINATION display shows code dialed

PROGRAM NON-DIAL-IN TRUNKS
MAP210-208
Issue 1, September 1983
Sheet 7 of 11

Code Assignment	Display
#0 Supervisor Console	0
#1 Bell 1 plus Supervisor	1
#2 Bell 2 plus Supervisor	2
#3 Bell 3 plus Supervisor	3
nnn Equipment Number of extension	nnn
* as Hunt Group number 1-12	Las

NOTE
The # Key is displayed as --# on the console display. The * Key is displayed as L on the console display.




ASSIGN TRUNK TO BUSY LAMP FIELD
[19A] Dial busy lamp position assigned to the trunk (Figure 208-2)

- * BUSY LAMP number lamp lit
- * SOURCE display shows equipment number of trunk and current busy lamp assignment
- * DESTINATION display shows new busy lamp assignment

PROGRAM NON-DIAL-IN TRUNKS
MAP210- 208
Issue 1, September 1983
Sheet 8 of 11

NOTE
 The busy lamp position dialed already exists. If assignment dialed is correct, press the CONFIRM key, this will remove the original assignment and assign the busy lamp position to this trunk. The busy lamp will therefore, indicate multiple numbers. Multiple appearances may be removed by proceeding through this MAP.



(22A) Press LAMP TEST key
 * All displays dark
 * All lamps dark except LAMP TEST lamp

PROGRAM NON-DIAL-IN TRUNKS
MAP210- 208
Issue 1, September 1983
Sheet 9 of 11




Figure 208-2 Busy Lamp Position Numbering

PROGRAM DIAL-IN TRUNKS	MAP210-209
MAP210-209	Issue 1, September 1983
Issue 1, September 1983	Sheet 1 of 11


NOTES

(1) All entries are made from the console dial pad
 (2) TRUNK lamp remains lit throughout procedure
 (3) A display of ED indicates that an incorrect key was pressed. Press the key specified in MAP and proceed.
 (4) This flow chart applies to E&M, LOOP and DX Tie Trunks
 (5) Refer to Figure 209-3 for an example of the form.


SYNOPSIS

Press TRUNK key.
 Enter Equipment number (10-161/162-256)
 Enter Trunk type number 2 or 4, 21 or 41
 Enter Trunk COS
 Enter Toll-Allow/Deny code
 Enter Busy Lamp Position number
 Press ENTER

SELECT TRUNK PROGRAM
 (3A) Press TRUNK key
 * TRUNK lamp lights and remains lit throughout procedure.



PROGRAM DIAL-IN TRUNKS	LADDM
MAP210- 209	011-010NA
Issue 1, September 1983	1 000
Sheet 2 of 11	11 1 000



HARDWARE POSITION NUMBER	PLUG 7						PLUG 9						PLUG 11						EXTENSION UNIT NO.	TRUNK UNIT NO. (1 TRUNK)	TRUNK UNIT NO. (2 TRUNK)				
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18				19	20	21	22
161	169	177	185	193	201	209	217	225	233	241	249												1		
162	170	178	186	194	202	210	218	226	234	242	250												2	1	1
163	171	179	187	195	203	211	219	227	235	243	251												3		
164	172	180	188	196	204	212	220	228	236	244	252												4	2	
165	173	181	189	197	205	213	221	229	237	245	253												5		
166	174	182	190	198	206	214	222	230	238	246	254												6	3	2
167	175	183	191	199	207	215	223	231	239	247	255												7		
168	176	184	192	200	208	216	224	232	240	248	256												8	4	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	CARD POSITION		
	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	SLOT NUMBER		
	PLUG 8						PLUG 10						PLUG 12												

SHELF 2 (SX-200 ONLY)

HARDWARE POSITION NUMBER	PLUG 1						PLUG 3						PLUG 5						EXTENSION UNIT NO.	TRUNK UNIT NO. (1 TRUNK)	TRUNK UNIT NO. (2 TRUNK)				
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18				19	20	21	22
001	009	017	025	033	041	049	057	065	073	081	089	097	105	113									1		
002	010	018	026	034	042	050	058	066	074	082	090	098	106	114									2	1	1
003	011	019	027	035	043	051	059	067	075	083	091	099	107	115									3		
004	012	020	028	036	044	052	060	068	076	084	092	100	108	116									4	2	
005	013	021	029	037	045	053	061	069	077	085	093	101	109	117									5		
006	014	022	030	038	046	054	062	070	078	086	094	102	110	118									6	3	2
007	015	023	031	039	047	055	063	071	079	087	095	103	111	119									7		
008	016	024	032	040	048	056	064	072	080	088	096	104	112	120									8	4	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	CARD POSITION		
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	SLOT NUMBER		
	PLUG 2						PLUG 4						PLUG 6												


SHELF 1

- NOTES:
1. DUAL AND OR QUAD RECEIVER EQUIPMENT NUMBERS ARE 090, 098, 106, 114, 092, 100, 108 AND 116.
 2. QUAD RECEIVER EQUIPMENT NUMBERS ARE 094, 102, 110, 118, 096, 104, 112 AND 120.
 3. EQUIPMENT POSITION 001 IS RESERVED FOR THE TEST LINE AND MUST THEREFORE BE EQUIPPED WITH A LINE CARD.
 4. TRUNK EQUIPMENT NUMBER IS SAME AS INDIVIDUAL TRUNK ACCESS CODE.
 5. SLOT 15 IS RESERVED FOR RECEIVER NO. 1.
 6. MAXIMUM NUMBER OF SUPERSET 4x = 64

Figure 209-1 Hardware/Equipment Number

PROGRAM DIAL-IN TRUNKS
MAP210- 209
Issue 1, September 1983
Sheet 4 of 11

NOTE
 The equipment number dialed is either assigned to an extension or does not contain a trunk card. Check equipment number and card slot. If you wish to remove the previous assignment and assign this equipment position to the trunk press CONFIRM button so the present entry will be eliminated, and return to (5). IF you wish to change the equipment entry return to (4).



- (8A) Press DELETE key
- DELETE lamp lit
 - SOURCE display shows equipment number and its current class
 - DESTINATION display shows 0



TABLE 209-1

CODE	TYPE
2	Direct Inward System Access VNL
4	Dial-In Trunk VNL
21	Direct Inward System Access Non VNL
41	Dial-In Trunk VNL




- SELECT TRUNK TYPE
- (9A) Dial trunk code (Table 209-1)
- TYPE lamp lit
 - SOURCE display shows the equipment number of the trunk and its current type
 - DESTINATION display shows trunk type entered


CAUTION
 Trunks **MUST** be removed from trunk groups before being removed from the system. Trunks cannot be deleted or changed while they are in use.



PROGRAM DIAL-IN TRUNKS	MAP210-209
MAP210-209	Issue 1, September 1983
Issue 1, September 1983	Sheet 5 of 11



PROGRAM DIAL-IN TRUNKS	14-1008
MAP210- 209	80 - 0125A3
Issue 1, September 1983	800 - 1 - 800
Sheet 6 of 11	17 - 1 - 200




PROGRAM DIAL-IN TRUNKS

MAP210-209


Issue 1, September 1983

Sheet 7 of 11



PROGRAM DIAL-IN TRUNKS
MAP210- 209
Issue 1, September 1983
Sheet 8 of 11

NOTE
 The busy lamp position dialed is already assigned to an extension or trunk.
 If you wish to remove the previous assignment and assign the busy lamp position to the trunk, press the CONFIRM key and return to (19).
 If you do not wish to remove the previous assignment return to (16).



(22A) Press LAMP TEST key
 * All displays dark
 * All lamps dark except LAMP TEST lamp

PROGRAM DIAL-IN TRUNKS

MAP210-209

Issue 1, September 1983

Sheet 9 of 11




Figure 209-2 Busy Lamp Position Numbering


PROGRAM DID TRUNKS	810 HARBOR
MAP210-210	OTS -0111A1
Issue 1, September 1983	
Sheet 1 of 9	8 of 2 read

NOTES

- (1) All entries are made from the console dial pad.
 (2) Trunk lamp remains lit throughout procedure.
 (3) A display of ED indicates that an incorrect key has been pressed. Press the key specified in the MAP and proceed.
 (4) For an example of the form refer to Figure 210-3.

SYNOPSIS


Enter equipment number
 10-112/162-256
 Enter trunk type code 3, 31, 6 or 61.
 Enter I/C code.
 Enter Busy Lamp assignment.
 Press ENTER.



SELECT TRUNK PROGRAM

- (3A) Press TRUNK key
 • Trunk lamp lights and remains lit throughout procedure

PROGRAM DID TRUNKS
MAP210- 210
Issue 1, September 1983
Sheet 2 of 9






Figure 210-1 Hardware/Equipment Number

PROGRAM DID TRUNKS
MAP210- 210
Issue 1, September 1983
Sheet 4 of 9




TABLE 210-1

CODE	TRUNK TYPE
3	DID VNL
6	CCSA VNL
31	DID Non VNL
61	CCSA Non VNL


CAUTION
Trunks **MUST** be removed from trunk groups before being removed from the system. Trunks cannot be deleted or changed while they are in use.

PROGRAM DID TRUNKS

MAP210-210

Issue 1, September 1983

Sheet 5 of 9



PROGRAM DID TRUNKS	010-01-01-01
MAP210- 210	01-01-01-01
Issue 1, September 1983	
Sheet 6 of 9	




Figure 210-2 Busy Lamp Position Numbering

PROGRAM DID TRUNKS


MAP210-210

Issue 1, September 1983

Sheet 7 of 9

NOTE

The Busy Lamp Position dialed already exists. If the assignment is correct, press the CONFIRM key, this will remove the old assignment and assign the position to this trunk. If the assignment is incorrect, return to (12).



(16A) Press LAMP TEST key
* All indicators go dark except LAMP TEST lamp

PROGRAM TRUNK GROUPS

MAP210-211

Issue 1, September 1983


Sheet 1 of 12

NOTES


- (1) All entries are made from the console dial pad.
 (2) TRUNK GROUP lamp remains lit throughout procedure.
 (3) A display of E0 indicates that an incorrect key has been pressed, press the key specified in the MAP.
 (4) If an equipment number is to be changed all trunks within the trunk group must be reentered.
 (5) For an example of the programming form refer to Figure 211-1.

SYNOPSIS

Set up trunk group and access code.
 Assign trunk group type, Toll Deny and Overflow Group codes.
 Enter all trunk equipment numbers assigned to the trunk group.



PROGRAM TRUNK GROUPS
MAP210- 211
Issue 1, September 1983
Sheet 2 of 12



PROGRAM TRUNK GROUPS


MAP210-211

Issue 1, September 1983

Sheet 3 of 12

ASSIGN TRUNK GROUP
ACCESS CODE

- (8A) Dial access code to be assigned to this trunk group
- ACCESS CODE lamp lit
 - SOURCE display shows new trunk group and existing access code if assigned, or the new trunk group and ---- if no access code assigned.
 - DESTINATION display shows new access code dialed




PROGRAM TRUNK GROUPS
MAP210- 211
Issue 1, September 1983
Sheet 4 of 12

ASSIGN TRUNK TYPE
 (8A) Dial trunk type code (Table 211-1)
 * TYPE lamp lit
 * SOURCE display shows trunk group number and current type
 * DESTINATION display 4 digit type code dialed

TABLE 211-1

Entry	Code	Description
First digit	1	No Answer Supervision
	2	Answer Supervision
	3	Toll Supervision
	4	Outgoing audio inhibited until answer supervision
Second digit	1	No message register
	2	Message register
	3	SMOR without message register
	4	SMOR with message register
Third digit	*1	Rotary dial office, no wait for dial tone
	*2	Rotary dial office, wait for dial tone
	**3	DTMF dial office, no wait for dial tone
	**4	DTMF dial office, wait for dial tone
Fourth digit	1	CO trunk
	2	Non-CO trunk
	3	Identified Trunk Group (Non CO)



PROGRAM TRUNK GROUPS

MAP210- 211

Issue 1, September 1983

Sheet 5 of 12

NOTE 1


- If answer supervision is not required (or not provided by the CO), then use 1 - No Answer Supervision.
- If tandem trunking or Message Registration is used, then use 2 - Answer Supervision.
- If supervision is used to indicate toll calls, and this feature is required, then use 2 - Toll Supervision.
- If audio cut-through or tie trunk tandem calls is required only after receipt of answer supervision, then use 4 - Outgoing Audio Inhibit until Answer Supervision.

NOTE 2


- If "wait for dial tone" is selected then any digits dialed prior to receipt of CO dial tone are ignored by the PABX. This prevents circumvention of the toll denial by dialing a fast valid digit before CO dial tone is received.

NOTE 3

- If the fourth digit selected is 3, the third digit must be 1.
- If extensions are DTMF the trunk will convert to dial pulse. Early line split is not provided.
- ** Trunks will repeat DTMF or dial pulse signals.



PROGRAM TRUNK GROUPS
MAP210- 211
Issue 1, September 1983
Sheet 6 of 12




PROGRAM TRUNK GROUPS
MAP210-211
Issue 1, September 1983
Sheet 7 of 12


NOTE
 Overflow group number must not be the same as the current trunk group number. If a call to a trunk group is routed to the overflow group, the restrictions of the overflow group are in force for that call.

ASSIGN OVERFLOW GROUP
 (16A) Dial overflow group number (1-12)
 * OVFL0 GROUP lamp lit
 * SOURCE display shows trunk group number and assigned overflow group number
 * DESTINATION display shows new overflow group number
 (16B) If no overflow group required press DELETE

ASSIGN EQUIPMENT NUMBERS TO THIS TRUNK GROUP
 (18A) Dial equipment number of trunk in trunk group (10-112 162-256)
 * EQPT NUMBER lamp lit
 * SOURCE display shows the trunk group number and existing equipment number



PROGRAM TRUNK GROUPS
MAP210- 211
Issue 1, September 1983
Sheet 8 of 12




PROGRAM TRUNK GROUPS

MAP210-211


Issue 1, September 1983

Sheet 9 of 12

- (22A) Dial first equipment number on this trunk group
- * EQPT NUMBER lamp lit
 - * SOURCE display shows trunk group and last equipment number entered
 - * DESTINATION display shows first equipment number entered



PROGRAM TRUNK GROUPS	MAP210- 211
Issue 1, September 1983	Sheet 10 of 12



TRUNK GROUPS

TO ENTER TRUNK GROUP PROGRAMMING PRESS TRUNK GROUP (TRUNK INFORMATION MUST BE ENTERED BEFORE TRUNK GROUP DATA)

TRUNK GROUP	DIAL 1-12	ACCESS CODE	DIAL CODE OR DELETE	TYPE SEE NOTES 6 & 7	TOLL DENY OR DELETE	ADD OR DELETE	OVRFLD GROUP NOTE 9	DIAL 1-12 OR DELETE	SEE NOTE 4 AND 8	PRESS EQPT NUMBER BEFORE DIALING EACH EQUIPMENT NUMBER ENTRY AFTER LAST ENTRY PRESS ENTER
NOTE 11				1ST DIGIT 2ND DIGIT 3RD DIGIT 4TH DIGIT	NOTES 9 & 10					

NOTES

- TO SEE THE TRUNKS IN A TRUNK GROUP: TRUNK GROUP DIAL NUMBER 11-12 EQPT NUMBER NEXT NEXT
- TO SEE ALL TRUNK GROUPS: TRUNK GROUP NEXT NEXT
- TO DELETE TRUNK GROUP: TRUNK GROUP DIAL NUMBER 11-12 ACCESS CODE DELETE ENTER
- TO MAKE A CHANGE TO A TRUNK GROUP, THE LIST OF MEMBERS MUST BE RE-ENTERED. INDIVIDUAL MEMBERS CANNOT BE DELETED OR CHANGED. THE EXISTING TRUNK GROUP LIST IS AUTOMATICALLY DELETED WHEN YOU START TO ENTER A NEW ONE.
- ORIGINAL AND OVERFLOW TRUNK GROUPS MUST BE THE SAME TYPE AND HAVE THE SAME TOLL RESTRICTION CHARACTERISTICS.

6. TRUNK GROUP TYPE IS 4 DIGITS

1st Digit:
 1-NO SUPERVISION
 2-ANSWER SUPERVISION
 3-TOLL REVERSAL
 4-OUTGOING AUDIO INHIBITED UNTIL ANSWER SUPERVISION TIMEOUT OR SOLOED

2nd Digit:
 1-ROTARY DIAL OFFICE, NO WAIT FOR DIAL TONE
 2-ROTARY DIAL OFFICE, WAIT FOR DIAL TONE
 3-TOUCH TONE DIAL OFFICE, NO WAIT FOR DIAL TONE
 4-TOUCH-TONE DIAL OFFICE, WAIT FOR DIAL TONE

3rd Digit:
 1-TRUNK GROUPS TYPE 4X2X AND 4X4X ARE NOT VALID AND SHOULD NOT BE PROGRAMMED

4th Digit:
 1-CENTRAL OFFICE
 2-NOR-CO
 3-IDENTIFIED TRUNK GROUP (NOR-CO)
 4-IDENTIFIED TRUNK GROUP (1 DIGIT)
 5-IDENTIFIED TRUNK GROUP (2 DIGITS)
 6-IDENTIFIED TRUNK GROUP (3 DIGITS)

8. THE TRUNKS WITHIN A TRUNK GROUP MAY BE PROGRAMMED FOR EITHER TERMINAL OR CIRCULAR HUNTING. IF TERMINAL HUNTING IS REQUIRED, ENTER TRUNK EQUIPMENT NUMBERS IN REQUIRED SEQUENCE.

IF CIRCULAR HUNTING IS REQUIRED MAKE LAST TRUNK EQUIPMENT NUMBER THE SAME AS THE FIRST TRUNK EQUIPMENT NUMBER.

9. USE OF TOLL DENY KEY DOES NOT APPLY IF TOLL CONTROL IS USED.

10. SEE SECTION MITL9105/9110-090-210-NA OR TOLL CONTROL FORMS IN THIS SECTION.

11. TOLL CONTROL IS HAZ PRIORITY

RANGE PROGRAMMING FOR
EXTENSION

MAP210-212

Issue 1, September 1983


Sheet 1 of 6

NOTE

For an example of the programming form refer to Figure 212-2.

SYNOPSIS RANGE PROGRAMMING

Enter RANGE programming
 Enter first equipment number, dial *
 Enter last equipment number
 Enter first extension number
 Enter first BUSY LAMP NUMBER
 Enter COS number for Range
 Enter Toll Deny
 Enter Pickup Group
 Enter Data



RANGE PROGRAMMING FOR EXTENSIONS
MAP210- 212
Issue 1, September 1983
Sheet 2 of 6






Figure 213-1

RANGE PROGRAMMING FOR
EXTENSION


MAP210-212

Issue 1, September 1983

Sheet 3 of 6



RANGE PROGRAMMING FOR EXTENSIONS
MAP210- 212
Issue 1, September 1983
Sheet 4 of 6



EXTENSION RANGE PROGRAMMING

TO ENTER EXTENSION RANGE PROGRAMMING PRESS

RANGE

NAME	EXTN NUMBER DIAL FIRST EXTN NUMBER DIAL # DIAL LAST EXTN NUMBER NOTE 1	EXTN NUMBER DIAL FIRST CODE OF RANGE OR EXT NOTES 2,3 OR 4	CODE NUMBER DIAL CODE 1-16 FOR RANGE	TOLL CODE OR DIAL CODE 1,2,OR 3 OR TOLL ALLOW NOTE 5	ADD DELETE	EXTN LAMP NUMBER DIAL FIRST EXTN LAMP 1-200 OR DELETE	FIELD GROUP DIAL 1-30 FOR RANGE OR DELETE	ENTER

NOTES

- 1. 001 - 161 EX-200 & EX-100 161 - 256 APPLIES TO EX-200 ONLY
- 2. TO ASSIGN NON-CONFLICTING SINGLE DIGIT DIRECTORY NUMBER ENTER 99
- 3. TO REMOVE EXTENSION PROGRAMMING
- 4. TO SEE THE NEXT EXTN NUMBER AS AN EXTENSION
- 5. COR. 1-3 APPLIES ONLY IF TOLL CONTROL IS USED.


EXTN NUMBER NEXT

EXTN EXTN NUMBER DIAL EQUIPMENT NUMBER EXTN NUMBER DELETE


EXTENSION MUST BE REMOVED FROM ANY HUNT GROUP BEFORE REMOVING THE EXTENSION PROGRAMMING




TERMINATING STANDARD PROGRAMMING MODE	
MAP210- 213	
Issue 1, September 1983	
Sheet 1 of 3	



TERMINATING STANDARD PROGRAMMING MODE	STARTING/STOPPING PROGRAMMING
MAP210- 213	SYNOPSIS
Issue 1, September 1983	ISSUE 1
Sheet 2 of 3	2 of 3



TERMINATING STANDARD PROGRAMMING MODE
MAP210- 213
Issue 1, September 1983
Sheet 3 of 3



SELECTION OF EXTENDED
PROGRAMMING

MAP210-221

Issue 1, September 1983


Sheet 1 of 2

TABLE 221-1

CODE	CONSOLE
7770	Maintenance
7771	Supervisor 1
7772	Supervisor 2


- (2A) Press RELEASE button several times
 (2B) Set thumbwheel switches on Tone Control card (card position 18 yellow) for console to be used in programming (Table 221-1)
 (2C) Press LAMP TEST button
 * LAMP TEST LED lit
 (2D) Alternately enter Programming Security Code from console (Feature 29)

- (4A) Place Extended Programming console overlay over console buttons




SELECTION OF EXTENDED PROGRAMMING
MAP210- 221
Issue 1, September 1983
Sheet 2 of 2

- (5A) Press LAMP TEST button
- (5B) Press NEXT button
- * LAMP TEST LED flashes for the duration of Extended Programming




ABSORB PLAN	MAP210-222
Issue 1, September 1983	
Sheet 1 of 6	

NOTE
For an example of the programming form refer to Figure 222-2



(3A) Press TOLL CONTROL button
* Toll Control LED lights

ABSORB PLAN	MAP210- 222
MAP210- 222	Issue 1, September 1983
Issue 1, September 1983	Sheet 2 of 6



ABSORB PLAN	MAP210- 222
Issue 1, September 1983	Sheet 3 of 6





Figure 222-2

ABSORB PLAN	0A27	0088A
MAP210- 222	000	09801
Issue 1, September 1983	0000000	00001
Sheet 4 of 6	000	00000



(14A) Press the ENTER button


TOLL CONTROL

ABSORB PLAN

<p>ABSORB PLAN</p> <p>DIAL 1 OR 2</p>	<p>DIAL REPEAT DIGITS (MAX 4) OR</p> <p>ABSORB REPEAT</p> <p>DELETE</p>	<p>DIAL UNLOCK DIGITS (MAX 4) OR</p> <p>ABSORB UNLOCK</p> <p>DELETE</p>	<p>ABSORB PLAN 1</p> <p>ABSORB PLAN 2</p>
<p>ABSORB PLAN NUMBER 1</p>			
<p>ABSORB PLAN NUMBER 2</p>			
<p>ENTER</p>			

TO VIEW THE ABSORB PLANS:

<p>ABSORB PLAN</p>	<p>NEXT</p>	<p>NEXT</p>
<p>PLAN NUMBER 1 DISPLAYED</p>	<p>PLAN NUMBER 2 DISPLAYED</p>	



TOLL CONTROL

ABSORB PLAN

<p>ABSORB PLAN DIAL 1 OR 2</p>	<p>DIAL REPEAT DIGITS (MAX 4) OR ABSORB REPEAT DELETE</p>	<p>DIAL UNLOCK DIGITS (MAX 4) OR ABSORB UNLOCK DELETE</p>	<p>ABSORB PLAN</p>	<p>ABSORB PLAN</p>
<p>ABSORB PLAN NUMBER 1</p>				<p>1. ABSORB PLAN NUMBER</p>
<p>ABSORB PLAN NUMBER 2</p>				<p>2. ABSORB PLAN NUMBER</p>
<p>ENTER</p>				

TO VIEW THE ABSORB PLANS:

ABSORB PLAN NEXT NEXT

PLAN NUMBER 1 DISPLAYED

PLAN NUMBER 2 DISPLAYED



CONTROL PLAN


MAP210-223

Issue 1, September 1993

Sheet 1 of 7


NOTE

For an example of the programming form refer to Figure



(3A) Press TOLL CONTROL button
 * Toll Control LED lights

CONTROL PLAN
MAP210- 223
Issue 1, September 1983
Sheet 2 of 7




(4A) Press CONTROL PLAN button
 * Control Plan LED lights
 (4B) Dial Control Plan number
 * DESTINATION Display shows Control Plan Number

(6A) Press DENY TOLL REV button
 (6B) Press DELETE button (Figure 223-1).


(7A) Press DENY TOLL REV button
 (7B) Press ADD button (Figure 223-2).

(8A) Press BASIC COND button
 (8B) Dial Basic Cond. number
 * Destination Display shows Basic Cond. number


CONTROL PLAN	
MAP210-223	
Issue 1, September 1983	
Sheet 3 of 7	



CONTROL PLAN
MAP210- 223
Issue 1, September 1983
Sheet 4 of 7



CONTROL PLAN
MAP210-223
Issue 1, September 1983
Sheet 5 of 7



NAME JORTWOD
CCC -075RAM
ESST 10/20/80 1.7 10/20
1 to 2 10/20

(27) 10/20

TOLL CONTROL CONTROL PLAN



CONTROL PLAN	DIAL 1-15	DENT TOLL REV	TOLL CONTROL		BASIC COND DIAL 1-5 NOTE 2	CONTROL PLAN		TABLE	DIAL 1-5 (800 ENTRY) 21-25 (20 RANGE) 51-73A ENTRY OR DELETE
			ADD	DELETE		ADD	DELETE		
1		1 0	-	-	1 ID	0			
					2 (1-XND)	0			
					3 (1-XD/1X)	0			
					4 (ND)	0	21		
					5 (ND/1X)	0	21		
2		1 0	-	-	1 ID	0		52	
					2 (1-XND)	1		51	
					3 (1-XD/1X)	1		51	
					4 (ND)	1	23		
					5 (ND/1X)	1	23		
3		1 1	-	-	1 ID	1			
					2 (1-XND)	1			
					3 (1-XD/1X)	1			
					4 (ND)	1			
					5 (ND/1X)	1			

ENTER

NOTE 1

ADD - ALLOW ALL CODES EXCEPT THOSE LISTED IN THE TABLE SPECIFIED

DELETE - DENY ALL CODES, EXCEPT THOSE LISTED IN THE TABLE SPECIFIED

TO REVIEW CONTROL PLAN ASSIGNMENTS

TO REVIEW THE BASIC CONDITIONS OF THE CONTROL PLAN

CONTROL PLAN DIAL 1-15

CONTROL PLAN DIAL 1-15

DISPLAY ENTRY DIAL 1

BASIC COND DIAL 1

DISPLAY BASIC CONDITION 1

DISPLAY ENTRY DIAL 1

DISPLAY BASIC CONDITION 2

DISPLAY BASIC CONDITION 3

NOTE 2, 3 IF ANY NUMBER 2-5
X IF ANY NUMBER 0-9

MITEL

ALSO REVIEW

KZIMP

TOLL CONTROL

CONTROL PLAN



CONTROL PLAN DIAL 1-15	DENY TOLL REV ADD OR DELETE	BASIC COND DIAL 1-5 NOTE 2	ADD OR DELETE NOTE 1	TABLE DIAL 1-5 (BDD ENTRY) 21-33 (20 RANGE) 51-7314 (ENTRY) OR DELETE	
4-15	Same	1 (R) 2 (1-XRX) 3 (1-RX/1X) 4 (RX) 5 (RX/1X)	/	-	
		1 (R) 2 (1-XRX) 3 (1-RX/1X) 4 (RX) 5 (RX/1X)			
		1 (R) 2 (1-XRX) 3 (1-RX/1X) 4 (RX) 5 (RX/1X)			ENTER

NOTE 1

ADD - ALLOW ALL CODES EXCEPT THOSE LISTED IN THE TABLE SPECIFIED TO REVIEW CONTROL PLAN ASSIGNMENTS

DELETE - DENY ALL CODES EXCEPT THOSE LISTED IN THE TABLE SPECIFIED TO REVIEW THE BASIC CONDITIONS OF THE CONTROL PLAN

NOTE 2: R IS ANY NUMBER 2-9
X IS ANY NUMBER 0-9

CONTROL PLAN DIAL 1-15 DISPLAY ENTRY NEXT


CONTROL PLAN DIAL 1-15 BASIC COND DIAL 1 DISPLAY ENTRY NEXT NEXT

DISPLAY BASIC CONDITION 1 DISPLAY BASIC CONDITION 2 DISPLAY BASIC CONDITION 3


TRUNK GROUP CLASS OF RESTRICTION	RESTRICTIVE
MAP210-224	ISS - OTHER
Issue 1, September 1983	ISSUE 1
Sheet 1 of 6	9 of 5 2000

NOTE

Refer to Figure 224-3 for an example of the programming form.



TRUNK GROUP CLASS OF RESTRICTION	
MAP210- 224	
Issue 1, September 1983	
Sheet 2 of 6	



ITOM
 To increase the toll control group's toll control number...







Figure 224-1

TRUNK GROUP CLASS OF RESTRICTION
MAP210-224
Issue 1, September 1983
Sheet 3 of 6



TRUNK GROUP CLASS OF RESTRICTION
MAP210- 224
Issue 1, September 1983
Sheet 4 of 6



[16A] Press ENTER button

NOTICE TO READ

CLASS OF RESTRICTION

(TRUNK GROUP)

TOLL CONTROL

TRUNK GROUP	DIAL 1-12	ABSORB PLAN DIAL 1-2 OR DELETE	COR NUMBER DIAL 1-2	CONTROL PLAN DIAL 1-15 OR DELETE
1		-	1 2 3	2 1
2		-	1 2 3	2 1
3		-	1 2 3	2 1
4		-	1 2 3	2 1
5		-	1 2 3	2 1


ENTER

TO REVIEW CLASS OF RESTRICTION OF A TRUNK GROUP

TRUNK GROUP DIAL 1-12 COR DIAL 1 DISPLAY ENTRY NEXT NEXT
COR 1 COR 2 COR 3

TO SEE NEXT TRUNK GROUP CLASS OF RESTRICTION

TRUNK GROUP DIAL 1-12 DISPLAY ENTRY NEXT



CLASS OF RESTRICTION

TOLL CONTROL
TRUNK GROUP

TRUNK GROUP DIAL 1-12	ANSWER PLAN DIAL 1-2 OR DELETE	COB NUMBER DIAL 1-2	CONTROL PLAN DIAL 1-12 OR DELETE	
6-12	- -	1	1	
		2	1	
		3	1	
		1	1	
		2	1	
		3	1	
		1	1	
		2	1	
		3	1	
		1	1	
		2	1	
		3	1	
				ENTER

TO REVIEW CLASS OF RESTRICTION OF A TRUNK GROUP

TRUNK GROUP DIAL 1-12 COB DIAL 1 DISPLAY ENTRY NEXT NEXT

COB 1 COB 2 COB 3

TO SEE NEXT TRUNK GROUP CLASS OF RESTRICTION

TRUNK GROUP DIAL 1-12 DISPLAY ENTRY NEXT



RESTRICTION TABLES

MAP210-225

Issue 1, September 1983

Sheet 1 of 8

NOTE 1

Refer to Figures 225-1, 225-2 and 225-3 for an example of the programming form.


NOTE 2

If the wrong number is entered by mistake go back to step 3.

NOTE 3

Use these MAPs to perform desired modifications.

(3A) Press the TOLL CONTROL button
* Toll Control LED lights



RESTRICTION TABLES
MAP210- 225
Issue 1, September 1983
Sheet 2 of 8

TABLE 225-1 (Note 1)

OPTION	MAP NUMBER
Add an entry	210-225
Display sequential entries	210-227
Search for a specific entry	210-228
Delete entry being displayed	210-229
Terminated Programming	210-274


- (4A) Press TABLE button
- * TABLE BUTTON LED lights
- (4B) Dial Table number

- (6A) Press DELETE button
- (6B) Press CONFIRM button
- (6C) Press ENTER button

STOP

STOP

STOP



4 ENTRY EXCEPTION TABLE

FROM BASIC CONDITION _____


TOLL CONTROL

THIS TABLE LISTS ALL THE CODES THAT ARE ALLOWED

OR TABLE NUMBER _____ CONTROL PLAN _____

THIS TABLE LISTS ALL THE CODES THAT ARE DENIED

<input type="checkbox"/> TABLE	DIAL 51-73	<input type="checkbox"/> DISPLAY ENTRY	PRESS <input type="checkbox"/> ADD	BEFORE DIALING EACH ENTRY	IF AN EXPANSION TABLE IS TO BE APPLIED TO THIS ENTRY	
				<input type="checkbox"/> TABLE DIAL TABLE NUMBER 1-73		
TABLE NUMBER						
51 <hr/> 52		213	1		24	
		214			25	
		619			26	
		011				
						<input type="checkbox"/> ENTER
TO SEARCH FOR A SPECIFIC ENTRY <input type="checkbox"/> DISPLAY ENTRY DIAL ENTRY <input type="checkbox"/> DISPLAY ENTRY IF THE ENTRY DOES NOT EXIST DASHES ARE SHOWN IN THE ENTRY DISPLAY			TO DELETE THE ENTRY BEING DISPLAYED <input type="checkbox"/> DELETE <input type="checkbox"/> ENTER NOTE: ANY OPERATIONS MAY BE PERFORMED IN ANY ORDER.			
<input type="checkbox"/> NEXT TO DISPLAY THE NEXT ENTRY HAS Y IN THE TABLE AFTER THE ENTRY HAS BEEN SELECTED			TO DELETE ALL ENTRIES FROM A TABLE <input type="checkbox"/> TABLE DIAL TABLE NUMBER <input type="checkbox"/> DELETE <input type="checkbox"/> CONFIRM <input type="checkbox"/> ENTER			



ADD AN ENTRY

MAP210-226


Issue 1, September 1983

Sheet 1 of 2


NOTE

If the wrong entry digits are keyed by mistake, attempt to add the entry as it was keyed. If the entry is accepted remove it with the delete key. If an error is given no further action is required, as the entry was ignored.

(2A) Press ADD button
(2B) Dial ENTRY digits (See Note)



ADD AN ENTRY	YRTWS NA 00
MAP210- 226	000-070AM
Issue 1, September 1983	00000 1 000
Sheet 2 of 2	2 to 1 000




DISPLAYING SEQUENTIAL ENTRIES


MAP210-227

Issue 1, September 1983


Sheet 1 of 1



SEARCH FOR AN ENTRY	MAP 210-228
MAP210- 228	Issue 1, September 1983
Issue 1, September 1983	Sheet 1 of 2



SEARCH FOR AN ENTRY
MAP210- 228
Issue 1, September 1983
Sheet 2 of 2




DELETE AN ENTRY

MAP210-229


Issue 1, September 1983

Sheet 1 of 2

(2A) Press DELETE button



DELETE AN ENTRY
MAP210- 229
Issue 1, September 1983
Sheet 2 of 2



PROGRAMMING PERSONAL TABLES

MAP210-242

Issue 1, September 1983

Sheet 1 of 11

NOTES

1. Prior to making programming entries on this MAP, Form SC-2 must have been completed. The completed form is used in conjunction with the relevant steps noted in this MAP.

2. After digit entries are made (e.g., Step (4)), the bell may ring and an error code may appear in the DESTINATION display when the key in the next sequence is pressed. In this event refer to Tables 242-1 or 242-2, and repeat the sequence, i.e., the relevant function key and its digit entries, in order to correct the previous entry. Figure 242-2 shows a typical error code entry.


3. Refer to Figures. 242-4, 242-5, 242-6, 242-7, 242-8 and 242-9 for an example of the programming forms.

NOTE

The SPEED CALL LED remains lit during programming in the Speed Call mode.

(3A) Press TABLE key

(E7) or (E8)





PROGRAMMING PERSONAL TABLES
MAP210- 242
Issue 1, September 1983
Sheet 2 of 11

NOTE
 Error E3 (Table 242-1) may occur after a subsequent key operation. See Note 2 and Figure 242-2.

- (4A) Enter Table number required (see From SC-2)
- DESTINATION display shows number entered (Figure 242-1)
 - When a subsequent key operation occurs the number is transferred to the SOURCE display and three hyphens appear as shown in (Figure 242-1).

TABLE 242-1

ERROR CODE	DESCRIPTION
E1	The equipment number entered is not that for a station
E3	The table number entered is not valid for the current size CONFIGURATION
E6	The CONFIGURATION (MAP210-221) entered does not include Speed Call



PROGRAMMING PERSONAL TABLES	
MAP210- 242	342-07143
Issue 1, September 1983	
Sheet 3 of 11	



(7A) Press EQPT NUMBER key
 * EQPT NUMBER LED is lit

De (6)

[7]
 ET

PRESS EQPT NUMBER KEY

[8]
 ET

DIAL EQUIPMENT NUMBER DIGITS

(8A) Dial equipment number digits for selected table
 * DESTINATION display shows dialed digits
 * SOURCE display shows digits entered (Figure 242-3) when a subsequent key operation occurs

[9]
 ET

PRESS ACCESS NUMBER KEY

(9A) Press ACCESS NUMBER key

Aller à (10)



Figure 242-2. Typical Error Code Display

NOTE
 Error E1 (Table 242-1) may occur after a subsequent key operation. See Note 2 and Figure 242-2.

PROGRAMMING PERSONAL TABLES
MAP210- 242
Issue 1, September 1983
Sheet 4 of 11

NOTE
 Error E1 (Table 242-1), or Error E5 (Table 242-2) may occur after Step (10). See Note 2 and Figure 242-2

(10A) Dial first speed call access number digits for the selected table (see Form SC-2)
 * DESTINATION display shows dialed digits in first two positions which go to the last two positions when a subsequent key operation occurs (Figure 242-3).




Figure 242-3 Completed Entries Display

(9) De (9)

(10) ET

DIAL ACCESS NUMBER

(11) Is Number Redial to be used for this Station

OUI

NON

(12) ET

PRESS NUMBER REDIAL KEY

(13) ET

PRESS ADD KEY

Aller à (14)


(12A) Press Number Redial Key

NOTE
 Error E5 (Table 242-3) may occur after Step (13). See Note 2 and Figure 242-2

(13A) Press ADD key
 * DESTINATION display shows Access Number
 * SOURCE display shows digit 1

TABLE NUMBER		ENTRY ACCESS NUMBERS		SOFT NUMBER	REDIAL	CLASS OF SERVICE																	
		COMMON-USE	PERSONAL			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
1		10-14																					
2		15-19																					
3		20-24																					
4		25-29																					
5		30-34																					
6		35-39																					
7		40-44																					
8		45-49																					
9		50-54																					
10		55-59																					
11		60-64																					
12		65-69																					
13		70-74																					
14		75-79																					
15		80-84																					
16		85-89																					
17		90-94																					
18		95-99																					
19																							
20																							
21																							
22																							
23																							
24																							
25																							

- NOTES: 1. IF TABLE IS TO BE ASSIGNED AS A PERSONAL TABLE, STRIKE OUT COMMON-USE ENTRY ACCESS NUMBERS. ENTER NEW ENTRY ACCESS NUMBERS IN PERSONAL COLUMN.
2. CHECK IN REMAINING COLUMNS AS REQUIRED FOR EACH TABLE



PERSONAL TABLE PROGRAMMING FORM SC-2
(SYSTEM MUST BE IN EXTENDED PROGRAMMING MODE)

CHISEL SPEED CALL

TABLE	EGPT NUMBER DIAL EQUIPMENT NO. 11-112 181-2546 OR DELETE	NOTE 2 & 13 ACCESS NUMBER DIAL ACCESS NO.	NOTE 3 NUMBER MEDIAL NOO OR DELETE
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			

NOTES

1. USE THE ENTRIES MADE ON FORM SC-1 FOR THE PERSONAL TABLES BY TRANSFERRING THESE IN TURN TO THEIR RESPECTIVE COLUMNS AGAINST THE SAME TABLE NUMBERS ON FORM SC-2. (COMMON - USE TABLES HAVE BLANK ENTRIES)
2. ONLY THE FIRST ACCESS NUMBER FOR EACH PERSONAL TABLE IS REQUIRED TO BE ENTERED. THE REMAINING ACCESS NUMBERS ARE AUTOMATICALLY ALLOCATED FOR THE TABLE.
3. THE SAVED NUMBER MEDIAL OPERATOR IS INITIALLY OMITTED IF NOT REQUIRED. FOR SUBSEQUENT PROGRAMMING SEE NOTES 8 & 9.
4. PERSONAL TABLE DATA IS PROGRAMMED IN EXTENDED PROGRAMMING MODE. SEE SECTION MITL9105/9110-090-210 - NA APPENDIX 2 FOR FULL DETAILS.
5. THE ENTER BUTTON MUST BE PRESSED TO ENTER EACH TABLE'S DATA.
6. REMOVING A PERSONAL TABLE REMOVES ALL ITS CONTENTS, ACCESS NUMBERS AND MEDIAL VALUE IF ANY.
7. TO REMOVE A PERSONAL TABLE
 SPEED CALL [TABLE] [DIAL TABLE NUMBER] [EGPT NUMBER] [DELETE] [ENTER]
8. TO ADD A MEDIAL ATTRIBUTE
 SPEED CALL [TABLE] [DIAL TABLE NUMBER] [NUMBER MEDIAL] [ADD] [ENTER]
9. TO REMOVE A MEDIAL ATTRIBUTE
 SPEED CALL [TABLE] [DIAL TABLE NUMBER] [NUMBER MEDIAL] [DELETE] [ENTER]
10. TO CHANGE A SPEED CALL ACCESS NUMBER
 SPEED CALL [TABLE] [DIAL TABLE NUMBER] [ACCESS NUMBER] [DIAL NEW ACCESS NUMBER] [ENTER]

SEE NOTE 5 TO ENTER DATA

PROGRAMMING PERSONAL TABLES

MAP210- 242


Issue 1, September 1983

Sheet 11 of 11

TABLE 242-2

ERROR CODE	DESCRIPTION
E4	Indicates attempt to enter access number (Step 10) for a common-use table
E4	Indicates attempt made to allocate number radial digits in a common-use table (Step 12)
E5	Indicates number radial already exists for another table (Step 12) assigned to the same equipment
E5	Indicates access number (Step 10) already exists for another table assigned to the equipment

(15A) Press ENTER key.
 (15B) Go to MAP210-274 if all programming is complete.



CONVERT TABLE FROM PERSONAL
TO COMMON-USE

MAP210-243

Issue 1, September 1983

Sheet 1 of 3

NOTE

Common-use Tables do not require programming. This MAP is the procedure used to convert a Personal Table to a Common-use Table.

NOTES

1. Prior to making programming entries on this MAP, Form SC-2 must have been completed. The completed form is used in conjunction with the relevant steps noted in this MAP.


2. After digit entries are made (e.g., Step (4)), the bell may ring and an error code may appear in the DESTINATION display when the key in the next sequence (i.e., the relevant function key and its digit entries) in order to correct the previous entry. Figure 243-2 shows a typical error code entry.

TABLE 243-1

ERROR CODE	DESCRIPTION
E3	The table number entered is not valid for the current size CONFIGURATION
E6	The CONFIGURATION (MAP210-221) entered does not include Speed Call



(3A) Press TABLE key



CONVERT TABLE FROM PERSONAL TO COMMON-USE
MAP210- 243
Issue 1, September 1983
Sheet 2 of 3





Figure 243-1 Table Number Display




Figure 243-2 Typical Entry Display




Figure 243-3 Typical Error Code Display





Figure 243-4 Completed Entry Display

CONVERT TABLE FROM PERSONAL TO COMMON-USE
--


MAP210- 243

Issue 1, September 1983

Sheet 3 of 3



CODE TABLE QUANTITY SELECTION OR CHANGE
MAP210- 250
Issue 1, September 1983
Sheet 2 of 2



- (4A) Press TABLE QUANT.
- (4B) Dial Table quantity digits (figure 250-1).
- (4C) Press Enter.




Figure 250-1

AREA CODE TABLE PROGRAMMING


MAP210-251

Issue 1, September 1983


Sheet 1 of 4

NOTE

For an example of the programming form refer to Figure 251-2.



AREA CODE TABLE PROGRAMMING
MAP210- 251
Issue 1, September 1983
Sheet 2 of 4



AREA CODE TABLE PROGRAMMING
MAP210-251
Issue 1, September 1983
Sheet 3 of 4





Figure 251-1

DIMMARDOPN SJRAT SOOD AREA
 182-07574M
 CSST 10000000 7 0000
 4 to 2 200/0

(2) next

AREA CODE TABLE PROGRAMMING FORM ARS - 3

PRESS

PRESS <input type="button" value="AREA CODE"/> DIAL 3 DIGITS	PRESS <input type="button" value="ROUTE TABLE"/> DIAL 1-15 OR DELETE	PRESS <input type="button" value="ENTER"/> NOTE 2
200-212	15	
213	2	
214-219	15	
300-399	15	
400-410	15	
411	0	
412-499	15	
500-599	15	
600-610	15	
611	0	

AREA CODE DIAL 3 DIGITS	ROUTE TABLE DIAL 1-15 OR DELETE	ENTER NOTE 2
612-699	0	
700-713	15	
714	2	
715-719	0	
800	2	
800-817	15	
818	1	
819	15	
900	14	
901-910	15	

AREA CODE DIAL 3 DIGITS	ROUTE TABLE DIAL 1-15 OR DELETE	ENTER NOTE 2
911	0	
912-919	15	


1. TO VIEW AN ENTRY

PRESS

TO REASSIGN ROUTE TABLE NUMBERS

PRESS

NOTE: 1. ROUTE TABLE 15 IS THE UNIVERSAL ROUTING TABLE I.E. AREA CODE DIGITS NOT ENTERED ARE AUTOMATICALLY IN ROUTE TABLE 15.
2. ENTER BUTTON MAY BE PRESSED AFTER ROUTE TABLE ENTRY OR AFTER ALL ROUTE ENTRIES




FINISH

REVIEW AREA CODE TABLE PROGRAMMING

MAP210-252

Issue 1, September 1983

Sheet 1 of 2



REVIEW AREA CODE TABLE PROGRAMMING
MAP210- 252
Issue 1, September 1983
Sheet 2 of 2





Figure 252-1 Area Code Table

X5841

DELETE AN AREA CODE TABLE


MAP210- 253

Issue 1, September 1983


Sheet 1 of 5

NOTE

Refer to Figure 253-1 and Figure 253-2 for an example of the programming form.



DELETE AN AREA CODE TABLE
MAP210- 253
Issue 1, September 1983
Sheet 2 of 5




AREA CODE/OFFICE CODE
PROGRAMMING FORM ARS 4B


FOR LOCAL AREA CODE




TO DELETE, ADD OR VIEW FOR ARS 4A



TO VIEW OFFICE WIDE TABLE



TO VIEW OFFICE CODE ENTRIES



AREA CODE/OFFICE CODE PROGRAMMING


MAP210- 254

Issue 1, September 1983

Sheet 1 of 4


NOTE

For an example of the programming form see Figures 253-1, 253-2.



AREA CODE/OFFICE CODE PROGRAMMING
MAP210- 254
Issue 1, September 1983
Sheet 2 of 4

NOTE
 For an example of the programming
 form see Figure 253.1-225 through 253.1-226



(4A) Select 2-numbered programming
 Overlay with Automatic Route
 Location
 (4B) Press AREA button
 AND LED lit

AREA CODE/OFFICE CODE PROGRAMMING	1000 AREA DISPATCH
MAP210-254	REV 01/83
Issue 1, September 1983	
Sheet 3 of 4	






Figure 254-1

SECTION MITL9105/9110-090-210-NA

AREA CODE/OFFICE CODE PROGRAMMING	10000 AREA COMMUNICATIONS
MAP210- 254	SEC-01210A
Issue 1, September 1983	Page 2 of 4
Sheet 4 of 4	3 to 2 read



REVIEW OR DELETE PART OR ALL AREA CODE/OFFICE CODE


MAP210-255

Issue 1, September 1983

Sheet 1 of 4

NOTE

For an example of the programming form refer to Figures 253-1 and 253-2.



REVIEW OR DELETE PART OR ALL AREA CODE/OFFICE CODE	WSIVR ERA JJ
MAP210- 255	885-0129AS
Issue 1, September 1983	Issue 1, 1983
Sheet 2 of 4	2 of 4






Fig. 255-1
Code Table

REVIEW OR DELETE PART OR ALL AREA CODE/OFFICE CODE


MAP210- 255

Issue 1, September 1983

Sheet 3 of 4



REVIEW OR DELETE PART OR ALL AREA CODE/OFFICE CODE
MAP210- 255
Issue 1, September 1983
Sheet 4 of 4



PROGRAM MODIFY DIGITS


MAP210- 256

Issue 1, September 1983

Sheet 1 of 3


NOTE

Refer to Fig. 256-1 for an example of the programming form.




- (3A) Select Extended Programming Overlay with Automatic Route Selection
 (3B) Press ARS button.
 • ARS LED lit

PROGRAM MODIFY DIGITS
MAP210- 256
Issue 1, September 1983
Sheet 2 of 3



TO REVIEW OR DELETE MODIFY DIGIT TABLES
MAP210-257
Issue 1, September 1983
Sheet 1 of 4

NOTE
For an example of the form refer to Fig. 256-1.



- (3A) Select Extended Programming Overlay with Automatic Route Selection.
- (3B) Press ARS button.
* ARS LED lit.

TO REVIEW OR DELETE
MODIFY DIGIT TABLES

MAP210- 257

Issue 1, September 1983

Sheet 2 of 4







Fig. 257-1
Modify Digits

TO REVIEW OR DELETE MODIFY DIGIT TABLES	NO WAIVER OF TIDIC YR000
MAP210- 257	YES -STORAS
Issue 1, September 1983	ISSUE 1, 1983
Sheet 3 of 4	3 of 4



TO REVIEW OR DELETE MODIFY DIGIT TABLES	NO WRITER OF THIS YR00M
MAP210- 257	255 -01 01AM
Issue 1, September 1983	00000 1 0000
Sheet 4 of 4	4 to 5 0000



ROUTE TABLE PROGRAMMING


MAP210-258

Issue 1, September 1983


Sheet 1 of 6

NOTE


For an example of the programming form refer to Fig. 258-1.




ROUTE TABLE PROGRAMMING
MAP210- 258
Issue 1, September 1983
Sheet 2 of 6



ROUTE TABLE PROGRAMMING	STUD
MAP210-258	83C-0105A
Issue 1, September 1983	1 of 6
Sheet 3 of 6	3 to 4



ROUTE TABLE PROGRAMMING	STUD
MAP210- 258	SEC -012141
Issue 1, September 1983	ISSUE 1
Sheet 4 of 6	9 to 11



IS TO D 3-DRA MUA DPT MALLUPP LUSTY STUOH

PRESS **ARS**

ROUTE TABLE PROGRAMMING FORM ARS-6 (1 OF 2)

BASIC SCHEDULE DATA				SCHEDULE CHOICES									
PRESS	PRESS	PRESS	PRESS	A			B			C			PRESS
ROUTE TABLE	ROUTE NUMBER	TRUNK GROUP	MODIFY DIGITS	SCHED A	CHOICE NUMBER	ROUTE NUMBER	SCHED B	CHOICE NUMBERS	ROUTE NUMBER	SCHED C	CHOICE NUMBER	ROUTE NUMBER	ENTER
DIAL 1-15 OR PRESS DELETE	DIAL 1-4	DIAL 1-12 OR DELETE		DIAL 4 DIGITS OR PRESS DELETE	DIAL 1-4	DIAL 1-4	DIAL 4 DIGITS OR PRESS DELETE	DIAL 1-4	DIAL 1-4	NOTE 1	DIAL 1-4	DIAL 1-4	AFTER EACH BLOCK
	1				1			1			1		ENTER
	2				2			2			2		
	3				3			3			3		
	4				4			4			4		
	1				1			1			1		ENTER
	2				2			2			2		
	3				3			3			3		
	4				4			4			4		
	1				1			1			1		ENTER
	2				2			2			2		
	3				3			3			3		
	4				4			4			4		

NOTE 1
DO NOT DIAL TIME AFTER PRESSING SCHEDULE C. IT WILL BE IN EFFECT ANY TIME A OR B ARE NOT.

SCHED C BUTTON



ROUTE TABLE PROGRAMMING FORM ARS-8 (2 OF 2)

1. TO DELETE A ROUTE TABLE

PRESS DIAL 1-15 PRESS

5. TO VIEW ROUTE CHOICES IN A SCHEDULE

PRESS DIAL 1-15

2. TO DELETE A ROUTE NUMBER BEING DISPLAYED

PRESS

OR

PRESS DIAL 1-4 PRESS

6. TO VIEW SCHEDULES IN A ROUTE CHOICE:

PRESS DIAL 1-15

3. TO DELETE A ROUTE CHOICE BEING DISPLAYED

PRESS

OR

PRESS DIAL 1-4 PRESS

(SCHED "X" IS SCHED A, B, OR C)

7. TO VIEW ROUTES TABLES:

PRESS DIAL 1-15

4. TO VIEW ROUTE TABLES

PRESS PRESS



TO REVIEW OR DELETE A ROUTE TABLE


MAP210- 259

Issue 1, September 1983


Sheet 1 of 3

NOTE

For an example of the programming form refer to Fig. 258-1.



TO REVIEW OR DELETE A ROUTE TABLE
MAP210- 259
Issue 1, September 1983
Sheet 2 of 3




TO REVIEW OR DELETE A ROUTE TABLE

MAP210-259

Issue 1, September 1983

Sheet 3 of 3




REVIEW OR DELETE ROUTES


MAP210-260

Issue 1, September 1983


Sheet 1 of 3



REVIEW OR DELETE ROUTES
MAP210-260
Issue 1, September 1983
Sheet 2 of 3



REVIEW OR DELETE ROUTES
MAP210-260
Issue 1, September 1983
Sheet 3 of 3



PROGRAM A PRIME KEY


MAP210-270

Issue 1, September 1983

Sheet 1 of 10


NOTE

For an example of the programming form see Figures 270-2 and 270-3.



PROGRAM A PRIME KEY
MAP210- 270
Issue 1, September 1983
Sheet 2 of 10

WARNING
 0 or 1 Toll Control cannot be enabled with Multi-Digit Toll Control



STOP






Fig. 270-1 X6043

PROGRAM A PRIME KEY	BY A. BLANDIN
MAP210-270	BY A. BLANDIN
Issue 1, September 1983	BY A. BLANDIN
Sheet 3 of 10	BY A. BLANDIN



PROGRAM A PRIME KEY
MAP210- 270
Issue 1, September 1983
Sheet 4 of 10

WARNING
 An Announce Port requires that the equipment number used as an Announce Port is dedicated to that task.




PROGRAM A PRIME KEY

MAP210-270

Issue 1, September 1983

Sheet 5 of 10





SUPERSET 4 PROGRAMMING S4 - 2
SEE FORM S4-1 FOR PROGRAMMING PROCEDURES

SET EOPT NUMBER OF SUPERSET 2-112 OR 161-256

1. PRIME KEY DEFINITION

PRIME KEY	LISTED NUMBER DIAL 1-4 DIGIT DIRECTORY NUMBER	COS NUMBER DIAL 1-18	TOLL DENY	PRESS OR OR CODE 1,3,3	ADD OR DELETE	BUSY LAMP DIAL 1-200 OR DELETE	PICKUP GROUP DIAL 1-30 OR DELETE	ANNOUNCE EOPT DIAL 2-256 OR DELETE	ENTER
-----------	--	-------------------------	-----------	------------------------------	---------------------	---	---	---	-------

2. NON - PRIME KEY DEFINITION

NOTE 1	SET KEY NUMBER 2-15	TYPE	DIAL KEY TYPE (1,3, OR 4 DIGITS) DEPENDING ON TYPE OR DELETE (NOTE 2)	LISTED NUMBER	DIAL 1-4 DIGIT DIRECTORY NUMBER	TRUNK EOPT NUMBER	DIAL 10-256 FOR DIS TYPE (NOTE 3)
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							

NOTES

- UNPROGRAMMED KEYS DEFAULT TO SPEED CALL
- USE LISTINGS BELOW TO PRODUCE THE ONE, THREE OR FOUR DIGIT KEY TYPE CODES
 - A. LINE TYPE FIRST DIGIT
 - PRIME LINE 1 - NO VARIANTS
 - PERSONAL OUT LINE 2 - SPECIFY VARIANTS
 - MULTIPLE CALL 3 - B.C.D. BELOW
 - DIRECT TRUNK SELECT 4 - SPECIFY VARIANTS
 - PRIVATE LINE 5 - B.C. BELOW
 - KEY LINE 2 - SPECIFY R.C. + 1
 - B. ERASURE VARIANT SECOND DIGIT
 - BOTH WAY 1
 - INCOMING ONLY 2
 - OUTGOING ONLY 3
 - C. RING VARIANT THIRD DIGIT
 - IMMEDIATE RING 1
 - DELAYED RING 2
 - NO RING 3
 - D. SECRETARIAL VARIANT FOURTH DIGIT
 - NON - SECRETARIAL 1
 - SECRETARIAL 2
- IT IS RECOMMENDED THAT SLOT 1 CONTAIN A LINE CASE, IF SO, THE FIRST POSSIBLE TRUNK EOPT NUMBER IS 010 (SLOT 2)

PRESS AFTER DEPRESSING EACH KEY

SUPERSET 4 PROGRAMMING S4 - 2
 (SEE FORM S4-1 FOR PROGRAMMING PROCEDURES)



SET DIAL EDP# NUMBER OF SUPERSET 3-112 OR 3-113 3-112 OR 3-113 3-112 OR 3-113

1. PRIME KEY DEFINITION

PRIME KEY	LISTED MEMBER DIAL 1-4 DIGIT DIRECTORY NUMBER	COO MEMBER DIAL 1-16	TOLL DENY	PRESS OR OR COO 1,2,3	ADD DELETE	BUSY LAMP DIAL 1-256 OR	PICKUP GROUP DIAL 1-30 OR	TRANSFER EDP# DIAL 2-256 OR	DELETE	ENTER
------------------	---	--------------------------------	------------------	------------------------------------	-----------------------------	--------------------------------------	--	--	---------------	--------------

2. NON - PRIME KEY DEFINITION

NOTE 1 SET KEY NUMBER DIAL 2-15	DIAL KEY TYPE (1,2,3 OR 4 DIGITS DEPENDENT ON TYPE OR DELETE PAGE 2)	LISTED NUMBER	DIAL 1-4 DIGIT DIRECTORY NUMBER	TRUNK EDP# NUMBER	DIAL 19-256 FOR DIS TYPE NOTE 3
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					

NOTES

- UNDEFINED KEYS DEFAULT TO SPEED CALL
- USE LISTINGS BELOW TO PROVIDE THE ONE, THREE OR FOUR DIGIT KEY TYPE CODES
 - A. LINE TYPE FIRST DIGIT
 - PERSONAL OTO LINE 6
 - NO VARIANTS
 - B. MULTIPLE CALL (B.C.D. BELOW)
 - DIRECT TRUNK SELECT 4
 - SPECIFY VARIANTS
 - PRIVATE LINE 5
 - B.C. BELOW
 - KEY LINE 7
 - SPECIFY B.C. + 1
 - C. DIRECTION VARIANT
 - WITH WAY 1
 - INCOMING ONLY 2
 - OUTGOING ONLY 3
 - D. RING VARIANT
 - IMMEDIATE RING 1
 - DELAYED RING 2
 - NO RING 3
 - E. SECRETARIAL VARIANT
 - NON - SECRETARIAL 1
 - SECRETARIAL 2
- IT IS RECOMMENDED THAT PAGE 1 CONTAIN A LINE CARD, IF SO THE FIRST POSSIBLE TRUNK EDP# NUMBER IS 910 SLOT 2

PRESS AFTER OPENING EACH KEY

SUPERSET 4 PROGRAMMING S4-1

SHEET 1 OF 2



1. TO ENTER SUPERSET 4 PROGRAMMING MODE

PLACE SYSTEM IN EXTENDED
PROGRAMMING MODELAMP TEST
LED FLASHESSUPER
SET

SYSTEM IS NOW READY FOR SUPERSET 3 PROGRAMMING

2. TO DELETE THE PRIME LINE (ALL APPEARANCES MUST BE DELETED BEFORE PRIME LINE CAN BE DELETED)

SET
EQPT
NUMBERDIAL EQPT NUMBER
OF SUPERSETPRIME
KEY

DELETE

ENTER

THE EQUIPMENT NUMBER DIALLED IS NO
LONGER IDENTIFIED AS A SUPERSET 3 PRIME LINE

3. TO ADD, CHANGE OR DELETE PRIME LINE PARAMETERS.

SET
EQPT
NUMBERDIAL EQPT NUMBER
OF SUPERSETPRIME
KEY

.

• KEY IDENTIFYING PARAMETER
I.E. ONE OF
LISTED NUMBER
COS NUMBER
TOLL DENY
BUSY LAMP NUMBER
PICKUP GROUP
ANNOUNCE EQPT NUMBER

3A TO ADD OR CHANGE: DIAL
NUMBER AS SHOWN
ON FORM S4-2

3B TO DELETE

DELETE

ENTER

THE SELECTED PARAMETER HAS BEEN ADDED
CHANGED OR DELETED AS REQUIRED

4. TO DELETE A NON-PRIME LINE


SET
EQPT
NUMBERDIAL EQPT NUMBER
OF SUPERSETSET
KEY
NUMBERDIAL
KEY#
12-15

DELETE

ENTER

THE SELECTED NON-PRIME LINE IS NOW DELETED

PROGRAM A PRIME KEY
MAP210- 270
Issue 1, September 1983
Sheet 10 of 10



PROGRAM A NON-PRIME KEY


MAP210-271

Issue 1, September 1983


Sheet 1 of 6

NOTE

For an example of the programming forms see Figures 270-2 and 270-3.




PROGRAM A NON-PRIME KEY
MAP210- 271
Issue 1, September 1983
Sheet 2 of 6



PROGRAM A NON-PRIME KEY
MAP210-271
Issue 1, September 1983
Sheet 3 of 6

NOTE 1
 When programming Multiple Call Line appearances, Type Options B, C and D must be programmed and a listed number specified. When programming Direct Trunk Select and Private Line types, only Type Options B and C must be programmed and a Trunk Eqpt. Number specified. When programming a Personal Outgoing Line there are no variants. When programming key line appearances, B and C and the digit 1 must be programmed.

(8A) Press TYPE button
 * TYPE LED lit
 Dial type (Note 1) (Figure 271-1) (Table 271-1) (Note 2)



(11A) Press LISTED NUMBER button
 * LISTED NUMBER LED lit
 Dial 1- to 4-digit directory number (Figure 271-1)
 (11B) Press ENTER button





Fig. 271-1 Typical Type

PROGRAM A NON-PRIME KEY
MAP210- 271
Issue 1, September 1983
Sheet 4 of 6

NOTE 1
When programming Multiple Call Line...
...Type Options B, C and D...
...must be programmed and a test...
...must be programmed.



- (13A) Press TRUNK EQPT NUMBER button
- TRUNK EQPT NUMBER LED lit
- Dial trunk equipment number
- (13B) Press ENTER button (Figure 271-2)




Fig. 271-2 Typical Entry



PROGRAM A NON-PRIME KEY

MAP210-271

Issue 1, September 1983

Sheet 5 of 6

NOTE 2


(a) **KEY LINE:** Key Lines are "appearances" of a listed number in the system. The listed number may be that of a prime line or may only exist on the particular key. When one set seizes the line, all other appearances of that listed number are busy.

(b) **MULTIPLE CALL:** MULTIPLE CALL keys are also appearances of a listed number in the system. They are different from key line appearances in that while one appearance of the listed number may be busy, other appearances of that listed number will be idle.

(c) **DIRECT TRUNK SELECT:** The DIRECT TRUNK SELECT key is used to represent specified trunks. Each DTS key is assigned a trunk equipment number. DIRECT TRUNK SELECT keys may share the same trunk equipment number. When a shared DTS trunk is in use by one user in the system, all other DTS keys assigned to that trunk are busy.

(d) **PRIVATE LINE:** A Private Line is similar to a DTS line except that a Transfer/Conference cannot be performed.

(e) **PERSONAL OUTGOING LINE:** A Personal Outgoing Line is similar to a Multiple Call appearance of a prime key on a SUPERSET. It is considered to be an appearance of the set's prime line. Having this key guarantees that there is always at least one free line on the set (for an outgoing call) should all other lines be busy.



PROGRAM A NON-PRIME KEY
MAP210- 271
Issue 1, September 1983
Sheet 6 of 6

**TABLE 271-1
TYPE OPTIONS**

A TYPE (major)
<ul style="list-style-type: none"> • *1st digit: represents the line type for the key. <p>1 = PRIME KEY 2 = KEY LINE 3 = MULTIPLE CALL 4 = DIRECT TRUNK SELECT 5 = PRIVATE LINE 6 = PERSONAL OUTGOING LINE</p>
B TYPE
<ul style="list-style-type: none"> • *2nd digit: represents the Direction Variant. <p>1 = BOTH WAY 2 = INCOMING ONLY 3 = OUTGOING ONLY</p>
C TYPE
<ul style="list-style-type: none"> • *3rd digit: represents the Ring Variant. <p>1 = IMMEDIATE RING 2 = DELAYED RINGING 3 = NO RING</p>
D TYPE
<ul style="list-style-type: none"> • *4th digit: represents the Secretarial Variant. <p>1 = NON-SECRETARIAL 2 = SECRETARIAL</p>

DELETE A NON-PRIME KEY


MAP210-272

Issue 1, September 1983

Sheet 1 of 3

NOTE

For an example of the programming forms see Figures 270-2 and 270-3.




DELETE A NON-PRIME KEY

MAP210- 272

Issue 1, September 1983

Sheet 3 of 3



DELETE A PRIME KEY


MAP210- 273

Issue 1, September 1983


Sheet 1 of 3

NOTE


For an example of the programming forms see Figures 270-2 and 270-3.



DELETE A PRIME KEY
MAP210- 273
Issue 1, September 1983
Sheet 2 of 3



DELETE A PRIME KEY
MAP210- 273
Issue 1, September 1983
Sheet 3 of 3




CHANGING ANY KEY

MAP210-274

Issue 1, September 1983

Sheet 1 of 5



CHANGING ANY KEY
MAP210- 274
Issue 1, September 1983
Sheet 2 of 5






Fig. 274-1

CHANGING ANY KEY

MAP210-274

Issue 1, September 1983

Sheet 3 of 5



CHANGING ANY KEY
MAP210- 274
Issue 1, September 1983
Sheet 4 of 5






Fig. 274-2 Typical Change X8047

- (14A) Press SET KEY NUMBER button
 - SET KEY NUMBER LED lit
- (14B) Dial set key number
- (14C) Press ENTER button

- (15A) Press SET KEY NUMBER button
 - SET KEY NUMBER LED lit
- (15B) Press TYPE button
 - TYPE LED lit
- (15C) If the line being programmed is not a Personal Outgoing Line, press one of the two following buttons:
 - LISTED NUMBER
 - TRUNK EQPT NUMBER
- (15D) Press ENTER button



CHANGING ANY KEY
MAP210- 274
Issue 1, September 1983
Sheet 5 of 5



MOVING A SUPERSET


MAP210- 275

Issue 1, September 1983


Sheet 1 of 3

NOTE


For an example of the programming forms see Figures 270-2 and 270-3.



MOVING A SUPERSET
MAP210- 275
Issue 1, September 1983
Sheet 2 of 3



MOVING A SUPERSET
MAP210-275
Issue 1, September 1983
Sheet 3 of 3





REVIEW SUPERSET PROGRAMMING

MAP210-276

Issue 1, September 1983


Sheet 1 of 5





REVIEW SUPERSET PROGRAMMING
MAP210- 276
Issue 1, September 1983
Sheet 3 of 5

- (7A) Press one of the following keys to review the appropriate information:
- ▲ LISTED NUMBER
 - ▲ COS NUMBER
 - ▲ TOLL DENY
 - ▲ BUSY LAMP
 - ▲ PICKUP GROUP
 - ▲ ANNOUNCE EQPT NUMBER




REVIEW SUPERSET PROGRAMMING


MAP210-276

Issue 1, September 1983

Sheet 4 of 5



REVIEW SUPERSET PROGRAMMING
MAP210- 276
Issue 1, September 1983
Sheet 5 of 5




TERMINATING PROGRAMMING

MAP210- 284

Issue 1, September 1983

Sheet 1 of 1



**SX-100®/SX-200®
SUPERSWITCH®
AUTOMATIC CALL DISTRIBUTION SYSTEM
SYSTEM TEST PROCEDURES
GENERIC ACD**

	CONTENTS	PAGE
1. INTRODUCTION		1
General		1
Reason for Issue		1
SUPERSET 4™		1
SUPERSET 3™		1
2. DETAILED TEST PROCEDURES		1
General		1
System Test Procedures		1
APPENDIX 1		
MITEL ACTION PROCEDURES		A1-1
APPENDIX 2		
EXTENSION TESTS		A2-1/2
Set Up Test Equipment (MAP215-201)		A2-3
Broker's Call (MAP215-202)		A2-5
Call Forwarding - Busy (MAP215-203)		A2-7
Call Forwarding - Don't Answer (MAP215-204)		A2-9
Call Forwarding - Follow Me (MAP215-205)		A2-11
Call Park (MAP215-206)		A2-13
Call Pickup (MAP215-207)		A2-15
Camp-On (MAP215-208)		A2-17/18
Consultation Hold/Transfer/Add-On (MAP215-209)		A2-19
Automatic Callback - Don't Answer (MAP215-210)		A2-21
Automatic Callback - Busy (MAP215-211)		A2-23
Meet-Me Conference (MAP215-212)		A2-25
Executive Busy Override (MAP215-213)		A2-27/28
Paging (MAP215-214)		A2-29/30
Do Not Disturb (MAP215-215)		A2-31
Call Hold (MAP215-216)		A2-33
Room Status (MAP215-217)		A2-37/38
Automatic Wake-Up (Alarm Call) (MAP215-218)		A2-39
Use a Common Use Speed Call (MAP215-219)		A2-41/42
Personal Speed Call (MAP215-220)		A2-43/44
External Call Forwarding (MAP215-221)		A2-45
Transfer with Privacy (MAP215-222)		A2-47/48
Account Code (MAP215-223)		A2-49
Hands-Free Station (MAP215-224)		A2-51/52

Copyright of MITEL Corporation 1983

1. INTRODUCTION

General

1.01 This Section details the system test procedures to be performed after the system installation (Section MITL9105/9110-090-200-NA) and programming (Section MITL9105/9110-090-210-NA) have been completed. Upon completion of the tests listed in this Section, all programmed system options and features will have been checked.

Reason for Issue

1.02 This Section has been issued to include the system test procedures for the extensions and the console for the ACD system.

SUPERSET 4

1.03 The SUPERSET 4 is similar to a standard telephone in that both are subject to Class Of Service limitations. To ensure that all Class Of Service related features it is only necessary to perform the System tests for that particular Class Of Service at a standard telephone. To test the actual mechanical functionality of the SUPERSET 4 see Section MITL9105/9110-090-320-NA.

SUPERSET 3

1.04 The SUPERSET 3 is similar to a standard telephone in that both are subject to Class Of Service limitations. To ensure that all Class Of Service related features it is only necessary to perform the System tests for that particular Class Of Service at a standard telephone.

2. DETAILED TEST PROCEDURES

General

2.01 All test procedures in this Section are performed in accordance with MITEL Action Procedures (MAPs). An outline of the purpose and use of MAPs is contained in Appendix 1. Actual system test procedures to be used for the System are as detailed in the following paragraphs.

System Test Procedures

2.02 The System Test Procedures are divided into two appendices: Extension Tests and Console Tests. The test level relationship is given in Tables 2-1 and 2-2. Some tests may not be relevant; i.e. Hotel/Motel (H/M) options when the system is configured for a business arrangement. Tables 2-3 and 2-4 give the suggested applications of these tests as Hotel/Motel (H/M) and Business. Note: in some situations some systems may use Options that seem out of context to the Hotel/Motel and Business sections, however the relevant test should

still be performed for these options.

**TABLE 2-1
EXTENSION TESTS**

R1

TEST	APPLICATION
Set Up Test Equipment	All
Broker's Call	All
Call Forwarding - Busy	All
Call Forwarding - Don't Answer	All
Call Forwarding - Follow Me	All
Call Park	All
Call Pickup	All
Camp-On	All
Consultation Hold/Transfer/Add-On	All
Automatic Callback - Don't Answer	All
Automatic Callback - Busy	All
Meet Me Conference	All
Executive Busy Override	All
Paging	All
Do Not Disturb	All
Call Hold	All
Room Status	H/M
Automatic Wake-Up (Alarm Call)	H/M
Personal Speed Call	H/M
Common Use Speed Call	Business
External Call Forwarding	All
Transfer with Privacy	All
Account Code	Business
Hands-Free Station	All
Call Forwarding Busy/Don't Answer	All
Enable Non-CO to Trunk Connect	All
Repeated Camp-On Tones	All
Extension Reset	All

TABLE 2-2
CONSOLE TEST

R1

TEST	APPLICATION
Answer Incoming Call	All
Automatic Callback	All
Extending Internal Calls	All
Answering Recall	All
Override	All
Flexible Night Service	All
Trunk Busy Operation	All
Trunk Group Supervisor Access	All
Trunk Group Dial Access	All
Test Termination	All
Answer Incoming CO Trunk Call	All
Supervisor Do Not Disturb	All
Message Waiting	All
Supervisor Call Forwarding - Busy	All
Supervisor Call Forwarding - Don't Answer	All
Supervisor Call Forwarding - Follow Me	All
Supervisor Call Forwarding Busy/Don't Answer	All
Supervisor Controlled Conference	All
Supervisor Station Busy Out	All
Call Block	H/M
Supervisor Do Not Disturb	All
Message Registration	H/M
Controlled Outgoing Call Restriction	All
Room Status	H/M
Automatic Wake-Up (Alarm Call)	H/M
Message Waiting H/M	H/M
Console Date Display and Date Utility	All
Customer Program Dump Load	All
Controlling the Printer	All
Room Audit	H/M
System Identifier	All
Common Use Speed Call	Business
Customer Programming	All
External Call Forwarding	All
Test Audible Tone Indicators	All
SUPERSET Disconnect Alarm	All

**TABLE 2-3
EXTENSION APPLICATIONS**

R1

TEST	APPLICATION
Set Up Test Equipment	Both
Broker's Call	Business
Call Forwarding - Busy	Business
Call Forwarding - Don't Answer	Business
Call Forwarding - Follow Me	Business
Call Park	Business
Call Pickup	Business
Camp-On	Business
Consultation Hold/Transfer/Add-On	Business
Automatic Callback - Don't Answer	Business
Automatic Callback - Busy	Business
Meet Me Conference	Business
Executive Busy Override	Business
Paging	Business
Do Not Disturb	Both
Call Hold	Business
Room Status	H/M
Automatic Wake-Up (Alarm Call)	H/M
Personal Speed Call	Business
Common Use Speed Call	Business
External Call Forwarding	Business
Transfer with Privacy	Business
Account Code	Business
Hands-Free Station	Business
Call Forwarding Busy/Don't Answer	Business
Enable Non-CO to Trunk Connect	Business
Repeated Camp-On Tones	Business

TABLE 2-4
CONSOLE APPLICATION

RT

TEST	APPLICATION
Answer Incoming Call	Both
Automatic Callback	Both
Extending Internal Calls	Both
Answering Recall	Both
Override	Business
Flexible Night Service	Both
Trunk Busy Operation	Both
Trunk Group Supervisor Access	Both
Trunk Group Dial Access	Both
Test Termination	Both
Answer Incoming CO Trunk Call	Both
Supervisor Do Not Disturb	Both
Message Waiting	H/M
Supervisor Call Forwarding - Busy	Business
Supervisor Call Forwarding - Don't Answer	Business
Supervisor Call Forwarding - Follow Me	Business
Supervisor Call Forwarding Busy/Don't Answer	Business
Supervisor Controlled Conference	Business
Supervisor Station Busy Out	Both
Call Block	H/M
Supervisor Do Not Disturb	H/M
Message Registration	H/M
Controlled Outgoing Call Restriction	H/M
Room Status	H/M
Automatic Wake-Up (Alarm Call)	H/M
Message Waiting H/M	H/M
Console Date Display and Date Utility	Both
Customer Program Dump Load	Both
Controlling the Printer	Both
Room Audit	H/M
System Identifier	Both
Common Use Speed Call	Business
Customer Programming	Both
External Call Forwarding	Business
Test Audible Tone Indicators	Both
SUPERSET Disconnect Alarm	Business

APPENDIX 1

MITEL ACTION PROCEDURES

GENERAL

A1.01 Task-oriented functions in this Section are implemented using MITEL Action Procedures (MAPs).

A1.02 A MAP is a step-by-step procedure using a flow chart principle, written and illustrated where necessary to a level of detail that allows both experienced and inexperienced personnel to carry out the tasks detailed. A MAP contains two levels of information as follows:

- (a) For experienced personnel, a series of steps (level one) each numbered (n) and annotated with minimal information.
- (b) For inexperienced personnel, each step referred to in (a) above is amplified by a connected series of numbered substeps (nA) (level two).

A1.03 A typical example of a MAP is shown in Figure A1-1, with the two levels detailed.

MAP SYMBOLS

A1.04 There are four basic symbol shapes which may be used in a MAP, and are defined as follows.

A1.05 AND Block: Used to indicate a level one step that must be performed. Consists of a square with the word AND centered in the block.

A1.06 OR Block: Used to indicate a choice of level one steps, one of which must be performed. Consists of a rectangle, with the text centered in the block, and with the word OR appearing between the alternative operations.

A1.07 The rectangle is also used to border instructions which imply that the operative must perform a task outside the scope of the MAP. The text is centered in the rectangle.

A1.08 DECISION Block: Used to indicate a decision within the level one steps which must be made. The symbol is based on a hexagon with the top and bottom sides extended. Decision text is centered in the symbol.

A1.09 START/FINISH/JUMP TO Block: Used to indicate the start and finish of a MAP. Also used to indicate "jump to" points within the MAP, for example "go to (n)" or "from (n)" or "return to (n)". The

symbol is a rectangle with semicircular ends. Text is centered in the symbol.

THE OPERATORS' USE OF MAPS

Experienced Operator

A1.10 For the experienced operator to complete a task using a MAP, reference to the sequential short form level one steps is usually all that is necessary. Using Figure A1-1 as an example, the experienced operator would proceed as follows.

A1.11 A (1) makes a decision based on the information within the block. If the answer is YES, the operator must proceed to a different MAP. If the answer is NO, the operator is faced with another decision at block (2).

A1.12 At (2) if the decision is NO, there is no requirement to proceed further and the test is abandoned. This naturally results in a FINISH block. If the decision is YES, the operator proceeds to (3) and (4) in succession; i.e. dials the DID station number and completes the call to the check extension.

A1.13 The description of the instructions carried out in A1.05 and A1.06 have assumed that the level of competence of the operator is such that short form level one steps contain sufficient information, and therefore the operator reads only the center column of the MAP, top to bottom of the page.

Inexperienced Operator

A1.14 If the operator's experience is such that the level two substeps should be referred to as follows.

- (a) At (1) and (2) make the decisions called for at these steps as before.
- (b) At step (3) dial the DID station number by performing substeps (3A), (3B) and (3C).


In terms of steps and substeps, the operative follows a decision, decision then step and substep paths in the example shown.

TOOLS, TEST EQUIPMENT AND SPECIAL INSTRUCTIONS

A1.16 Any tools, test equipment or special instructions that the operator required or needs to know are stated on the first page of each MAP. If the MAP is long, and contains a number of sub procedures, these are listed in synopsis form on the first page.

SECTION MITL9105/9110 98-215

ANSWER DID TRUNK CALL
MAP215-152
Issue 1, January 00
Sheet 1 of 2



AS 92

M110

Figure A1-1 Typical MAP Page

APPENDIX 2

EXTENSION TESTS

A2.01 The following test are a series of extension tests. Specific reference should be made to Table 2-1 and Table 2-3. These Tables will determine if the test is relevant to the system application.

TABLE A2-1
 EXTENSION TESTS

R1

ORDER	OPTION	MAP No.
1	Set Up Test Equipment	215-201
2	Broker's Call	215-202
3	Call Forwarding - Busy	215-203
4	Call Forwarding - Don't Answer	215-204
5	Call Forwarding - Follow Me	215-205
6	Call Park	215-206
7	Call Pickup	215-207
8	Camp-On	215-208
9	Consulation Hold/Transfer/Add-On	215-209
10	Automatic Callback - Don't Answer	215-210
11	Automatic Callback - Busy	215-211
12	Meet Me Conference	215-212
13	Executive Busy Override	215-213
14	Paging	215-214
15	Do Not Disturb	215-215
16	Call Hold	215-216
17	Room Status	215-217
18	Automatic Wake-Up (Alarm Call)	215-218
19	Common Use Speed Call	215-219
20	Personal Speed Call	215-220
21	External Call Forwarding	215-221
22	Transfer with Privacy	215-222
23	Account Code	215-223
24	Hands-Free Station	215-224
25	Call Forwarding Busy/Don't Answer	215-225
26	Enable Non-CO to Trunk Connect	215-226
27	Repeated Camp-On Tones	215-227
28	Extension Reset	215-228

APPENDIX 3

CONSOLE TESTS

A3.01 The following tests are a series of console tests. Specific reference should be made to Table 2-2 and Table 2-4. These Tables will determine if the test is relevant to the system application.

TABLE A3-1
CONSOLE TESTS

R1

ORDER	TEST	MAP No.
1	Answer Incoming Call	215-300
2	Automatic Callback	215-301
3	Extending Internal Calls	215-302
4	Answering Recall	215-303
5	Override	215-304
6	Flexible Night Service	215-305
7	Trunk Busy Operation	215-306
8	Trunk Group Supervisor Access	215-307
9	Trunk Group Dial Access	215-308
10	Test Termination	215-309
11	Answer Incoming CO Trunk Call	215-310
12	Supervisor Do Not Disturb	215-311
13	Message Waiting	215-312
14	Supervisor Call Forwarding - Busy	215-313
15	Supervisor Call Forwarding - Don't Answer	215-314
16	Supervisor Call Forwarding - Follow Me	215-315
17	Supervisor Call Forwarding - Busy/Don't Answer	215-316
18	Supervisor-Controlled Conference	215-317
19	Supervisor Station Busy-out	215-318
20	Block	215-319
21	Supervisor Do Not Disturb (H/M)M	215-320
22	Message Registration	215-321
23	Controlled Outgoing Call Restriction	215-322
24	Room Status	215-323
25	Automatic Wake-Up (Alarm Call)	215-324
26	Message Waiting H/M	215-325
27	Console Date Display and Date Utility	215-326
28	Customer Program Dump Load	215-327
29	Controlling the Printer	215-328
30	Room Audit	215-329
31	System Identifier	215-330
32	Common Use Speed Call	215-331
33	Customer Programming	215-332
34	External Call Forwarding	215-333
35	Test Audible Tone Indicators	215-334
36	Single Digit Dialing	215-335
37	Common Alerting Devices	215-336
38	Answer DID Trunk Call	215-337
39	SUPERSET Disconnect Alarm	215-338

SET UP TEST EQUIPMENT

MAP215-201

Issue 1, September 1983

Sheet 1 of 2

TEST EQUIPMENT REQUIRED

Maintenance Handset (BUTT-IN)
Console
1, 2, and 3 Telephone Sets (Check Extensions located within reach of equipment cabinet).

Note: Check extension must have access to all features to be tested.






Fig. 201-2

X266


SET UP TEST EQUIPMENT
MAP215- 201
Issue 1, September 1983
Sheet 2 of 2



BROKER'S CALL	LEAD EXTENSION
MAP215- 202	100-101548
Issue 1, September 1983	Issue 1 of 2
Sheet 1 of 2	1 to 2



BROKER'S CALL	JAN 1 1983
MAP215- 202	101-215-NA
Issue 1, September 1983	
Sheet 2 of 2	




CALL FORWARDING - BUSY


MAP215- 203

Issue 1, September 1993


Sheet 1 of 2



CALL FORWARDING - BUSY
MAP215- 203
Issue 1, September 1983
Sheet 2 of 2




CALL FORWARDING - DON'T ANSWER	
MAP215-204	401-215-2111
Issue 1, September 1983	Page 7 of 11
Sheet 1 of 2	1 10 1 1983



CALL FORWARDING - DON'T ANSWER	
MAP215- 204	DATE: 21 SEP 83
Issue 1, September 1983	ISSUE: 1 OF 1
Sheet 2 of 2	PAGE: 2 OF 2

- AT CONSOLE**
- (4A) Dial test line number
 - * Ringing tone
 - * DESTINATION display shows number of test line and its class
 - * ATT and RING lamps lit
 - (4B) Wait 45 s - no change
 - (4C) Press console RELEASE
 - * Console idle




CHECK CALL FORWARDING - DON'T ANSWER INACTIVE

CALL FORWARDING - FOLLOW ME

MAP215- 205


Issue 1, September 1983

Sheet 1 of 2



CALL FORWARDING - FOLLOW ME
MAP215- 205
Issue 1, September 1983
Sheet 2 of 2

- AT CONSOLE**
- (4A) Dial test line number
 - * DESTINATION display shows number of test line and its class
 - * ATT and RING lamps lit
 - (4B) Press console **RELEASE**
 - * Console Idle




TA MAINTENANCE MAIL DEST
 (A) Dial number of test line
 (B) Check destination display
 (C) Press console RELEASE
 (D) Console Idle

TA MAINTENANCE MAIL DEST
 (A) Dial number of test line
 (B) Check destination display
 (C) Press console RELEASE
 (D) Console Idle


TA MAINTENANCE MAIL DEST
 (A) Dial number of test line
 (B) Check destination display
 (C) Press console RELEASE
 (D) Console Idle

CALL PARK
MAP215-206
Issue 1, September 1983
Sheet 1 of 2



SECTION MITL9105/9110-090-215-NA

CALL PARK
MAP215- 206
Issue 1, September 1983
Sheet 2 of 2




CALL PICKUP

MAP215-207

Issue 1, September 1983

Sheet 1 of 2



CALL PICKUP
MAP215- 207
Issue 1, September 1983
Sheet 2 of 2

Note: Check extension and test line must be in the same Pickup group.


AT CONSOLE

- (4A) Dial number other than that of test line or check extension
- * DESTINATION display shows number dialed and class of extension dialed
 - * ATT and RING lamps lit
 - * Busy Lamp Field shows called number busy

AT MAINTENANCE HANDSET

- (5A) Set switch to OFF-HOOK
- * Dial tone
- (5B) Dial Directed Call Pickup code + number dialed in (4A)
- (5C) Two-way conversation with console

- (6A) Set maintenance handset switch to ON-HOOK
- (6B) Press console RELEASE




CAMP-ON

MAP215- 208

Issue 1, September 1983

Sheet 1 of 1




CONSULTATION HOLD/TRANSFER/ADD-ON


MAP215-209

Issue 1, September 1983


Sheet 1 of 2




CONSULTATION HOLD/TRANSFER/ADD-ON
MAP200- 209
Issue 1, September 1983
Sheet 2 of 2



AUTOMATIC CALLBACK - DON'T ANSWER
MAP215- 210
Issue 1, September 1983
Sheet 1 of 2



AUTOMATIC CALLBACK - DON'T ANSWER
MAP200- 210
Issue 1, September 1983
Sheet 2 of 2




AUTOMATIC CALLBACK - BUSY

MAP215- 211

Issue 1, September 1983

Sheet 1 of 2




MEET-ME CONFERENCE


MAP215- 212

Issue 1, September 1983

Sheet 1 of 2



MEET-ME CONFERENCE
MAP215- 212
Issue 1, September 1983
Sheet 2 of 2




EXECUTIVE BUSY OVERRIDE

MAP215-213

Issue 1, September 1983

Sheet 1 of 1




PAGING


MAP215- 214

Issue 1, September 1983


Sheet 1 of 1



DO NOT DISTURB	WRITTEN FOR D...
MAP215-215	FILE # 271245
Issue 1, September 1983	ISSUE # 1
Sheet 1 of 2	DATE 9/1/83



DO NOT DISTURB
MAP215- 215
Issue 1, September 1983
Sheet 2 of 2




CALL HOLD


MAP215-216

Issue 1, September 1983

Sheet 1 of 4



CALL HOLD
MAP215- 216
Issue 1, September 1983
Sheet 2 of 4




CALL HOLD

MAP215-216

Issue 1, September 1983

Sheet 3 of 4



ROOM STATUS
MAP215- 217
Issue 1, September 1983
Sheet 1 of 1

SYNOPSIS
The maid may update the Room Status from the room.

AT CHECK EXTENSION
 (1A) Lift handset
 * Dial tone
 (1B) Dial Room Status access code + Maid code (Table 217-1)


AT CONSOLE
 (2A) Press GUEST ROOM
 (2B) Dial Check Extension. Destination display shows numbers as in Table 217-2

**TABLE 217-1
MAID DIALED CODES**

MAID CODE	INDICATION
1	Maid in Room, Requires Cleaning
2	Maid left Room, Status Unchanged
3	Maid left Room, Room Ready

**TABLE 217-2
ROOM STATUS CODE**

STATUS CODE	STATUS
Period Indicates	Maid in room
1	Room vacant and ready
2	Room occupied and clean
3	Room vacant, requires cleaning
4	Room occupied, requires cleaning



AUTOMATIC WAKE-UP (ALARM CALL)

MAP215- 21B

Issue 1, September 1983

Sheet 1 of 2

AT CHECK EXTENSION


- (1A) Lift handset
 * Dial tone
 (1B) Dial Automatic Wake-Up
 access code and Wake-Up
 time (24-hour format)
 * Dial tone
 (1C) Replace handset

AT CHECK EXTENSION


- (2A) Check extension rings at
 requested time

AT CHECK EXTENSION

- (3A) Repeat Step (1A)
 * Dial tone
 (3B) Dial Automatic Wake-Up
 access code and 9999
 * Dial tone
 (3C) Replace handset



AUTOMATIC WAKE-UP (ALARM CALL)
MAP215- 21B
Issue 1, September 1983
Sheet 2 of 2




USE A COMMON USE SPEED CALL

MAP215-219

Issue 1, September 1983

Sheet 1 of 1



PERSONAL SPEED CALL

MAP215-220

Issue 1, September 1983

Sheet 1 of 1

TABLE 220-1


Digits	Meaning
*1	5 second pause
*2	Wait for dial tone
*3 (NN)	Allows the required number of digits to be dialed (NN denotes the required number of defined digits 01-16)

AT THE CHECK EXTENSION

- (1A) Lift handset
 (1B) Dial the Speed Call access code
 (1C) Dial 0 + Speed Call Entry code
 * Short burst dial tone
 (1D) Dial all digits including pauses and manual digit insertions (Table 220-1)
 (1E) Go on-hook

- (2A) Dial tone
 (2B) Dial the Speed Call access code
 (2C) Dial the Speed Call Personal code
 * Tone returned (busy or ringback)

- (3A) Dial tone
 (3B) Dial the Speed Call access code
 (3C) Dial 0
 (3D) Dial the Speed Call Personal code
 (3E) Go on-hook



EXTERNAL CALL FORWARDING

MAP215- 221

Issue 1, September 1983

Sheet 1 of 2

TABLE 221-1

Digits	Meaning
*1	5 second pause
*2	Wait for dial tone
*3 (NN)	Allows the required number of digits to be dialed (NN denotes the required number of defined digits 01-16)


AT THE CHECK EXTENSION

- (1A) Lift handset
- * Dial tone
- (1B) Dial Speed Call access code
- (1C) Dial 0
- (1D) Dial Speed Call Entry code
- * Short burst of dial tone
- (1E) Dial all LDN digits including pauses and manual digit insertions (Table 221-1)
- (1F) Go on-hook


- (2A) Dial Call Forwarding code (Cell Forward - Busy, Follow-Me, Busy-Don't answer or Don't Answer)
- (2B) Dial Speed Call access code
- (2C) Dial Speed Call Entry code
- (2D) Go on-hook

AT CHECK EXTENSION 1

- (3A) SIMULATE the code selected in step 1; i.e. busy take phone off hook, do no answer phone, etc.
- (3B) Dial Check extension 1 from check extension 2
- * Call will be forwarded to local directory number



EXTERNAL CALL FORWARDING
MAP215- 221
Issue 1, September 1983
Sheet 2 of 2




TRANSFER WITH PRIVACY

MAP215-222


Issue 1, September 1983

Sheet 1 of 1



821-3111
Issue 1 December 1991
WTL102-113
TRANSFER WITH PRIVACY

821-3111



ACCOUNT CODE	BOLD TRUNK
MAP215- 223	SEE -87 02AR
Issue 1, September 1983	Issue 1, 7/83
Sheet 1 of 2	1 of 2


Note
SMDR must be enabled for this test.

TOOLS REQUIRED:
1 PRINTER: RS232 COMPATIBLE
88 characters/line.
300 or 1200 baud


- (1A) Connect printer to RS232 port via a RS232 connection
- (1B) Ensure Scanner Card and printer are set up for the same baud rate, character set and parity
- (1C) Clear printer port by dialing:
 - * 1400
 - * Press RELEASE
- (1D) Enable printer port by dialing:
 - * 14 + number sign
 - * Press RELEASE

- (2A) Account Codes may be:
 - * Account Code Length: 4 digits (System Option 231)
 - * Account Code Length: 8 digits (System Option 232)
 - * Account Code Length: 12 digits (System Option 233)
 - * Variable Length Account Codes (System Option 234)
- (2B) Review programming to see which Account Code Length is applicable

- AT CHECK EXTENSION 1**
- (3A) Lift handset, Dial tone
 - (3B) Dial:
 - * Account Code access code
 - * Appropriate Account Code (see Step (2))
 - * Dial tone returned
 - * Dial Trunk access code
 - * Dial Directory Number including prefix, area code etc.



ACCOUNT CODE	XXXXXXXXXX
MAP215- 223	XXXXXXXXXX
Issue 1, September 1983	XXXXXXXXXX
Sheet 2 of 2	XXXXXXXXXX



AT CHECK EXTENSION 1
 (4A) Terminate the call
 (4B) SMDR printout access with
 Account Code included

HANDS-FREE STATION

MAP215-224

Issue 1, September 1983


Sheet 1 of 1

Note
For maximum results check extension 1 should be a speaker phone or a SUPERSET 4.

AT CHECK EXTENSION 2

- (1A) Lift handset
* Dial tone
(1B) Dial check extension 1 (check extension 1 should be in the hands-free state)
* Check extension 1 rings for 1 second and connection is made

- (2A) Ensure there is a connection between check extension 1 and check extension 2
(2B) Go on-hook




CALL FORWARDING - BUSY/DON'T ANSWER
--


MAP215-225

Issue 1, September 1983


Sheet 1 of 2



CALL FORWARDING -- BUSY/DON'T ANSWER
MAP200- 225
Issue 1, September 1983
Sheet 2 of 2



ENABLE NON-CO TRUNK TO TRUNK CONNECT
MAP215- 226
Issue 1, September 1983
Sheet 1 of 1



REPEATED CAMP-ON TONES


MAP215-227

Issue 1, September 1983

Sheet 1 of 1

NOTE

If System Option 217 is enabled, Repeated Camp-on Tones will occur every 5 s. If System Option 218 is enabled Repeated Camp-on Tones will occur every 15 s. If neither Option 217 or 218 is enabled, the tones will be repeated every 10 s.




EXTENSION RESET


MAP215- 228

Issue 1, September 1983

Sheet 1 of 2



EXTENSION RESET
MAP215- 228
Issue 1, September 1983
Sheet 2 of 2



ANSWER INCOMING CALL

MAP215- 300

Issue 1, September 1983

Sheet 1 of 5

Note: Equipment number displayed is same as individual Trunk Access Number.



- AT MAINTENANCE HANDSET**
- (2A) Set switch to OFF-HOOK
 - Dial tone
 - (2B) Dial CO Trunk access code
 - CO dial tone
 - (2C) Dial console listed directory number

- AT CONSOLE**
- (3A) ANSWER and LDN lamps flash, ringer sounds
 - (3B) Press LDN
 - ANSWER, LDN and SOURCE lamps light
 - SOURCE display (Fig. 300-1) shows number of calling trunk and ATT lamp lit
 - Two-way conversation, console and maintenance set





Fig. 300-1

ANSWER INCOMING CALL
MAP215- 300
Issue 1, September 1983
Sheet 2 of 5

Note: Equipment number displayed is same as Individual Trunk Access Number.

(4A) Press SERIAL CALL
 * SERIAL CALL lamp lights

AT CONSOLE
 (5A) Dial number of check extension
 * ANSWER, LDN and DESTINATION lamps lit
 * SOURCE display (Fig. 300-2) shows the equipment number of the calling trunk
 * DESTINATION display shows the number and COS of the check extension
 * ATT and RING lamps lit

AT CHECK EXTENSION
 (6A) Lift check extension handset
 * Two-way conversation with console





Fig. 300-2




Fig. 300-3

ANSWER INCOMING CALL
MAP215- 300
Issue 1, September 1983
Sheet 3 of 5

Note: Equipment number displayed is same as individual Trunk Access Number.

- AT CONSOLE**
 (7A) Press SOURCE
- * ANSWER, LDN and SOURCE lamps lit
 - * SOURCE display (Fig. 300-3) shows the number of the calling trunk, ATT lamp lit
 - * DESTINATION display shows number and COS of check extension
 - * Two-way private call with maintenance set

- AT CONSOLE**
 (8A) Press DEST
- * ANSWER, LDN and DEST lamps lit
 - * SOURCE display (Fig. 300-4) shows the equipment number of the calling trunk
 - * DESTINATION display shows the number and COS of the check extension
 - * ATT lamp lit
 - * Two-way private call with check extension

- AT CONSOLE**
 (9A) Press BOTH
- * ANSWER, LDN and BOTH lamps lit
 - * SOURCE display (Fig. 300-5) shows equipment number of calling trunk
 - * ATT lamp lit
 - * DESTINATION display shows number and COS of check extension
 - * ATT lamp lit
 - * Three-way call, check extension, maintenance set and console





Fig. 300-4




Fig. 300-5

ANSWER INCOMING CALL
MAP215- 300
Issue 1, September 1983
Sheet 4 of 5






Fig. 300-6

ANSWER INCOMING CALL

MAP215-300

Issue 1, September 1983

Sheet 5 of 5



AUTOMATIC CALLBACK	
MAP215- 301	
Issue 1, September 1983	
Sheet 1 of 2	





Fig. 301-1

AUTOMATIC CALLBACK
MAP215- 301
Issue 1, September 1983
Sheet 2 of 2

AT CHECK EXTENSION
 (4A) Ringer sounds
 (4B) Lift handset
 * Two-way call

(5A) Replace check extension handset
 (5B) Press console RELEASE
 * Console idle



EXTENDING INTERNAL CALLS

MAP215-302

Issue 1, September 1983

Sheet 1 of 2

Note: Individual Trunk Access Number displayed is same as equipment number of trunk.



AT CHECK EXTENSION

- (2A) Lift handset
 * Dial tone
 (2B) Dial 0
 * Ringing tone

AT CONSOLE

- (3A) ANSWER and DIAL 0 lamps flash
 * Ringer sounds
 (3B) Press DIAL 0
 * ANSWER, DIAL 0 and SOURCE lamps light
 * SOURCE display (Fig. 302-1) shows number and COS of check extension
 * ATT lamp lit
 * Two-way conversation






Fig. 302-1

EXTENDING INTERNAL CALLS
MAP215- 302
Issue 1, September 1983
Sheet 2 of 2



AT CONSOLE

- (4A) Dial CO Trunk access code
- * CO dial tone
 - * ANSWER, DEST and DIAL 0 lamps lit
 - * SOURCE display (Fig. 302-2) shows number and COS of check extension
 - * DESTINATION display shows trunk access code
 - * ATT lamp lit

- (5A) Press console RELEASE
- * Console idle
 - * CO dial tone heard at check extension

- (6A) Replace check extension handset




Fig. 302-2

ANSWERING RECALL	333 00000000
MAP215-303	100-975741
Issue 1, September 1983	Sheet 1 of 2






Fig. 303-1

ANSWERING RECALL
MAP215- 303
Issue 1, September 1983
Sheet 2 of 2



- (4A) Check extension 2 rings
 (4B) Press console RELEASE
 * Console idle

- AT CONSOLE**
 (5A) After time out period (10, 20, 30 or 40 s)
 * RCL and ANSWER lamps flash
 * Ringer sounds
 (5B) Press RECALL
 * RCL, ANSWER and SOURCE lamps light
 * SOURCE display (Fig. 303-3) shows the number and COS of check extension 1
 * ATT and RCL lamps lit
 * DESTINATION display shows number and COS of check extension 2

- (6A) Press console CANCEL
 * Console idle
 (6B) Replace check extension handset 1
 (6C) Press console RELEASE
 * Console idle




Fig. 303-2




Fig. 303-3

OVERRIDE

MAP215-304

Issue 1, September 1983

Sheet 1 of 2





Fig. 304-1

 OVERRIDE
 MAP215- 304
 Issue 1, September 1983
 Sheet 2 of 2



FLEXIBLE NIGHT SERVICE	
MAP215-305	REV 21-12
Issue 1, September 1983	
Sheet 1 of 2	

Note: Individual Trunk Access Number displayed is the equipment number of the trunk.

- AT CONSOLE**
- (1A) Dial *, 3
 - * ANSWER and DEST lamps lit
 - (1B) Dial Individual Trunk access code (equipment number)
 - * ANSWER and DEST lamps lit
 - * DESTINATION display shows individual trunk (equipment) number

- (2A) Press NIGHT 1
 - * ANSWER and DEST lamps lit
 - * SOURCE display shows individual Trunk Equipment Number and Night Service assignment
 - * DESTINATION display shows existing extension or Hunt Group assignment
- (2B) Dial number of check extension 1
 - * ANSWER and DEST lamps lit
 - * SOURCE display (Fig. 305-1) shows individual trunk number and night assignment
 - * DESTINATION display shows number of check extension 1
- (2C) Press RELEASE

- (3A) Press NIGHT 1 button selected in step (2A)
 - * NIGHT lamp lit
 - * Night trunk is connected to check extension






Fig. 305-1

FLEXIBLE NIGHT SERVICE
MAP215- 305
Issue 1, September 1983
Sheet 2 of 2



TRUNK BUSY OPERATION	306-306
MAP215-306	306-306
Issue 1, September 1983	306-306
Sheet 1 of 2	306-306

Note: Individual Trunk Access Number displayed is same as equipment number of trunk.

- AT CONSOLE**
- (1A) Dial *, 9 individual Trunk number, *
- * ANSWER and DEST lamps light
 - * Dial tone returned if trunk is free
- (1B) Press RELEASE



- (2A) Dial *, 9 individual Trunk Number dialed in (1A) + *
- * ANSWER and DEST lamps lit
 - * DESTINATION display shows number dialed, ATT lit (Fig. 306-1)
 - * Busy tone
- (2B) Press RELEASE

- (3A) Dial *, 9 Individual Trunk Number, number sign
- * ANSWER and DEST lamps lit
 - * DESTINATION display (Fig. 306-2) shows number dialed, ATT lit
- (3B) Press RELEASE




Fig. 306-1

TRUNK BUSY OPERATION
MAP215- 306
Issue 1, September 1983
Sheet 2 of 2





Fig. 306-2

(5A) Press RELEASE



TRUNK GROUP SUPERVISOR ACCESS	
MAP215- 307	USE - 81 07 1983
Issue 1, September 1983	ISSUED - 7 09 1983
Sheet 1 of 2	FIG. 307-1




Fig. 307-1





Fig. 307-2

TRUNK GROUP SUPERVISOR ACCESS
MAP215- 307
Issue 1, September 1983
Sheet 2 of 2



- AT SUPERVISOR CONSOLE**
- (4A) Press RELEASE
 - * Console idle
 - (4B) Dial CO trunk access code
 - * Dial tone
 - * ANSWER and DEST lamps lit
 - * ATT lamp lit
 - (4C) Press RELEASE
 - * Console idle



TRUNK GROUP DIAL ACCESS
MAP215- 308
Issue 1, September 1983
Sheet 1 of 2






Fig. 308-1

TRUNK GROUP DIAL ACCESS
MAP215- 308
Issue 1, September 1983
Sheet 2 of 2




(4A) Press RELEASE button

TEST TERMINATION


MAP215- 309

Issue 1, September 1983

Sheet 1 of 8



TEST TERMINATION
MAP215- 309
Issue 1, September 1983
Sheet 2 of 8




TEST TERMINATION


MAP215- 309

Issue 1, September 1983

Sheet 3 of 8



TEST TERMINATION
MAP215- 309
Issue 1, September 1983
Sheet 4 of 8




TEST TERMINATION


MAP215-309

Issue 1, September 1983

Sheet 5 of 8



TEST TERMINATION
MAP215- 309
Issue 1, September 1983
Sheet 6 of 8




TEST TERMINATION


MAP215-309

Issue 1, September 1983

Sheet 7 of 8



TEST TERMINATION
MAP215- 309
Issue 1, September 1983
Sheet 8 of 8




ANSWER INCOMING CO TRUNK CALL

MAP215-310

Issue 1, September 1983

Sheet 1 of 6

Note: Equipment number displayed is same as Individual Trunk Access Number.



ANSWER INCOMING CO TRUNK CALL
MAP215- 310
Issue 1, September 1983
Sheet 2 of 6

Note: Equipment number displayed is same as Individual Trunk Access Number.

AT CONSOLE

- (4A) ANSWER and LDN lamps flash, ringer sounds
- (4B) Press LDN
 - * ANSWER, LDN and SOURCE lamps light
 - * SOURCE display (Fig. 310-1) shows number of calling trunk and ATT lamp lit
 - * Two-way conversation, console and maintenance set

- (6A) Press SERIAL
 - * SERIAL lamp lights





Fig. 310-1

ANSWER INCOMING CO TRUNK CALL

MAP215-310

Issue 1, September 1983

Sheet 3 of 6

Note: Equipment number displayed is same as Individual Trunk Access Number.

AT CONSOLE

- (7A) Dial number of check extension
- * ANSWER, LDN, and DEST lamps lit
 - * SOURCE display (Fig. 310-2) shows the equipment number of the calling trunk
 - * DESTINATION display shows the number and COS of the check extension
 - * ATT and RING lamps lit

AT CHECK EXTENSION

- (8A) Lift check extension handset
- * Two-way conversation with console

AT CONSOLE

- (9A) Press SOURCE
- * ANSWER, LDN and SOURCE lamps lit
 - * SOURCE display (Fig. 310-3) shows the number of the calling trunk
 - * DESTINATION display shows number and COS of check extension
 - * Two-way private call with maintenance set





Fig. 310-2








Fig. 310-3


ANSWER INCOMING CO TRUNK CALL
MAP215- 310
Issue 1, September 1983
Sheet 4 of 6



ANSWER INCOMING CO TRUNK CALL	
MAP215-310	310-310
Issue 1, September 1983	
Sheet 5 of 6	



ANSWER INCOMING CO TRUNK CALL
MAP215- 310
Issue 1, September 1983
Sheet 6 of 6



SUPERVISOR DO NOT DISTURB

MAP215- 311

Issue 1, September 1983

Sheet 1 of 2

Note 1:

Ring is given in substep (2B) if System Option 138 is selected. Otherwise re-order tone is given and remainder of (2) substeps are omitted.






Fig. 311-1

SUPERVISOR DO NOT DISTURB
MAP215- 311
Issue 1, September 1983
Sheet 2 of 2

None

Step in this section is required for the system to be installed. The system is installed in the order shown in this section and the order is given and numbered to the system as shown.

- AT CHECK EXTENSION 2**
 (4A) Lift handset
 * Dial tone
 (4B) Dial number of Check Extension 1
 * Ringing tone
- AT CHECK EXTENSION 1**
 (4C) Bell rings
 (4D) Lift handset
 * Two-way conversation, Check Extension 1 and 2
 (4E) Replace Check Extension handsets
- AT CONSOLE**
 (4F) Press DO NOT DSTB key
 * Check Extension 1 lamp in Busy Lamp Field is not lit
 (4G) Release DO NOT DSTB key
 * Console idle



MESSAGE WAITING	INITIATE BOARDING
MAP215-312	CTE-1702AN
Issue 1, September 1983	Issue 1, 1983
Sheet 1 of 2	2 of 2 sheets

WARNING
 Pressing MSGE WAIT when console is active with an extension may activate or remove the feature at the extension.






Fig. 312-1

MESSAGE WAITING
MAP215- 312
Issue 1, September 1983
Sheet 2 of 2



SUPERVISOR CALL FORWARDING - BUSY	
MAP215- 313	
Issue 1, September 1983	
Sheet 1 of 2	

- AT CONSOLE**
- (1A) Dial * 11333
 * SOURCE display shows check extension 1 number and '-' (no forward code), Fig. 313-1
- (1B) Dial 1222
 * SOURCE display shows check extension 1 number and '1' (busy code) (Fig. 313-2)
 * DESTINATION display shows check extension 2 number, ATT lamp lit
- (1C) Press RELEASE
 * Console idle

- AT CHECK EXTENSION 1**
- (2A) Lift handset
 * Dial tone
- AT MAINTENANCE HANDSET**
- (2B) Set switch to OFF-HOOK
 * Dial tone
- (2C) Dial number of check extension 1
 * Check extension 2 rings
- (2D) Replace check extension 1 handset and place maintenance handset switch to ON-HOOK

- AT MAINTENANCE HANDSET**
- (3A) Set switch to OFF-HOOK
 * Dial tone
- (3B) Dial number of check extension 1
 * Check extension 1 rings






Fig. 313-1



SUPERVISOR CALL FORWARDING - BUSY
MAP200- 313
Issue 1, September 1983
Sheet 2 of 2



SUPERVISOR CALL FORWARDING - DON'T ANSWER	
MAP215- 314	DATE - 09/21/83
Issue 1, September 1983	ISSUED BY - J. B. ...
Sheet 1 of 2	2 of 2 sheets

Note
See also MAP215-333 for External Call Forwarding.






Fig. 314-1

SUPERVISOR CALL FORWARDING - DON'T ANSWER
MAP200- 314
Issue 1, September 1983
Sheet 2 of 2

staff
 Top also MAP200-314 for Extension Call Forwarding



- AT MAINTENANCE HANDSET**
- (4A) Set switch to OFF-HOOK
 - * Dial tone
 - (4B) Dial number of check extension 1
 - * Ringing tone
 - (4C) Check extension 1 rings for at least 1 minute without forwarding to check extension 2
 - (4D) Set switch to ON-HOOK
 - (4E) Check extension 1 stops ringing





Fig. 314-2

SUPERVISOR CALL FORWARDING - FOLLOW ME	
MAP215- 315	315-0001A
Issue 1, September 1983	
Sheet 1 of 2	1 of 2 sheets

Note
See also MAP215-333 for External Call Forwarding.



TSBOPAK BSHAKSTWAM TA
 VOOH-910 at follow to2 (A)
 and to4
 (B) Dial number of check extension
 and ringed
 (C) Check extension 2 rings
 (D) Set switch to ON-HOOK
 (E) Check extension 1 lamp busy






Fig. 315-1

SUPERVISOR CALL FORWARDING - FOLLOW ME
MAP200- 315
Issue 1, September 1983
Sheet 2 of 2



- AT MAINTENANCE HANDSET**
- (4A) Set switch to OFF-HOOK
 - * Dial tone
 - (4B) Dial number of check extension 1
 - * Ringing tone
 - (4C) Check extension 2 rings
 - (4D) Set switch to ON-HOOK
 - (4E) Check extension 1 stops ringing



SUPERVISOR CALL FORWARDING BUSY/DON'T ANSWER	
MAP215- 316	316-0021AM
Issue 1, September 1983	
Sheet 1 of 2	

Note
See also MAP215-335 for External Call Forwarding.







Fig. 316-1

SUPERVISOR CALL FORWARDING BUSY/DON'T ANSWER
MAP200- 316
Issue 1, September 1983
Sheet 2 of 2

- AT CONSOLE**
- (4A) Dial * 11333
 - * SOURCE display shows number of check extension 1 and 'Busy-Don't Answer code '4' (Fig. 316-2)
 - * DESTINATION display shows number of check extension 2. (Fig. 316-2)
 - (4B) Press number
 - (4C) Press RELEASE



SUPERVISOR-CONTROLLED
CONFERENCE

MAP215- 317

Issue 1, September 1983

Sheet 1 of 3





Fig. 317-1

SUPERVISOR-CONTROLLED CONFERENCE
MAP200- 317
Issue 1, September 1983
Sheet 2 of 3






Fig. 317-2

SUPERVISOR-CONTROLLED CONFERENCE

MAP215- 317

Issue 1, September 1983

Sheet 3 of 3




SUPERVISOR STATION BUSY-OUT


MAP215- 318

Issue 1, September 1983


Sheet 1 of 2




SUPERVISOR STATION BUSY-OUT	
MAP215- 318	811-217988
Issue 1, September 1983	811-217988
Sheet 2 of 2	811-217988



CALL BLOCK	XXXXX
MAP215-319	XXXXX
Issue 1, September 1983	XXXXX
Sheet 1 of 2	XXXXX



CALL BLOCK	NOV 8 1983
MAP215- 319	875 47544
Issue 1, September 1983	Page 1 of 2
Sheet 2 of 2	Page 1 of 2



SUPERVISOR DO NOT DISTURB (H/M)

MAP215- 320

Issue 1, September 1983

Sheet 1 of 3

WARNING

Pressing DO NOT DSTB key when console is active with an extension may activate or remove the feature at the extension.

Note 1: Ringing is given in substep (2B) if System Option 174 is selected. Otherwise, reorder tone is given and remainder of step (2) is omitted.

AT CONSOLE

- (1A) Press GUEST ROOM
* GUEST ROOM lamp lit
- (1B) Dial number of check extension 1
* SOURCE display shows check extension number and message register, ATT lamp lit
* DESTINATION display shows room status code (Fig. 320-1)
- (1C) Press DO NOT DSTB
* DO NOT DSTB lamp lit
* Check extension 1 lamp lit in Busy Lamp Field
- (1D) Press RELEASE
* Console idle

AT CHECK EXTENSION 2

- (2A) Lift handset
* Dial tone
- (2B) Dial number of check extension 1
* Ringing tone (NOTE 1)
* Console rings
* DIAL 0 and ANSWER lamps flash
- AT CONSOLE**
- (2C) Press ANSWER
* SOURCE display shows number of check extension 2 and class of service
* ATT and INT lamps lit
- (2D) Two-way conversation, console and check extension 2
- (2E) Press RELEASE
- (2F) Replace check extension 2 handset

AT CONSOLE

- (3A) Press DO NOT DSTB
* SOURCE display, Fig. 320-2, shows total number of rooms with 'do not disturb' facility
- (3B) Release DO NOT DSTB
* Console idle

START

[1]
AND

DISPLAY GUEST ROOM STATUS AT CONSOLE

[2]
AND

VERIFY FEATURE FROM SECOND PARTY

[3]
AND

DISPLAY NUMBER OF ROOMS WITH DO NOT DISTURB ACTIVATED

Go to (4)




Fig. 320-1

SUPERVISOR DO NOT DISTURB (H/M)	
MAP215- 320	REV. 1/1983
Issue 1, September 1983	
Sheet 2 of 3	





Fig. 320-2

SUPERVISOR DO NOT DISTURB (H/M)

MAP215- 320

Issue 1, September 1983

Sheet 3 of 3



MESSAGE REGISTRATION (H/M)

MAP215- 321

Issue 1, September 1983

Sheet 1 of 2






Fig. 321-1

MESSAGE REGISTRATION (H/M)
MAP215- 321
Issue 1, September 1983
Sheet 2 of 2





CONTROLLED OUTGOING CALL RESTRICTION (H/M)	
MAP215- 322	REV - 000143
Issue 1, September 1983	ISSUED 2 83
Sheet 1 of 2	2 of 2 sheets

Note: This MAP applies when console has ROOM RESTR. If ROOM STATUS see MAP215-323.


TABLE 322-1
ROOM STATUS CODES

CODE	STATUS
1	Room is vacant and ready
2	Room is occupied and clean
3	Room is vacant but requires cleaning
4	Room is occupied but requires cleaning



- AT CONSOLE**
- (1A) Press GUEST ROOM
 - * GUEST ROOM lamp lit
 - (1B) Dial check extension 1
 - * SOURCE display shows number and message register count
 - * DESTINATION display shows room status code (and period if maid in room) (See Fig. 322-1 and Table 322-1)




VERIFY ROOM STATUS




YES




ENABLE ROOM RESTRICTION (OUTGOING CALLS)



- AT CONSOLE**
- (3A) Dial digit 1
 - * SOURCE display shows room number and message registration
 - * DESTINATION display changes to read digit '1' for room status (Fig. 322-1)
 - (3B) Press ROOM RESTR
 - * ROOM RESTR lamp lit
 - (3C) Press RELEASE
 - * SOURCE and DESTINATION displays are cleared
 - * ROOM RESTR lamp cleared



CONTROLLED OUTGOING CALL RESTRICTION (H/M)
MAP200- 322
Issue 1, September 1983
Sheet 2 of 2



ROOM STATUS (H/M)	EXTENSION
MAP215- 323	323-323
Issue 1, September 1983	
Sheet 1 of 4	

NOTES

(1) The single-digit codes in the following procedures have meanings shown in Tables 323-1 and 323-2.

(2) Maid codes are dialed from room only, after the 'Maid Access' code has been dialed (Table 323-2).

AT CONSOLE

(1A) Press GUEST ROOM

(1B) Dial the number of check extension 1

- * SOURCE display shows number of check extension 1 and message register count
- * DESTINATION display shows room status code (Table 323-1)

(1C) Dial digit 3

- * DESTINATION display shows room status code 3 (Fig. 323-1)

AT CHECK EXTENSION 1

(2A) Lift handset

- * Dial tone

(2B) Dial 'Maid Access' code then digit 1 (Table 323-2)

(2C) Replace handset

AT CONSOLE

(2D) Repeat steps (1A)-(1C)

- * Period sign appears after status code in DESTINATION display

(2E) Press RELEASE

- * SOURCE and DESTINATION displays extinguished

AT CONSOLE

(3A) Press ROOM STATUS

(3B) Press and hold digit 0

- * Check extension 1 lamp lit in BUSY LAMP FIELD
- * SOURCE display shows total number of rooms with maids present (Fig. 323-2)

(3C) Release key pad digit 0

(3D) Press ROOM STATUS

(3E) Press and hold digit 3

- * Check extension 1 lamp lit in BUSY LAMP FIELD
- * SOURCE display, (Fig. 323-2) changes to reflect total number of vacant rooms which require cleaning

(3F) Release key pad digit 3

- * BUSY LAMP FIELD resumes normal indications

(3G) Press RELEASE




TABLE 323-1 ROOM STATUS CODES

STATUS CODE	STATUS
1	Room vacant and ready
2	Room occupied and clean
3	Room vacant, requires cleaning
4	Room occupied, requires cleaning

TABLE 323-2 MAID-DIALED CODES

MAID CODE	INDICATION (NOTE 2)
1	Maid in room, requires cleaning
2	Maid left room, status unchanged
3	Maid left room, room ready




Fig. 323-1

ROOM STATUS (H/M)
MAP215- 323
Issue 1, September 1983
Sheet 2 of 4





Fig. 323-2

ROOM STATUS (H/M)	STATUS ROOM
MAP215-323	SEE -175NA
Issue 1, September 1983	
Sheet 3 of 4	

AT CONSOLE

- (7A) Press GUEST ROOM
- (7B) Dial the number of check extension 1 and Message Register count
 - * SOURCE display shows number of check extension 1
 - * DESTINATION display shows room status '1' (Fig. 323-3)
- (7C) Dial digit 2
 - * DESTINATION display shows room status code '2'
- (7D) Press RELEASE
 - * SOURCE and DESTINATION displays extinguished

- (8A) Press ROOM STATUS
- (8B) Press and hold key pad digit 2
 - * Check extension 1 lamp lit in BUSY LAMP FIELD
 - * SOURCE display, Fig. 323-2, changes to reflect total number of rooms which are occupied and cleaned
- (8C) Release key pad digit 2
 - * BUSY LAMP FIELD resumes normal lamp indications
- (8D) Press RELEASE






Fig. 323-3

ROOM STATUS (H/M)
MAP215- 323
Issue 1, September 1983
Sheet 4 of 4




AUTOMATIC WAKE-UP
(ALARM CALL)


MAP215-324

Issue 1, September 1983

Sheet 1 of 2



AUTOMATIC WAKE-UP (ALARM CALL)
MAP200- 324
Issue 1, September 1983
Sheet 2 of 2



MESSAGE WAITING (H/M)

MAP215-325

Issue 1, September 1983

Sheet 1 of 2

WARNING

Pressing the MSGE WAIT key when console is active with an extension may activate or remove the feature at the extension.

Note 1

The lamp flash facility to flash telephones fitted with lamps is available on PABX line cards bearing part number 9110-010-000. Either option 276 for lamp flash or option 275 for bell ring may be programmed, but not both.

AT CHECK EXTENSION 1

- (1A) Lift handset
* Dial tone

AT CONSOLE

- (1B) Press GUEST ROOM
* GUEST ROOM lamp lit
(1C) Dial check extension 1
* Busy tone
* Extension busy lamp lit
(1D) Press MSGE WAIT
* MSGE WAIT lamp lit
* Extension busy lamp lit
(1E) Press RELEASE

AT CONSOLE

- (2A) Press MSGE WAIT
* SOURCE display (Fig. 325-1), shows total number of rooms with messages waiting
(2B) Release MSGE WAIT
* SOURCE display becomes idle

AT CHECK EXTENSION 1

- (3A) Replace handset
* Bell rings after 10 s (Note 1)

AT CHECK EXTENSION 1

- (3B) Lift handset
* Dial tone
(3C) Dial '0'
* Ringing tone
* Console rings

AT CONSOLE

- (3D) Press ANSWER
* SOURCE display shows number and class of service of check extension 1, ATT lamp lit
(3E) Two-way conversation between console and check extension 1
(3F) MSGE WAIT lamp lit

START

[1]
ANDSET UP
MESSAGE
WAITING[2]
ANDDISPLAY
NUMBER OF
ROOMS WITH
MESSAGES
WAITING[3]
ANDEXTENSION
CALL TO
CONSOLE

Go to (4)





Fig. 325-1

MESSAGE WAITING (H/M)
MAP215- 325
Issue 1, September 1983
Sheet 2 of 2

When the handset is replaced at the console, the MSGE WAIT lamp goes off. The handset is then available for use. The handset is not available for use until the handset is replaced at the console.



- AT CONSOLE**
- (4A) Press MSGE WAIT
 - * MSGE WAIT lamp goes off
 - (4B) Press RELEASE
 - (4C) Replace handset at check extension 1



Pressing the MSGE WAIT lamp will cause the MSGE WAIT lamp to go off. The handset is then available for use.

AT CHECK EXTENSION
 (1A) Lift handset
 * Dial tone
 AT CONSOLE
 (2A) Press MSGE WAIT
 * MSGE WAIT lamp
 (2B) Replace handset at check extension 1

AT CONSOLE
 (3A) Press MSGE WAIT
 * MSGE WAIT lamp
 (3B) Replace handset at check extension 1


AT CHECK EXTENSION
 (4A) Replace handset
 * Dial tone
 AT CONSOLE
 (4B) Press MSGE WAIT
 * MSGE WAIT lamp
 (4C) Replace handset at check extension 1

CONSOLE DATE DISPLAY AND DATE UTILITY
--

MAP215- 326


Issue 1, September 1983

Sheet 1 of 1




CONTROLLING THE PRINTER	
MAP215-328	888-10-215-NA
Issue 1, September 1983	
Sheet 1 of 2	

TOOLS REQUIRED:
 Printer, RS232 compatible, 88 characters per line and 300 or 1200 baud print rate.



CONTROLLING THE PRINTER
MAP215- 328
Issue 1, September 1983
Sheet 2 of 2

COMPLIANT LOGOT
 -compla 00 avhsecoms 00127 19831
 buad 0007 to 000 line 00- 101 2151
 2151 2010



- (4A) Dial *1400
 - * Printer stops, all output from the system is ignored
- (4B) Dial * 14 number sign
 - * Printer is enabled

ROOM AUDIT

MAP215-329

Issue 1, September 1983

Sheet 1 of 1

Note: Ensure Printer is not in local mode.





Fig. 329-1

SYSTEM IDENTIFIER	SPRINTER SYSTEMS
MAP215- 330	DEC - 813748
Issue 1, September 1983	PHONE 2 3448
Sheet 1 of 2	2 to 2 3448

AT CONSOLE
 (1A) Dial *17
 * Source display shows the current system ID (Fig. 330-1)






Fig. 330-1

AT CONSOLE
 (3A) Dial new system identifier (1-3 digits)
 * New ID appears in DESTINATION display



SYSTEM IDENTIFIER
MAP215- 330
Issue 1, September 1983
Sheet 2 of 2



COMMON USE SPEED CALL

MAP215- 331

Issue 1, September 1983

Sheet 1 of 1




TABLE 331-1

Digits	Meaning
*1	5 Second pause
*2	Wait for dial tone
*3 (NN)	Allows the required number of manual digits to be dialed (NN denotes the required number of defined digits)




Fig. 331-1





Fig. 331-2

CUSTOMER PROGRAMMING

MAP215- 332

Issue 1, September 1983

Sheet 1 of 1



EXTERNAL CALL FORWARDING	
MAP215-333	CEL-815744
Issue 1, September 1983	71098 J 0000
Sheet 1 of 2	7 to 8 0000


TABLE 333-1
CALL FORWARDING CODES

CODE	MEANING
1	Busy
2	Don't Answer
3	Follow Me
4	Busy/Don't Answer


AT CONSOLE
 (1A) Dial *11 + check extension 1 number
 * SOURCE display shows number of check extension 1 and type of call forwarding in effect (a (-) if no call forwarding)
 * ATT lamp lit
 (1B) Dial type of call forwarding (Table 333-1)

AT CONSOLE
 (2A) Dial System Speed, Call Access Code, Dial Speed Call, Table Number (personal or common use) Note: Table Number must contain a valid external number
 (2B) Press RELEASE button

AT CHECK EXTENSION 2
 (3A) Lift handset
 * Dial tone
 (3B) Dial check extension 1 number
 * Call will be forwarded to an external location immediately if; Call Forwarding Busy, Call Forwarding Busy-Don't Answer or Call Forward Follow Me is used (Note: Create a busy situation at check extension 1 before dialing if Call Forward Busy or Busy Don't Answer is used) or
 * Call will be externally forwarded after six rings at check extension 1 if Call Forward Don't Answer is used



EXTERNAL CALL FORWARDING
MAP215- 333
Issue 1, September 1983
Sheet 2 of 2





TEST AUDIBLE TONE INDICATORS


MAP215- 334

Issue 1, September 1983

Sheet 1 of 4

Fig. 334-1
Lockout Display


TEST AUDIBLE TONE INDICATORS
MAP215- 334
Issue 1, September 1983
Sheet 2 of 4




TEST AUDIBLE TONE INDICATORS
MAP215- 334
Issue 1, September 1983
Sheet 3 of 4

AT CHECK EXTENSION 1
 (8A) Lift handset
 * Dial tone
 (8B) Stay off-hook

AT CONSOLE
 (9A) After check extension 1 is off-hook for 45 seconds, an alarm will sound at the console as: one short ring followed by one longer ring repeated
 (9B) Press the ALARM RESET button
 * DESTINATION and SOURCE displays show lockout condition (Fig. 334-1)



TEST AUDIBLE TONE INDICATORS
MAP215- 334
Issue 1, September 1983
Sheet 4 of 4



SINGLE DIGIT DIALING

MAP215-335

Issue 1, September 1983

Sheet 1 of 2

NOTE


Step (2) is for DTMF telephones and gives immediate ring. Step (3) is for DTMF or rotary dial telephones and tests programmed timeout interval (3, 4 or 5 s).

AT CHECK EXTENSION 2

- (2A) Lift handset
 * Dial tone
 (2B) Dial 'n' (see above note)
 * Ringing tone
 * Check extension 1 bell rings
 (2C) Lift handset at check extension 1
 * Two-way conversation, check extensions 1 and 2
 (2D) Replace handsets on check extensions 1 and 2

AT CHECK EXTENSION 2

- (3A) Lift handset
 * Dial tone
 (3B) Dial 'n' (see note)
 * Ringing tone
 * Check extension 1 bell rings
 (3C) Lift handset at check extension 1
 * Two-way conversation, check extensions 1 and 2
 (3D) Replace handsets on check extensions 1 and 2



SINGLE DIGIT DIALING
MAP215- 335
Issue 1, September 1983
Sheet 2 of 2

Note: To conduct the following system tests, check extension 1 must be programmed as a "SERVICE" extension with code "n" (a single digit code). Alternatively check extension 1 may be temporarily connected in parallel on the cross-connect field to an extension which has a "SERVICE" code, for the test duration.

AT CONSOLE

- (4A) Dial keypad digit 'n'
 * DESTINATION display shows digit 'n' (in Fig. 335-1 'n' is '5')
 * No ringing tone heard
 * ATT lamp lit
- (4B) Wait at least 10 seconds
 * No ringing tone heard
- (4C) Press RELEASE

AT CONSOLE

- (5A) Dial keypad digits 'n number sign'
 * DESTINATION display shows check extension number 1 (NOTE 1) and class (Fig. 335-2)
 * ATT and RING lamps lit
 * Ringing tone
- AT CHECK EXTENSION 1**
- (5B) Bell rings
- (5C) Lift handset
 * Two-way conversation with console
- (5D) Replace handset at check extension 1
- AT CONSOLE**
- (5E) Press RELEASE
 * Both parties idle



335-1
 This diagram shows the destination display for a single digit dialing test. The display shows the digit '5' in the NUMBER field and 'CLASS' in the CLASS field. The DESTINATION field shows 'ATT RING BUSY ERR'.




Fig. 335-1

335-2
 This diagram shows the destination display for a check extension test. The display shows the digit '5' in the NUMBER field and '6' in the CLASS field. The DESTINATION field shows 'ATT RING BUSY ERR'.






Fig. 335-2

COMMON ALERTING DEVICES	
MAP215-336	SEE -812944
Issue 1, September 1983	
Sheet 1 of 2	



COMMON ALERTING DEVICES
MAP215- 336
Issue 1, September 1983
Sheet 2 of 2




ANSWER DID TRUNK CALL

MAP215-337

Issue 1, September 1983

Sheet 1 of 3



ANSWER DID TRUNK CALL
MAP215- 337
Issue 1, September 1983
Sheet 2 of 3





Fig. 337-1

ANSWER DID TRUNK CALL

MAP215-337

Issue 1, September 1983

Sheet 3 of 3

- AT MAINTENANCE HANDSET**
- (7A) Set switch to OFF-HOOK
* Dial tone
- (7B) Dial CO Trunk access code
* CO dial tone
- (7C) Dial DID number for check extension 1 but omit dialing the last digit
* Ringing tone





Fig. 337-2

- AT CONSOLE**
- (9A) DIAL 0 and ANSWER lamps flash, ringer sounds
- (9B) Press DIAL 0 key
* ANSWER, DIAL 0 and SOURCE lamps lit
* SOURCE display (Fig. 337-2) shows number of calling trunk
* ATT, INT and DID lamps lit
* Two-way conversation, console and maintenance set
- (9C) Press RELEASE
* Console idle

- (10A) Reorder tone obtained
(10B) Set maintenance set switch to ON-HOOK




SUPERSET DISCONNECT

MAP215-338

Issue 1, September 1983

Sheet 1 of 1



SX-100*/SX-200*

SUPERSWITCH*

AUTOMATIC CALL DISTRIBUTION SYSTEM

EXTENSION TEST PROCEDURES

GENERIC ACD

	CONTENTS	PAGE
1.	GENERAL	1
	Reason for Issue	1
	SUPERSET 4*	1
	SUPERSET 3*	1
2.	TEST AND OPERATIONAL PROCEDURES	1
	General	1
	Operating Procedures	1
	Chart 2-1 Station-to-Station Call	2
	Chart 2-2 Hunt Group	3
	Chart 2-3 Broker's Call	4
	Chart 2-4 Call Hold	5
	Chart 2-5 Call Forwarding - Busy	7
	Chart 2-6 Call Forwarding - Don't Answer	8
	Chart 2-7 Call Forwarding - Follow Me	9
	Chart 2-8 Override	10
	Chart 2-9 Dial Call Pickup	11
	Chart 2-10 Camp-on	12
	Chart 2-11 Automatic Callback - Busy	13
	Chart 2-12 Do Not Disturb	14
	Chart 2-13 Call Park/Pickup	15
	Chart 2-14 Paging	16
	Chart 2-15 Trunk Answer from any Station	17
	Chart 2-16 Consultation Hold/Transfer/Add-on	18
	Chart 2-17 Automatic Wake-up(Alarm Call)	20
	Chart 2-18 Meet-Me Conference	21
	Chart 2-19 Automatic Callback - Don't Answer	22
	Chart 2-20 Directed Call Pickup	23
	Chart 2-21 Station Conference	24
	Chart 2-22 Speed Call	25
	Chart 2-23 Saved Number Redial	26
	Chart 2-24 External Call Forwarding	27
	Chart 2-25 Call Forwarding Busy/Don't Answer	28
	Chart 2-26 Hands-Free	29
	Chart 2-27 Transfer with Privacy	30
	Chart 2-28 Repeated Camp-on	31

CONTENTS

PAGE

APPENDIX 1
 SUPERSET AND TEST PROCEDURES A1-1

APPENDIX 2
 SUPERSET 3 TEST PROCEDURES A2-1

EXTENSION TEST PROCEDURES
GENERIC ACD

PAGE	CONTENTS
1	GENERAL
1	Reason for Issue
1	SUPERSET 4
1	SUPERSET 5
2	TEST AND OPERATIONAL PROCEDURES
2	General
2	Operator Procedures
2	Chart 2-1 Station-to-Station Call
3	Chart 2-2 Hunt Group
4	Chart 2-3 Broker's Call
8	Chart 2-4 Call Hold
7	Chart 2-5 Call Forwarding - Busy
8	Chart 2-6 Call Forwarding - Don't Answer
8	Chart 2-7 Call Forwarding - Follow Me
10	Chart 2-8 Override
11	Chart 2-8 Old Call Pickup
12	Chart 2-10 Campaign
13	Chart 2-11 Automatic Callback - Busy
14	Chart 2-12 Do Not Disturb
18	Chart 2-13 Call Park/Pickup
18	Chart 2-14 Paging
17	Chart 2-15 Trunk Answer from any Station
18	Chart 2-16 Consultation Hold/Transfer/Add-on
20	Chart 2-17 Automatic Wake-up/Alarm Call
21	Chart 2-18 Meet-Me Conference
22	Chart 2-19 Automatic Callback - Don't Answer
23	Chart 2-20 Directed Call Pickup
24	Chart 2-21 Station Conference
25	Chart 2-22 Speed Call
26	Chart 2-23 Saved Number Redial
27	Chart 2-24 External Call Forwarding
28	Chart 2-25 Call Forwarding Busy/Don't Answer
29	Chart 2-26 Hands-Free
30	Chart 2-27 Transfer with Privacy
31	Chart 2-28 Repeated Camp-on

1. GENERAL

1.01 This Section describes the extension test procedures for SX-100/SX-200 Automatic Call Distribution (ACD) Systems. These procedures should be performed as operational tests, upon installation of extensions after the initial system installation. See Section MITL9105/9110-090-200-NA for system installation instructions.

Reason for Issue

1.02 This practice has been issued to include Generic ACD information requiring an extension test procedure.

SUPERSET 4

1.03 For SUPERSET 4 extension test procedures, see APPENDIX 1.

SUPERSET 3

1.04 For SUPERSET 3 test procedures see APPENDIX 2.

2. TEST AND OPERATIONAL PROCEDURES**General**

2.01 Satisfactory completion of the extension test procedures confirms that the apparatus has been installed and programmed correctly.

2.02 If any operating procedure cannot be completed as described, verify that:

- The procedure is applicable to the extension (i.e. the feature being tested is assigned to the extension).
- The apparatus which provides the feature (e.g. Music on Hold) is correctly installed.

Operating Procedures

2.03 Chart 2-1 should be performed on each extension. Charts 2-2 through 2-28 should be performed once per system.

**CHART 2-1
STATION-TO-STATION CALL**

Step	Action	Verification
Called station idle:		
1.	Lift handset.	Dial tone returned.
2.	Dial any extension number.	Dial tone removed after first digit; ringback tone heard after completion of dialing.
3.	Called extension answers.	Ringback tone removed; 2-way conversation.
4.	Called and calling extensions replace handsets.	
Called station busy (enable Callback Busy):		
5.	Lift handset.	Dial tone returned.
6.	Dial originating extensions number.	Busy tone returned.
7.	Dial Callback code.	Dial tone returned.
8.	Replace handset.	
9.	Busy extension goes on-hook.	Original extension rings.
10.	Original extension answers.	Ringback tone returned; called extension rings.
11.	Called extension answers.	Two-way conversation.
Called station busy (member of a hunt group):		
12.	Lift handset.	Dial tone returned.
13.	Dial Hunt Group access code.	Dial tone removed after first digit; ringback tone heard; next free extension of group is rung.
14.	Free extension answers.	Ringback tone removed; 2-way conversation.
15.	Extensions replace handset.	

**CHART 2-2
HUNT GROUP**

Step	Action	Verification
First station idle (Terminal):		
1.	Lift handset.	Dial tone returned.
2.	Dial Hunt Group access code.	Dial tone removed after first digit; ringback tone heard upon completion of dialing. First extension in group hears ringing.
3.	First extension answers.	Ringback tone removed; 2-way conversation.
First station busy (Terminal):		
4.	Repeat Steps 1 and 2.	Next idle extension in group hears ringing.
5.	Next idle extension answers.	Ringback tone removed, 2-way conversation.
Hunt groups (Circular):		
6.	Repeat Steps 1 and 2.	Hunting starts at the extension after the last extension rung in the group. System will ring first idle extension in the hunt group; if no idle extension is found, busy tone is returned.

**CHART 2-3
BROKER'S CALL**

Step	Action	Verification
Extension in conversation wishes a private alternative conversation after flashing switchhook:		
1.	Flash switchhook.	Transfer dial tone returned.
2.	Extension dials number of third party.	Third party phone rings.
3.	Third party answers.	Extension and third party may now converse in private.
4.	Extension flashes switchhook.	Extension returns to original (1st) party.
5.	Third party is on hold. Extension may alternate between conversations by flashing switchhook.	The three parties CANNOT be joined together in one conversation.

CHART 2-4
CALL HOLD

Step	Action	Verification
To set up a Call Hold:		
1.	Extension in conversation wishes to put call on hold, flashes switchhook.	No tones or sound heard by extension on hold unless Music on Hold is provided. Flashing extension receives transfer dial tone.
2.	Extension dials Call Hold code.	Dial tone returned.
3.	Extension replaces handset.	Extension is now free to make or receive calls.
To retrieve the call at the original extension:		
4.	Extension lifts handset.	Dial tone returned.
5.	Extension dials Call Hold Local Retrieve code.	Extension connected to call on hold.
To retrieve a call at another extension:		
6.	Extension lifts handset.	Dial tone returned.
7.	Extension dials Call Hold Remote Retrieve code.	No tones or sound heard.
8.	Extension dials Call Holding extension's number.	Extension connected to call on hold.
To use Call Hold as a Broker feature:		
9.	Perform Steps 1, 2 and 3 under "To set up a Call Hold".	
10.	Extension lifts handset.	Dial tone returned.
11.	Extension dials third party.	Ringback tone heard; third extension's phone is ringing.
12.	Third party answers.	Conversation takes place.
13.	Extension flashes switchhook.	Transfer dial tone is returned.
14.	Extension dials Call Hold code.	Third party is placed on hold, second party is retrieved.

**CHART 2-4 (CONT'D)
CALL HOLD**

Step	Action	Verification
15.	Controlling extension may repeat Steps 13 and 14 as often as required.	Each repetition exchanges the party on hold with the one in the conversation.
To join all three parties into one conversation:		
16.	Extension flashes switchhook on second extension.	Transfer dial tone returned.
17.	Extension dials Call Hold Retrieve code.	Extension connected to third party.
18.	Extension flashes switchhook.	Three parties in conversation.

Note: A conference CANNOT be put on Call Hold.

**CHART 2-5
CALL FORWARDING - BUSY**

Step	Action	Verification
To set up Call Forwarding - Busy:		
1.	Forwarding extension lifts handset.	Dial tone returned.
2.	Extension dials Call Forwarding - Busy code, and number of extension to which calls are to be forwarded (calls may also be forwarded to the Supervisor).	Dial tone returned; forwarding successful.
3.	Extension replaces handset.	
To test Call Forwarding - Busy:		
4.	At extension in Steps 1-3 lift handset.	Dial tone returned.
5.	At an alternate extension lift the handset.	Dial tone returned.
6.	Dial extension with Call Forwarding - Busy in effect.	Ringback tone returned; extension that was forwarded to, rings.
7.	Replace handset.	
To cancel a Call Forwarding - Busy:		
8.	Extension lifts handset.	Dial tone returned.
9.	Extension dials Call Forwarding - Busy code.	No tones or sound heard.
10.	Extension replaces handset.	Cancellation complete.
To test cancellation:		
11.	Repeat Step 4.	Busy tone returned.
12.	Replace handset.	

**CHART 2-6
CALL FORWARDING - DON'T ANSWER**

Step	Action	Verification
To set up Call Forwarding - Don't Answer:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Call Forwarding - Don't Answer code and number of extension to which calls are to be forwarded (calls may also be forwarded to the Supervisor).	Dial tone returned; forwarding successful.
3.	Extension replaces handset.	
To test Call Forwarding - Don't Answer:		
4.	At an alternate extension lift the handset.	Dial tone returned.
5.	Dial extension with Call Forwarding - Don't Answer in effect.	Ringback tone returned. Do not answer the call after a time-out. The call will be transferred to the extension selected in 2.
6.	Replace handset.	
To cancel Call Forwarding - Don't Answer:		
7.	Extension lifts handset.	Dial tone returned.
8.	Extension dials Call Forwarding - Don't Answer code.	No tones or sound heard.
9.	Extension replaces handset.	Cancellation complete.
To test cancellation:		
10.	Repeat Steps 4 and 5.	Extension dialled rings normally.
11.	Replace handset.	

**CHART 2-7
CALL FORWARDING - FOLLOW ME**

Step	Action	Verification
To set up Call Forwarding - Follow Me:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Call Forwarding - Follow Me code and number of extension to which calls are to be forwarded (calls may also be forwarded to the Supervisor).	Dial tone returned; forwarding successful.
3.	Extension replaces handset.	
To test Call Forwarding - Follow Me:		
4.	At an alternate extension lift the handset.	Dial tone returned.
5.	Dial the extension with Call Forwarding - Follow Me in effect.	Ringback tone returned; extension that was forwarded to, rings.
6.	Replace handset.	
To cancel Call Forwarding - Follow Me:		
7.	Originating extension lifts handset.	Dial tone returned.
8.	Originating extension dials Call Forwarding - Follow Me code.	No tones or sound heard.
9.	Extension replaces handset.	Cancellation complete.

CHART 2-8
 OVERRIDE

Step	Action	Verification
1.	Establish a 2-party call.	Talking connection.
2.	Extension lifts handset.	Busy tone returned.
3.	Dial busy extension.	Busy tone returned.
4.	Calling extension dials Override code.	Parties in conversation hear a 1 second warning tone unless the COS of one or more of them prevents being overridden. After beep, calling extension is in conversation. All extensions will hear a short warning tone every 6 seconds.

**CHART 2-9
DIAL CALL PICKUP**

Step	Action	Verification
Any extension in the Pickup group is ringing:		
1.	Idle extension lifts handset.	Dial tone returned.
2.	Extension dials Dial Call Pickup code.	Extension is connected to calling party.

CHART 2-10
CAMP-ON

Step	Action	Verification
1.	Establish a 2-party call.	
2.	Extension lifts handset.	Dial tone returned.
3.	Dial busy extension.	Busy tone returned.
4.	Calling extension remains off-hook for more than 10 seconds.	a) Calling extension (after 10 seconds) receives a change in busy tone. b) The dialed extension receives a short warning tone.
5.	Busy extensions hang up.	Dialed extension is rung.

**CHART 2-11
AUTOMATIC CALLBACK - BUSY**

Step	Action	Verification
1.	Extension lifts handset.	Dial tone returned.
2.	Dial busy extension.	Busy tone returned.
3.	Calling extension dials Automatic Callback - Busy code.	Dial tone returned.
4.	Calling extension replaces handset.	
5.	Called extension replaces handset.	<ul style="list-style-type: none"> a) Calling extension rings. b) Called extension rings when calling extension answers. c) Calling extension hears ringback tone. d) Two-way conversation.

**CHART 2-12
DO NOT DISTURB**

Step	Action	Verification
Extension sets up Do Not Disturb:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Do Not Disturb code followed by 1.	Dial tone returned.
3.	Extension replaces handset.	
4.	Extension is not called while in the Do Not Disturb mode.	A calling extension receives reorder tone or Supervisor intercept.
Extension cancels Do Not Disturb:		
5.	Extension lifts handset.	Dial tone returned.
6.	Extension dials Do Not Disturb code followed by 2.	No tone or sound; Do Not Disturb is cancelled.
7.	Extension replaces handset.	Calling extensions can ring the original extension.

**CHART 2-13
CALL PARK/PICKUP**

Step	Action	Verification
To park an established call:		
1.	Flash switchhook.	Transfer dial tone returned.
2.	Extension dials Call Park code.	Dial tone returned to parking extension. No tones or sound heard unless music provided to parked extension.
3.	Extension replaces handset.	
To pick up a parked call from the parking extension:		
4.	Extension lifts handset.	Extension connected to parked call.
To pick up a parked call using an alternate extension:		
5.	Lift handset of alternate extension.	Dial tone returned.
6.	Alternate extension dials Call Park/Directed Call Pickup code and number of parking extension.	Alternate extension connected to parked call.

CHART 2-14
PAGING

Step	Action	Verification
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Paging zone code.	Extension receives a short warning tone. Extension may now page.
3.	Extension replaces handset.	
Repeat for each of the three codes if assigned.		

CHART 2-15
TRUNK ANSWER FROM ANY STATION

Step	Action	Verification
To answer a TAFAS call:		
1.	Extension user hears Night Bell.	
2.	Extension lifts handset.	Dial tone returned.
3.	Extension dials TAFAS night code.	Extension is connected to trunk call.
TRANSFER		
To idle extension		
4.	Third extension rings.	Perform Steps 1 and 2 in Consultation Hold
5.	Extension on hold receives ringing tone and is connected to third extension when it is answered.	Extension effects transfer, replaces handset
To busy extension		
6.	Third extension busy, ringing extension receives busy tone.	Perform Steps 1 and 2 in Consultation Hold
7.	Extension on hold receives busy tone and is transferred to busy line after 30 seconds.	Extension effects transfer, replaces handset
During consultation		
8.	Effecting extension and third extension converse.	Perform Steps 1 to 3 in Consultation Hold
9.	Extension on hold and third extension are connected.	Effecting extension hangs up

**CHART 2-16
CONSULTATION HOLD/TRANSFER/ADD-ON**

Step	Action	Verification
CONSULTATION HOLD		
Established call:		
1.	Extension flashes switchhook.	a) Flashing extension receives transfer dial tone. b) Second extension in conversation is put on hold, and hears music if provided.
2.	Extension which flashed, dials third extension.	Third extension rings.
3.	Third extension answers.	Effecting extension and third extension are connected. Second extension remains on hold.
TRANSFER		
To idle extension:		
4.	Perform Steps 1 and 2 in Consultation Hold.	Third extension rings.
5.	Extension effecting transfer replaces handset.	Extension on hold receives ringing tone, and is connected to third extension when it is answered.
To busy extension:		
6.	Perform Steps 1 and 2 in Consultation Hold.	Third extension busy, effecting extension receives busy tone.
7.	Extension effecting transfer replaces handset.	Extension on hold receives busy tone and is camped-on to busy line after 10 seconds.
During consultation:		
8.	Perform Steps 1 to 3 in Consultation Hold.	Effecting extension and third extension converse.
9.	Effecting extension hangs up.	Extension on hold and third extension are connected.

CHART 2-16 (CONT'D)
CONSULTATION HOLD/TRANSFER/ADD-ON

Step	Action	Verification
ADD-ON		
10.	Perform Steps 1 to 3 in Consultation Hold.	Effecting extension and third extension connected. Second extension remains on hold.
11.	Effecting extension flashes switchhook.	All three extensions connected.
After 3-way consultation:		
12.	Perform Steps 1 to 3 in Consultation Hold.	Effecting extension and third extension converse.
13.	Effecting extension flashes switchhook.	All extensions connected.
14.	Effecting extension replaces handset.	Remaining extensions remain connected.

CHART 2-17
AUTOMATIC WAKE-UP (ALARM CALL)

Step	Action	Verification
Extension sets Automatic Wake-up (Alarm Call):		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Automatic Wake-Up access code and Wake-Up time as a 4-digit number (24-hour clock).	Dial tone returned.
3.	Extension replaces handset.	
4.	At selected time:	Extension receives 6 rings every 5 minutes for a total of three attempts. a) Extension receives no tone or receives Music on Hold if provided.
Extension cancels Automatic Wake-up (Alarm Call):		
5.	Extension lifts handset.	Dial tone returned.
6.	Extension dials Automatic Wake-Up access code and 9999.	Dial tone returned.
7.	Extension replaces handset.	

CHART 2-18
MEET-ME CONFERENCE

Step	Action	Verification
To set up a Meet-Me Conference:		
1.	At at prearranged time, dial Meet-Me Conference access code from up to seven extensions.	First extension on hold. First extension hears warning tone as second extension is connected. Extensions in conference hear warning tone as succeeding extensions are connected.

**CHART 2-19
AUTOMATIC CALLBACK - DON'T ANSWER**

Step	Action	Verification
To set up Automatic Callback - Don't Answer:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials destination.	Destination extension rings.
3.	Extension receives no answer, flashes switchhook.	Dial tone returned.
4.	Extension dials Automatic Callback - Don't Answer code and number of extension called.	Dial tone returned.
5.	Extension replaces handset.	
6.	Called extension uses extension.	Extension goes busy for duration of call.
7.	Called extension replaces handset.	Calling extension rings.
8.	Calling extension lifts handset.	Called extension rings; calling extension hears ringback tone.
9.	Called extension answers.	Conversation takes place.

**CHART 2-20
DIRECTED CALL PICKUP**

Step	Action	Verification
	Any extension is ringing:	
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Directed Call Pickup code, and the number of the extension being rung.	Extension is connected to call.

**CHART 2-21
STATION CONFERENCE**

Step	Action	Verification
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials first conferee extension for Station Conference.	Called party extension rings.
3.	Called extension answers. Calling extension informs of conference, flashes switchhook and dials second conferee extension.	a) Calling extension and called extension connected. b) Called extension goes on hold. Calling extension receives transfer dial tone. c) Second conferee extension rings.
4.	Second conferee answers.	
5.	Calling extension flashes switchhook.	All extensions connected.
6.	Any extension may add up to a total of seven extensions to the Station Conference by repeating Steps 3(b) & 3(c).	

CHART 2-22
SPEED CALL

Step	Action	Verification
Extension programs a Speed Call:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Speed Call access code.	
3.	Extension dials 0.	
4.	Extension dials Speed Call Entry access code.	
5.	Extension dials Trunk Group access code or ARS code.	See Note.
6.	Extension dials digits to be used as Speed Call Number.	See Note.
7.	Extension replaces handset.	
To verify programmed number:		
8.	Extension dials Speed Call access code.	
9.	Extension dials Entry Access Number and manual digits if required.	If the call is successful, ringback tone will be returned from the CO and the correct number will be rung.

Note: *1 for 5 second pause, *2 for Wait for Dial Tone, or *3nn for user-dialed digits may be entered at any time.

**CHART 2-23
SAVED NUMBER REDIAL**

Step	Action	Verification
Extension programs a last number redial:		
1.	After completion of dialing an outside number, the extension has 10 seconds to dial an *. This will store the dialed number in the last number redial.	
To use Saved Number Redial:		
2.	Extension goes off-hook.	Dial tone returned.
3.	Extension dials Speed Call Feature access code.	
4.	Extension dials Entry Access Number for saved number redial.	Saved number dialed rings.

Note: If for a second dial, a 3 second pause is required. If the call is successful, the dial tone will be returned from the CO and the correct number will be rung. User-dialed digits may be entered at any time.

**CHART 2-24
EXTERNAL CALL FORWARDING**

Step	Action	Verification
Extension wishes to transfer all calls to an external number:		
1.	Repeat Steps 1-7 of Chart 2-22. (Note: It is possible to use manual digit insertion.)	
2.	Extension lifts handset.	Dial tone returned.
3.	Extension dials the External Call Forwarding access code.	No tone returned.
4.	Extension dials Speed Call access code and Speed Call Entry access code from Step 1.	Dial tone returned.
To verify External Call Forwarding:		
5.	From an alternate extension dial the External Call Forwarded extension.	If the External Call Forwarding is successful, the external number will be rung.

CHART 2-25
CALL FORWARDING BUSY/DON'T ANSWER

Step	Action	Verification
Extension wishes to have Call Forwarding Busy/Don't Answer active at the same time:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Call Forwarding Busy/Don't Answer code.	No tones returned.
3.	Extension dials extension number, calls are to be forwarded to.	Dial tone returned; all calls will be forwarded.
To test Call Forwarding Busy/Don't Answer:		
4.	Repeat Steps 4, 5 and 6 of Chart 2-5, and Steps 4 and 5 of Chart 2-6.	

CHART 2-26
HANDS-FREE

Step	Action	Verification
Extension wishes to place itself in a Hands-Free state:		
1.	Extension lifts handset.	Dial tone returned.
2.	Extension dials Hands-Free access code or remains off-hook for 15 seconds.	No tone returned; extension now in Hands-Free state.
3.	To remove extension from Hands-Free state, return handset to on-hook position.	Extension will be rung normally.

CHART 2-27
TRANSFER WITH PRIVACY

Step	Action	Verification
An extension wishes to consult with two parties privately, with the option of connecting them both together by going on-hook:		
1.	Extension is conversing with first party.	Normal conversation.
2.	Extension flashes the switchhook.	Dial tone returned.
3.	Extension dials new extension number.	Ringback tone returned, and extension converses privately when call is answered.
4.	Extension flashes switchhook and returns to original party. Extension may alternate between parties privately by flashing the switchhook.	Private conversation between original party and extension.
5.	Extension returns the handset to the on-hook position.	Both parties may now converse.

**CHART 2-28
REPEATED CAMP-ON**

Step	Action	Verification
<p>By enabling the appropriate COS and System Option, an extension or trunk will remain camped-on to an extension and have the camp-on warning tones repeated (programmable - every 5, 10 or 15 seconds).</p>		
1.	Establish a 2-party call.	
2.	Alternate extension lifts handset.	Dial tone returned.
3.	Dial extension in 2-party call.	Busy tone returned.
4.	Calling extension remains off-hook for more than 10 seconds.	a) Calling extension (after 10 seconds) receives a change in busy tone. b) The dialed extension receives a short warning tone.
5.	Calling extension remains off-hook.	The dialed extension continues to receive warning tones (every 5, 10 or 15 seconds as programmed).
6.	Dialed extension hangs up.	The dialed extension is rung; dialing extension receives ringback tone. Answer call; ensure 2-party call.

TABLE A1.1-1
RELATED MITEL PRACTICES

APPENDIX 1

SUPERSET 4

TEST PROCEDURES

A1. GENERAL

A1.01 This Appendix describes the test procedures for the SUPERSET 4. These procedures should be performed as operational tests upon installation of a SUPERSET 4, after the initial system installation. Refer to the appropriate MITEL practices Table A1.1-1 for system installation instructions and Feature descriptions.

A1.02 This Appendix has been issued to incorporate all information required to check out a SUPERSET 4 after installation.

A2. TEST AND OPERATIONAL PROCEDURES

GENERAL

A2.01 Satisfactory completion of the test procedures confirms correct key operation, liquid-crystal display activation, hookswitch functioning, and speaker output, and checks that the set has been installed correctly.

A2.02 When a SUPERSET 4 has power applied to it (i.e. is just connected to an operating system) or the system has just been powered-up, SUPERSET 4 is displayed for approximately 1 minute. Then the display clears to time and date.

A2.03 If any test fails, verify that the system is installed correctly and is powered-up.

A2.04 Perform the tests listed in Table A1.2-1 at each SUPERSET 4.

**TABLE A1.1-1
RELATED MITEL PRACTICES**

SECTION NO.	TITLE
MITL9105/9110-090-100-NA	General Description
MITL9105/9110-090-107-NA	SUPERSET 4 Features and Services Description
MITL9105/9110-090-200-NA	Shipping, Receiving, and Installation Instructions


- A1.01 Satisfactory completion of the test procedures confirms correct key operation, liquid-crystal display activation, hookswitch functioning, and speaker output, and checks that the set has been installed correctly.
- A1.02 When a SUPERSET 4 has power applied to it (i.e. is just connected to an operating system) or the system has just been powered-up, SUPERSET 4 is displayed for approximately 7 minutes. Then the display clears to time and date.
- A1.03 If any test fails, verify that the system is installed correctly and powered-up.
- A1.04 Perform the tests listed in Table A1.1-1 at each SUPERSET 4.

**TABLE A1.2-1
INSTALLER LOOP TEST ROUTINES**

Step	Action	Verification	Notes																										
Accessing Test Routines																													
1.	Go off-hook (handset or hands-free)	- Dial tone returned. - Line status display indicates line busy at this set.	1																										
2.	Dial Loop Test Access Code	- "TEST! PRESS KEYS" displayed.	2, 3																										
Keypad Test																													
3.	Press keys 1-9, *, 0, and # in turn	- DTMF tones are heard through handset or speaker. - a 2-digit number is displayed, as follows: <table border="1"> <thead> <tr> <th>Key Pressed</th> <th>Number Displayed</th> </tr> </thead> <tbody> <tr><td>1</td><td>01</td></tr> <tr><td>2</td><td>02</td></tr> <tr><td>3</td><td>03</td></tr> <tr><td>4</td><td>04</td></tr> <tr><td>5</td><td>05</td></tr> <tr><td>6</td><td>06</td></tr> <tr><td>7</td><td>07</td></tr> <tr><td>8</td><td>08</td></tr> <tr><td>9</td><td>09</td></tr> <tr><td>*</td><td>10</td></tr> <tr><td>0</td><td>00</td></tr> <tr><td>#</td><td>11</td></tr> </tbody> </table>	Key Pressed	Number Displayed	1	01	2	02	3	03	4	04	5	05	6	06	7	07	8	08	9	09	*	10	0	00	#	11	
Key Pressed	Number Displayed																												
1	01																												
2	02																												
3	03																												
4	04																												
5	05																												
6	06																												
7	07																												
8	08																												
9	09																												
*	10																												
0	00																												
#	11																												
Supplementary Feature Buttons Test																													
4.	Press the "display", "display features", "speaker on/off", and "mic. on/off" buttons in turn.	A 2-digit number is displayed as follows: <table border="1"> <thead> <tr> <th>Button Pressed</th> <th>Number Displayed</th> </tr> </thead> <tbody> <tr><td>display</td><td>12</td></tr> <tr><td>features</td><td>13</td></tr> <tr><td>speaker on/off</td><td>14</td></tr> <tr><td>mic. on/off</td><td>15</td></tr> </tbody> </table>	Button Pressed	Number Displayed	display	12	features	13	speaker on/off	14	mic. on/off	15	4 5 6																
Button Pressed	Number Displayed																												
display	12																												
features	13																												
speaker on/off	14																												
mic. on/off	15																												

**TABLE A1.2-1 (CONT'D)
INSTALLER LOOP TEST ROUTINES**

Step	Action	Verification	Notes
Feature Select Buttons and Features Display Test			
5.	Press each of the feature select (unmarked) buttons in turn.	The prompts above each button are activated, and a 2-digit number is displayed. See Figure A1-1.	7
6.	Press the display features button.	Supplementary feature names are activated (see Figure A1-1).	8
Line Select Buttons, Hold Button, Line Status Display, and Tone Ringer Test			
7.	Press the red hold button and each line select button in turn	<ul style="list-style-type: none"> - The line status display next to each button (except hold) is activated to indicate an incoming call (alternating square/circle format). - A 2-digit number is displayed, as follows: <ul style="list-style-type: none"> hold button = 30 to upper line select button = 45 - The tone-ringer sounds when the upper line select button is pressed. 	
Hookswitch Test			
8(a)	If the tests are run with the handset on-hook, lift the handset.	"HANDSET UP" displayed	
(b)	Press the "speaker on/off" button, and replace the handset.	Number 14 displayed, then "HANDSET DOWN" displayed.	
9(a)	If the tests are run with the handset off hook, replace handset.	"HANDSET DOWN" displayed.	
(b)	Lift handset.	"HANDSET UP" displayed.	



X5949

Figure A1-1 Feature Select Buttons and Features Display Test

TABLE A1.2-1 (CONT'D)
INSTALLER LOOP TEST ROUTINES

Step	Action	Verification	Notes
Terminating Test Routines			
10.	If the tests are run with the handset on-hook, press the "speaker on/off" button, or if the tests are run with the handset off-hook, replace the handset.	Set becomes idle; time and date are displayed.	

- Notes:**
1. If test is run in hands-free mode, "MIC ON" is displayed.
 2. Access code is found in the relevant switch practice.
 3. All prompts and line status displays are cleared. "MIC ON" remains if test is run in hands-free mode.
 4. Supplementary feature names are also displayed.
 5. Do not press this button if test is run in hands-free mode, as it will cause the test to be terminated.
 6. If test is run in hands-free mode, "MIC ON" prompt is turned on or off each time this button is pressed.
 7. Prompts remain displayed after button is released to allow error patterns to be detected.
 8. Supplementary feature names remain displayed until another button is pressed.



APPENDIX 2

SUPERSET 3

TEST PROCEDURES

A2.1 GENERAL

A2.1.01 This Appendix describes the test procedures for the SUPERSET 3. These procedures should be performed as operational tests upon installation of a SUPERSET 3, after the initial system installation. Refer to the appropriate MITEL practices Table A2.1-1 for system installation instructions and Feature descriptions.

Reason for Issue

A2.1.02 This Appendix has been issued to incorporate all information required to check out a SUPERSET 3 after installation.

A2.2 TEST AND OPERATIONAL PROCEDURES

General

A2.2.01 Satisfactory completion of the test procedures confirms that the set has been installed correctly.

A2.2.02 When a SUPERSET 3 has power applied to it (i.e. is just connected to an operation system) or the system has just been powered-up, the test outlined in Table A2.2-1 is automatically performed.

A2.2.03 If any test fails, verify that the system is installed correctly and is powered-up.

**TABLE A2.1-1
RELATED MITEL PRACTICES**

Section No.	Title
MITL9105/9110-090-100-NA	General Description
MITL9105/9110-090-107-NA	SUPERSET 3 Features and Services Description
MITL9105/9110-090-200-NA	Shipping, Receiving, and Installation Instructions

TABLE A2.2-1

Test	LED			Timing
	1	2	3	
1	ON	ON	ON	1 second all on
2	FLASHING	OFF	OFF	10-15 seconds
3	OFF	OFF	OFF	if set is on hook
OR	ON	OFF	OFF	if set is off hook 10 to 15 seconds

Note: If all LEDs turn on steady for more than a few seconds there is an error. Check wiring then try a known good spare.