

# Panasonic

2.4GHz Cordless Phone

## Operating Instructions

Model No. **KX-TG2564S**

Pulse-or-tone dialing capability



Caller ID Compatible

**PLEASE READ BEFORE USE AND SAVE.**

**Charge the battery for about 15 hours before initial use.**

**Panasonic World Wide Web address: <http://www.panasonic.com>**  
for customers in the USA or Puerto Rico

Preparation

Basic Operation

Advanced Operation

Useful Information

# Before Initial Use

Please read **IMPORTANT SAFETY INSTRUCTIONS** on page 71 before use.  
Read and understand all instructions.

**Thank you for purchasing your new Panasonic cordless telephone.**

Caller ID and Call Waiting Service, where available, are telephone company services. After subscribing to Caller ID, this phone will display a caller's name and phone number. Call Waiting Caller ID, which displays a second caller's name and phone number while the user is on another call, requires a subscription to both Caller ID and Call Waiting.

Attach your purchase receipt here.


## For your future reference

Serial No. \_\_\_\_\_ Date of purchase \_\_\_\_\_  
(found on the bottom of the unit)

Name and address of dealer \_\_\_\_\_

## Accessories (included) For extra orders, call 1-800-332-5368.

- AC Adaptor (p. 10)  
Order No. PQLV10Z



one

- Telephone Line Cord  
(p. 10)  
Order No. PQJA10075Z




one

- Handset (p. 10)  
Order No. PQJXF0621Z



one

- Handset Cord (p. 10)  
Order No.  
PFJA04C001Z



one

- Belt Clip (p. 62)  
Order No.  
PQKE10127Z3



one

- Charger Unit (p. 11)  
Charger Order No.  
PQLV30016ZS  
AC Adaptor Order No.  
KX-TCA1-G (KX-TCA1)



one

# For Best Performance

## Battery Charge

A rechargeable Ni-Cd battery powers the cordless handset. Charge the battery for about **15 hours** before initial use (p. 11).




## Base Unit Location/Noise

Calls are transmitted between the base unit and the cordless handset using wireless radio waves. **For maximum distance and noise-free operation**, the recommended base unit location is:

Away from electrical appliances such as a TV, personal computer or another cordless phone.

In a **HIGH and CENTRAL** location with no obstructions such as walls.



### Note:

While using the cordless handset:

- If you are near a microwave oven which is being used, noise may be heard from the receiver. Move away from the microwave oven and closer to the base unit.
- If you use the cordless handset near another cordless phone's base unit, noise may be heard. Move away from the other cordless phone's base unit and closer to your base unit.

# Contents

## Preparation

<b>Location of Controls</b> .....	6
<b>Displays</b> .....	9
<b>Settings</b> .....	10
Connections .....	10
Battery Charge .....	11
Date and Time <small>Cordless Handset</small> .....	13
Dialing Mode <small>Cordless Handset</small> .....	15
Line Mode <small>Cordless Handset</small> .....	16
<b>Programmable Functions</b> .....	17
Auto Talk Feature <small>Cordless Handset</small> .....	19
Ringer Volume <small>Cordless Handset</small> <small>Base Unit</small> .....	20
LCD Contrast <small>Cordless Handset</small> <small>Base Unit</small> .....	21

## Basic Operation

<b>Making Calls</b> <small>Cordless Handset</small> <small>Base Unit</small> .....	23
<b>Answering Calls</b> <small>Cordless Handset</small> <small>Base Unit</small> .....	28
<b>Caller ID Service</b> .....	29
<b>Using the Caller List</b> .....	30
Viewing the Caller List <small>Cordless Handset</small> <small>Base Unit</small> .....	30
Calling Back from the Caller List <small>Cordless Handset</small> <small>Base Unit</small> .....	31
Editing the Caller's Phone Number <small>Cordless Handset</small> <small>Base Unit</small> .....	32
The Caller ID Number Auto Edit Feature <small>Cordless Handset</small> .....	34
Storing Caller List Information in the Directory <small>Cordless Handset</small> .....	36
Erasing Caller List Information <small>Cordless Handset</small> <small>Base Unit</small> .....	37

## Advanced Operation

<b>Directory</b> .....	39
Storing Names and Numbers <small>Cordless Handset</small> .....	39
Entering Names and Symbols <small>Cordless Handset</small> .....	41
Finding Stored Items <small>Cordless Handset</small> <small>Base Unit</small> .....	42
Dialing <small>Cordless Handset</small> <small>Base Unit</small> .....	44
Editing <small>Cordless Handset</small> .....	45
Erasing <small>Cordless Handset</small> <small>Base Unit</small> .....	46
<b>One-Touch Dialer</b> .....	47
Storing Phone Numbers in Memory <small>Base Unit</small> .....	47
Dialing <small>Base Unit</small> .....	48
<b>Intercom</b> <small>Cordless Handset</small> <small>Base Unit</small> .....	49
Transferring a Call Using the Intercom <small>Cordless Handset</small> <small>Base Unit</small> .....	50
<b>Conference</b> <small>Cordless Handset</small> <small>Base Unit</small> .....	51

<b>Voice Mail Service</b> .....	52
Storing a Voice Mail Access Number <b>Cordless Handset</b> .....	52
Setting the Voice Mail (VM) Tone Detection <b>Cordless Handset</b> .....	54
Listening to Voice Mail Messages <b>Cordless Handset</b> <b>Base Unit</b> .....	55
<b>Special Features</b> .....	56
Temporary Tone Dialing (For Rotary or Pulse Service Users)	
<b>Cordless Handset</b> <b>Base Unit</b> .....	56
Muting Your Conversation <b>Cordless Handset</b> <b>Base Unit</b> .....	56
For Call Waiting Service Users <b>Cordless Handset</b> <b>Base Unit</b> .....	57
How to Use the PAUSE Button	
(For PBX Line/Long Distance Calls) <b>Cordless Handset</b> <b>Base Unit</b> ..	57
FLASH Button <b>Cordless Handset</b> <b>Base Unit</b> .....	58
Security Code Setting <b>Cordless Handset &amp; Base Unit</b> .....	59

**Useful Information**

<b>Wall Mounting</b> .....	60
<b>Belt Clip</b> .....	62
<b>Optional Headset</b> .....	62
<b>Battery Replacement</b> .....	63
<b>Adding Another Phone</b> .....	64
<b>If the Following Appear...</b> .....	64
<b>Troubleshooting</b> .....	<b>66</b>
<b>Important Safety Instructions</b> .....	71
<b>FCC and Other Information</b> .....	73
<b>Specifications</b> .....	76
<b>Warranty</b> .....	77
<b>Index</b> .....	79

**Important:**

**Cordless Handset** : Perform with the cordless handset.

**Base Unit** : Perform with the base unit.

**Cordless Handset** **Base Unit** : Perform with the cordless handset and the base unit separately.

**Cordless Handset & Base Unit** : Perform with both the cordless handset and base unit together.

Preparation


Basic Operation


Advanced Operation

Useful Information

# Location of Controls

## Base unit





### How to use the Navigator key

This key has four active areas that are indicated by arrows.




- Pressing the up and down arrows allows you to enter the Caller List and scroll through the function menu, the Caller List and the directory list. They are also used to adjust the handset and speaker volumes.
- Pressing the right and left arrows allows you to enter the directory list.
- Pressing the right arrow allows you to select or confirm your menu choices.

Throughout this Operating Instructions, the navigator key is indicated by the arrows ▼, ▲, ◀ or ▶.

## ► Location of Controls

### Cordless handset



#### How to use the Navigator key


This key has four active areas that are indicated by arrows.



- Pressing the up and down arrows allows you to enter the Caller List and scroll through the function menu, the Caller List and the directory list. They are also used to adjust the cordless handset receiver volume.
- Pressing the right and left arrows allows you to enter the directory list and move the cursor when entering directory items.
- The right arrow is used to select or confirm your menu choices and to edit a phone number of the Caller List into one of 3 patterns. The left arrow is used to select a clearer channel.


Throughout this Operating Instructions, the navigator key is indicated by the arrows ▼, ▲, ◀ or ▶.

## Charger unit



## Displays


### Cordless handset



① The display shows the dialed number, call status, programming options and directory items etc. If you subscribe to a Caller ID service, caller information will be displayed (p. 29). The number of new calls will also be displayed.

- ② The voice mail icon displays when the voice mail message(s) is/are recorded (p. 52).
- ③ The directory icon displays when storing or viewing the directory items (p. 39, 42).
- ④ The battery icon indicates the battery strength.

### Base unit




① The time and date is displayed while the unit is not in use. The display shows the dialed number, call status, programming options and directory items etc. If you subscribe to a Caller ID service, caller information will be displayed (p. 29). The number of new calls will also be displayed.

- ② The voice mail icon displays when the voice mail message(s) is/are recorded (p. 52).

# Settings

## Connections


### Base unit



- USE ONLY WITH Panasonic AC ADAPTOR PQLV10 (Order No. PQLV10Z).
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- Use only a Panasonic Handset for the KX-TG2564S.
- To connect a standard telephone on the same line, see page 64.
- If your unit is connected to a PBX which does not support Caller ID services, you cannot access those services.



## Charger unit




- USE ONLY WITH Panasonic AC ADAPTOR KX-TCA1 (Order No. KX-TCA1-G).
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)

## Battery Charge

Place the cordless handset on the charger and charge for about **15 hours** before initial use.

- Make sure the cordless handset faces forward as shown.
- The CHARGE indicator lights and a beep sounds.
- Charge time may be longer than 15 hours depending on circumstance noise condition.



## Battery strength

You can check the battery strength on the cordless handset display. The battery strength is as shown in the chart below.


Display prompt	Battery strength
{■■■■}	Fully charged
{■■■}	Medium
{■■}	Low
⚡{■■}⚡ (flashing)	Needs to be recharged.

## ► Settings

### Recharge

Recharge the battery when:

- “Recharge battery” is displayed,
- “{ ■}” flashes on the display, or
- the cordless handset beeps intermittently while it is in use.



Recharge battery  
{ ■}

- If you DO NOT recharge the cordless handset battery for more than 15 minutes, the display will continually indicate “Recharge battery” and/or “{ ■}” will continue to flash when the cordless handset is lifted off the charger.

### Battery information

After your Panasonic battery is fully charged (p. 11):

Operation		Approx. battery life
While in use (TALK)	near the base unit*	Up to about 4.5 hours
	away from the base unit	Up to about 3.5 hours
While not in use (Standby)		Up to about 11 days

\*Within about 10 feet (3 m)

- Battery life may be shortened depending on usage conditions, such as viewing the Caller ID Caller List or directory list, and ambient temperature.
- Clean the charge contacts of the cordless handset and the charger with a soft, dry cloth once a month. Clean more often if the unit is subject to grease, dust or high humidity.** Otherwise the battery may not charge properly.
- If the battery is fully charged, you do not have to place the cordless handset on the charger until “Recharge battery” is displayed and/or “{ ■}” flashes. This will maximize the battery life.
- The battery cannot be overcharged.



# Date and Time Base Unit

Make sure the base unit and cordless handset are not being used.

1 Press **FUNCTION/EDIT**.

▶Date and time  
Save DIRECT#  
▼▲ ▶=Yes

2 Press **▶** (Yes key) at "Date and time".

Date:2002.01.01  
0-9=Date ◀▶  
▼=Next

3 Enter the current date (year, month, and day) using 4-digit numbers.  
(Ex. To set Apr. 15, 2002, enter "2002" and "0415".)

Date:2002.04.15  
0-9=Date ◀▶  
▼=Next

4 Press **▼** (Next key).

Time:12:00AM  
0-9=Time ◀▶  
\*=AM/PM ▼=Next

5 Enter the current time (hour and minute) using a 4-digit number.  
(Ex. To set 9:30, enter "0930".)

Time:09:30AM  
0-9=Time ◀▶  
\*=AM/PM ▼=Next

6 Select "AM" or "PM" by pressing **\***.

Time:09:30PM  
0-9=Time ◀▶  
\*=AM/PM ▼=Next

7 Press **▼** (Next key).

Date:2002.04.15  
Time:09:30PM  
▲=Edit ▶=Save

8 Press **▶** (Save key).

Date:2002.04.15  
Time:09:30PM

- A beep sounds.
- The clock starts working.
- If 3 beeps sound, the setting is not correct. Start again from step 3.
- To exit the programming mode, press **EXIT**.

- You can exit the programming mode any time by pressing **EXIT**.
- In step 5, you cannot enter numbers greater than 12. **Do not use military time.** (To set 13:00 hours, enter "0100", and select "PM" by pressing **\***.)
- If you enter a wrong number in step 3 or step 5, press **◀** or **▶** to move the cursor to the incorrect number. Enter the correct number.

## ► Settings

---

If a power failure occurs, the time/date flashes on the base unit display. Adjust the date/time.

### **For Caller ID service users** (p. 29)

- The Caller ID information will reset the clock after the first ring if the adjusted time and/or date is incorrect.
- If the time has not previously been set, the Caller ID information will not adjust the clock.
- The Caller ID information will automatically adjust the clock for daylight saving time.



# Dialing Mode Cordless Handset

You can program the dialing mode **using the cordless handset near the base unit**. If you have touch tone service, set to "Tone". If rotary or pulse service is used, set to "Pulse". Your phone comes from the factory set to "Tone".

**Make sure the base unit and cordless handset are not being used.**

1 Press **MUTE/FUNCTION**.

▶Save directory  
 Ringer volume  
 ▼▲ ▶=Yes

2 Scroll to "Program" by pressing ▼ or ▲.

LCD contrast  
 ▶Program  
 ▼▲ ▶=Yes

3 Press ▶ (Yes key).

▶Set flash time  
 Set line mode  
 ▼▲ ▶=Yes

4 Scroll to "Set dial mode" by pressing ▼ or ▲.

▶Set dial mode  
 Auto talk  
 ▼▲ ▶=Yes

5 Press ▶ (Yes key).

Dial mode  
 :Tone  
 ▼▲ ▶=Save

6 Select "Pulse" or "Tone" by pressing ▼ or ▲.

Dial mode  
 :Pulse  
 ▼▲ ▶=Save

7 Press ▶ (Save key).

- A beep sounds.
- To exit the programming mode, press **OFF**.

Dial mode  
 :Pulse








•You can exit the programming mode any time by pressing **OFF**.

## ► Settings

### Line Mode **Cordless Handset**

You can program the line mode **using the cordless handset near the base unit**. If the line is connected to a low voltage system such as a PBX, set to "B". Otherwise the Call Waiting Caller ID Feature may not be used (p. 57). Your phone comes from the factory set to "A".

**Make sure the base unit and cordless handset are not being used.**

- 1 Press **MUTE/FUNCTION**.  

- 2 Scroll to "Program" by pressing ▼ or ▲.  

- 3 Press ► (Yes key).  

- 4 Scroll to "Set line mode" by pressing ▼ or ▲.  

- 5 Press ► (Yes key).  

- 6 Select "B" or "A" by pressing ▼ or ▲.  

- 7 Press ► (Save key).
  - A beep sounds.
  - To exit the programming mode, press **OFF**.

• You can exit the programming mode any time by pressing **OFF**.

# Programmable Functions



## Cordless Handset

You can program the following function items **using the cordless handset near the base unit**. The display shows the programming instructions. See the corresponding pages for function details.

**Make sure the base unit and cordless handset are not being used.**

Press **MUTE/FUNCTION** on the cordless handset.



<Function menu>\*

- ▶ Save directory..... To store an item in the directory (p. 39).
- Ringer volume..... To select the ringer volume (p. 20).
- LCD contrast..... To select the LCD contrast of the cordless handset (p. 21).
- Program

Scroll to "Program" by pressing ▼ or ▲, and press ► (Yes key).

<Function menu>\*

- ▶ Set flash time..... To select the flash time (p. 58).
- Set line mode..... To select the line mode (p. 16).
- Set dial mode..... To select the dial mode (p. 15).
- Auto talk..... To set the Auto Talk feature (p. 19).
- Save VM access#..... To set the voice mail access number (p. 52).
- VM tone detect..... To select the voice mail tone (p. 54).
- Caller ID edit..... To set the Caller ID Number Auto Edit feature (p. 34).

### During programming

\*To select a desired function item, scroll through the items by pressing ▼ or ▲. Then press ► (Yes key) to go to the next step.

- You can exit the programming mode any time by pressing **OFF**.
- If the cordless handset has lost communication with the base unit, 3 beeps sound and "No link to base. Walk closer to base & try again" is displayed.

## ► Programmable Functions

---

### Base Unit

You can program the following function items **using the base unit**. The display shows the programming instructions. See the corresponding pages for function details.

**Make sure the base unit and cordless handset are not being used.**

Press **FUNCTION/EDIT** on the base unit.



<Function menu>\*

►Date and time .....	To adjust the date and time (p. 13).
Save DIRECT# .....	To store the phone numbers in the DIRECT buttons (p. 47).
LCD contrast .....	To select the LCD contrast of the base unit (p. 22).

### During programming

\*To select a desired function item, scroll through the items by pressing **▼** or **▲**. Then press **►** (Yes key) to go to the next step.

- You can exit the programming mode any time by pressing **EXIT**.



# Auto Talk Feature Cordless Handset

The Auto Talk feature allows you to answer a call by lifting the cordless handset off the charger without pressing . If you want to use this feature, turn the feature ON by programming. Your phone comes from the factory set to OFF.

**Make sure the base unit and cordless handset are not being used.**

- 1 Press **MUTE/FUNCTION**.
 

▶Save directory  
 Ringer volume  
 ▼▲ ▶=Yes
- 2 Scroll to "Program" by pressing or .
 

LCD contrast  
 ▶Program  
 ▼▲ ▶=Yes
- 3 Press (Yes key).
 

▶Set flash time  
 Set line mode  
 ▼▲ ▶=Yes
- 4 Scroll to "Auto talk" by pressing or .
 

Set dial mode  
 ▶Auto talk  
 ▼▲ ▶=Yes
- 5 Press (Yes key).
 

Auto talk  
 : Off  
 ▼▲ ▶=Save
- 6 Select "On" or "Off" by pressing or .
 

Auto talk  
 : On  
 ▼▲ ▶=Save
- 7 Press (Save key).
 

Auto talk  
 : On

  - A beep sounds.
  - To exit the programming mode, press **OFF**.

- You can exit the programming mode any time by pressing **OFF**.
- In order to view Caller ID information after you lift the cordless handset off the charger to answer a call, leave the Auto Talk feature OFF.

## ► Programmable Functions

### Ringer Volume

You can program the cordless handset and base unit ringer volumes to HIGH, LOW or OFF. If set to OFF, the cordless handset and base unit will not ring. Your phone comes from the factory set to HIGH.

**Make sure the base unit and cordless handset are not being used.**

#### Cordless Handset

- 1 Press **MUTE/FUNCTION**.
- 2 Scroll to "Ringer volume" by pressing **▼** or **▲**.
- 3 Press **▶** (Yes key).
  - The current setting is displayed.
- 4 Select the desired volume by pressing **▼** or **▲**.
  - Each time you press **▼** or **▲**, the volume will change and ring.
  - If you set to OFF, the unit will not ring.
- 5 Press **▶** (Save key).
  - A beep sounds.

▶Save directory  
Ringer volume  
▼▲ ▶=Yes

Save directory  
▶Ringer volume  
▼▲ ▶=Yes

HIGH  
Ringer  
Low ■■■■■■ High  
▼▲ ▶=Save

LOW  
Ringer  
Low ■■ High  
▼▲ ▶=Save

OFF  
Ringer off  
▼▲ ▶=Save

- You can exit the programming mode any time by pressing **OFF**.
- When you replace the battery, the selected ringer volume setting will return to the factory set (HIGH). Reprogram if necessary.

#### Base Unit

- To select **HIGH (preset) or LOW**, press **RINGER**.  
Each time you press the button, the ringer volume will change and ring.
- To turn the ringer **OFF**, press and hold **RINGER** until 2 beeps sound.  
"Ringer off" is displayed.
- To turn the ringer **ON**, press **RINGER**.  
The ringer will sound at the HIGH level.




# LCD Contrast

You can program the cordless handset and base unit LCD contrast (5 levels). To make the displays clearer, set to high level. Your phone comes from the factory set to level 3.


**Make sure the base unit and cordless handset are not being used.**

## Cordless Handset

1 Press **MUTE/FUNCTION**.



2 Scroll to "LCD contrast" by pressing or .



3 Press (Yes key).



4 Select the desired contrast by pressing or .

- Each time you press or , the LCD contrast will change.



5 Press (Save key).

- A beep sounds.
- To exit the programming mode, press **OFF**.



- You can exit the programming mode any time by pressing **OFF**.

# ▶ Programmable Functions

---

## Base Unit

1 Press **FUNCTION/EDIT**.

```
▶Date and time
  Save DIRECT#
▼▲                               ▶=Yes
```

2 Scroll to "LCD contrast" by pressing ▼ or ▲.

```
▶LCD contrast
▼▲                               ▶=Yes
```

3 Press ▶ (Yes key).  
•The current setting is displayed.

```
  LCD contrast
  Low █ █ █ High
▼▲                               ▶=Save
```

4 Select the desired contrast by pressing ▼ or ▲.  
•Each time you press ▼ or ▲, the LCD contrast will change.

```
  LCD contrast
  Low █ █ High
▼▲                               ▶=Save
```

5 Press ▶ (Save key).  
•A beep sounds.  
•To exit the programming mode, press **EXIT**.

```
  LCD contrast
  Low █ █ High
```


•You can exit the programming mode any time by pressing **EXIT**.

# Making Calls



## Cordless Handset

To have a hands-free conversation, connect an optional headset to the handset (p. 62).



1 Press

Talk

2 Dial a phone number.

- The dialed number is displayed.
- After a few seconds, the display will show the length of the call and the battery strength.

Talk  
1112222

Talk  
00-00-00 {■■■■}

3 To hang up, press **OFF** or place the cordless handset on the charger.

Off  
00-01-08 {■■■■}

- “Line in use” is displayed on the base unit while the cordless handset is engaged in an outside call.
- If the cordless handset has lost communication with the base unit, 3 beeps sound and “No link to base. Walk closer to base & try again” is displayed.

## ► Making Calls

---

### To dial after confirming the entered number

- 1 Dial a phone number.
  - If you misdial, press **CLEAR/INTERCOM/HOLD** and dial again.



3334444

- 2 Press .
- After a few seconds, the display will show the length of the call and the battery strength.



Talk  
3334444

- 3 To hang up, press **OFF** or place the cordless handset on the charger.



Off  
00-01-08 [||||]

### If noise interferes with the conversation

Press  to select a clearer channel in the talk or intercom mode, or move closer to the base unit.

### To redial the last number dialed on the cordless handset

Press  → **REDIAL/PAUSE**.

### To dial after confirming the last number dialed on the cordless handset

Press **REDIAL/PAUSE** → .



## To put a call on hold

Press **CLEAR/INTERCOM/HOLD**.

Line on HOLD.  
To transfer  
press INTERCOM.

- “Line on HOLD.” is displayed on the base unit.
- The DIGITAL SP-PHONE indicator flashes.
- If you put a call on hold for more than 6 minutes, an alarm tone will sound. The call will be disconnected after a total of 10 minutes.
- To transfer the call to the base unit, see page 50.

## To release the hold

From the cordless handset, press


From the base unit, press **DIGITAL SP-PHONE** or lift the handset.

- If another phone is connected on the same line (p. 64), you can also release the hold by lifting its handset.

## To select the receiver volume

Press or while talking.

- Each time you press or , the volume level will change among 3 levels (HIGH, MEDIUM, or LOW).
- The display will return to the length of the call.



## Lighted cordless handset keypad

The cordless handset dialing buttons will light when you press a button or lift the cordless handset off the charger, and flash when a call is received. The lights will go out a few seconds after pressing a button to start operations, lifting the cordless handset or answering a call or pressing a button to complete operations such as hanging up a call, leaving the Caller List/Directory or programming.


## Backlit LCD display

The lighted cordless handset display will stay on for a few seconds after pressing a cordless handset button or lifting the cordless handset off the charger.

## ► Making Calls

### Base Unit

You can make a call by simply lifting the handset and dialing the phone number. To hang up, place the handset on the cradle.



### Using the speakerphone

- 1 Press **DIGITAL SP-PHONE**.
- The indicator lights.

Talk

- 2 Dial a telephone number.
- The dialed number is displayed.
  - After a few seconds, the display will show the length of the call.

Talk

1112222

- 3 When the other party answers, talk into the **MIC** (microphone).

Talk

00-00-00

- 4 To hang up, press **DIGITAL SP-PHONE**.
- The indicator light goes out.

Off

00-01-08

•“Line in use” is displayed on the cordless handset while the base unit is engaged in an outside call.

### To redial the last number dialed

Lift the handset or press **DIGITAL SP-PHONE** → **REDIAL**.

## Hands-free Digital Duplex Speakerphone

- For best speaker performance, use in a quiet room and talk alternately with the caller.
- If the other party has difficulty hearing you, press  to decrease the speaker volume. Decreasing the speaker volume will increase the microphone sensitivity.
- You can switch to the handset by lifting it up. To switch back to the speakerphone, press **DIGITAL SP-PHONE**.

## To adjust the handset volume (3 levels) or speaker volume (8 levels) while talking

To increase, press .

To decrease, press .

- The display shows the volume level for a few seconds.

Ex. Handset volume level: 2

Loud  
Low  High

Ex. Speaker volume level: 3

Loud  
Low  High

## To put a call on hold

Press **HOLD**.

- "Line on HOLD." is displayed on the cordless handset.
- The DIGITAL SP-PHONE indicator flashes.
- If using the handset, you can place it on the cradle.
- If you put a call on hold for more than 6 minutes, an alarm tone will sound. The call will be disconnected after a total of 10 minutes.
- To transfer the call to the cordless handset, see page 50.

Line on HOLD.  
To transfer  
press INTERCOM.

## To release the hold

From the base unit:

—when using the speakerphone, press **DIGITAL SP-PHONE** or lift the handset.

—when using the handset, press **HOLD**.

From the cordless handset, press .

- If another phone is connected on the same line (p. 64), you can also release the hold by lifting its handset.

## Backlit LCD display

The lighted base unit display will stay after lifting the handset or pressing **DIGITAL SP-PHONE**.

# Answering Calls

When a call is received, the unit rings and "Incoming call" is displayed. If you subscribe to a Caller ID service, the calling party information will be displayed after the first ring (p. 29).

In order to view the Caller ID information, please wait until the second ring to answer a call.

## Cordless Handset

Press .

- You can also answer a call by pressing any dialing button **0** to **9**, **\*** or **#** (—Any Key Talk).
- You can select the ringer volume while a call is being received. Press  or  while the cordless handset is just ringing. To set to OFF, press and hold .



## Auto Talk

If you set the Auto Talk feature to ON (p. 19), you can answer a call by lifting the cordless handset off the charger without pressing .



## Base Unit

You can answer a call by simply lifting the handset. To hang up, place the handset on the cradle.

## Using the speakerphone

- 1 Press **DIGITAL SP-PHONE**.
  - The indicator lights.
- 2 Talk into the **MIC**.
- 3 To hang up, press **DIGITAL SP-PHONE**.
  - The indicator light goes out.



- You can select the ringer volume while a call is being received. Press **RINGER** while the base unit is just ringing. To set to OFF, press and hold **RINGER**.
- When the cordless handset and base unit ringer volumes are set to OFF, they will not ring (p. 20).

# Caller ID Service

This unit is compatible with a Caller ID service offered by your telephone company. If you subscribe to a Caller ID service, the calling party's information will be shown on the cordless handset and the base unit after the first ring.

The unit can record information of up to 50 different callers, including the time and date received and the number of times called, in the Caller List. The Caller List information is sorted by the most recent call to the oldest. When the 51st call is received, the first call is deleted.

Using the list, you can automatically call back a caller. You can store the callers' names and numbers from the Caller List into the directory.


If you subscribe to both Caller ID and Call Waiting services, when a second call is received while talking, the new caller's name and phone number will be displayed (p. 57).

## How caller information is displayed when a call is received

The displays show the caller's name and number after the first ring.

- After you answer the call with the base unit or cordless handset, its display will show the length of the call.

ROBINSON, TINA  
1-000-222-3333



- Caller information cannot be displayed in the following cases:
  - If the caller dialed from an area which does not provide a Caller ID service, the display will show "Out of area".
  - If the caller has requested not to display his/her information, the display will show "Private caller".
  - If a long distance call is identified, and the caller's name and/or number cannot be received, the display will show "Long distance".
- If your unit is connected to a PBX which does not support Caller ID services, you cannot access those services.
- The name display service may not be available in some areas. For further information, please contact your telephone company.

# Using the Caller List

## Viewing the Caller List

You can view the caller list with the cordless handset or the base unit. Caller List information includes the caller's name and phone number, the time and date the call was received, and the number of times that caller called (p. 31).

**Make sure the base unit and cordless handset are not being used.**

### Cordless Handset

1 Press  or  to enter the Caller List.

- The display will show, for example, the following.

```
5 new calls
▼▲ ▶=Directory
```

- You can go to the directory list by pressing  (p. 42).

2 To search from the most recent call, press .  
To search from the oldest call, press .

- To scroll between callers, press  or .

```
SMITH, JACK
1-222-333-4444
3:10P JUN.10
```

3 To exit the list, press **OFF**.

### Base Unit

1 Press  or  to enter the Caller List.

- The display will show, for example, the following.

```
5 new calls
▼▲ ▶=Directory
```

- You can go to the directory list by pressing  (p. 42).

2 To search from the most recent call, press .  
To search from the oldest call, press .

- To scroll between callers, press  or .

```
SMITH, JACK
1-222-333-4444
3:10P JUN.10
```

3 To exit the list, press **EXIT**.

- If "No items stored" is displayed, the Caller List is empty.
- If there is no name information for a caller, the display will only show the phone number.
- Once new calls have been checked, "√" will be added.
- While you are viewing the Caller List with the cordless handset, another person cannot access the list using the base unit, and vice versa.



## What “√” means

When the display shows “√”, you have already viewed this calling information, answered the call or called back the caller. If the same caller calls again, the call entry with “√” will be replaced with the new call entry.

SMITH, JACK  
1-222-333-4444  
3:10P JUN.10 √

## If a caller calls more than once

The number of times the same caller called is displayed (“×2” to “×9”). The time and date of the most recent call will be recorded. After checking, “×2” to “×9” will be replaced with “√”.

TURNER, CINDY  
1-234-456-7890  
11:20A JUN.12 ×2

## Calling Back from the Caller List

### Cordless Handset

- 1 Press or to enter the Caller List.

3 new calls  
▼▲ ▶=Directory

- 2 Scroll to the desired caller by pressing or .

TURNER, CINDY  
1-234-456-7890  
11:20A JUN.12 ×2

- 3 Press .  
•The displayed phone number is dialed automatically.

Talk  
12344567890

### Base Unit

- 1 Press or to enter the Caller List.

3 new calls  
▼▲ ▶=Directory

- 2 Scroll to the desired caller by pressing or .

TURNER, CINDY  
1-234-456-7890  
11:20A JUN.12 ×2

- 3 Press **DIGITAL SP-PHONE** or lift the handset.  
•The displayed phone number is dialed automatically.

Talk  
12344567890

- In some cases, you may have to edit the number before dialing (p. 32, 33). (Ex. You may have to delete “1” and the area code.)
- If a phone number is not displayed in the caller information, you cannot call back that caller.

## ► Using the Caller List

### Editing the Caller's Phone Number

You can edit a phone number into one of 3 patterns to call back or store it into the directory.

#### The Caller ID Number Auto Edit Feature (p. 34)

This feature will allow the unit to edit a Caller ID number into one of 3 patterns you desired for you automatically in the Caller List. For detail and activation, please see page 34.

**Make sure the base unit and cordless handset are not being used.**

#### Cordless Handset

1 Press  or  to enter the Caller List.

```
5 new calls
▼▲ ▶=Directory
```

2 Scroll to the desired caller by pressing  or , and press .

```
PARKER, FRED
1-234-321-5555
11:20A JAN.12 ✓
```

```
▶Edit
Save directory
▼▲ ▶=Yes
```

3 Press  (Yes key) at "Edit".

```
PARKER, FRED
1-234-321-5555
▼=Next ▶=Edit
```

4 Press  (Edit key) to select a pattern.

- Each time you press  (Edit key), the number is rearranged into one of 3 patterns.

(a) 

(b) 

(c) 1-

- The order in which patterns (a)–(c) are displayed depends on how the telephone number is displayed in step 3.

(a) 

```
321-5555
▼=Next ▶=Edit
```

(b) 

```
234-321-5555
▼=Next ▶=Edit
```

(c) 

```
1-234-321-5555
▼=Next ▶=Edit
```

5 After editing the number, you can continue with calling back or storing procedures.

To call back, press  (p. 31).

To store the number in the directory, press  (Next key). Follow the instructions on the display (p. 36). (If the caller has no name information, see page 36, from step 3.)



## Base Unit

1 Press or to enter the Caller List.

5 new calls  
▼▲ ▶=Directory


2 Scroll to the desired caller by pressing or , and press **FUNCTION/EDIT**.

PARKER, FRED  
1-234-321-5555  
11:20A JAN.12 ✓

3 Press **FUNCTION/EDIT** to select a pattern.

- Each time you press **FUNCTION/EDIT**, the number is rearranged into one of 3 patterns.

- (a) 
  - The order in which patterns (a)–(c) are displayed depends on how the telephone number is displayed in step 2.



4 After editing the number, you can continue with calling back. Press **DIGITAL SP-PHONE** or lift the handset (p. 31).

# The Caller ID Number Auto Edit Feature

### Cordless Handset

There are 3 patterns of phone number (Ⓐ, Ⓑ, and Ⓒ, p. 32, 33). This feature allows your phone to automatically edit an in-coming Caller ID number into one pattern you preferred, and display the Caller ID number with that pattern on the base unit and cordless handset automatically.

After this feature is activated, Caller ID numbers coming from considered area codes (201, for example), from which the Caller ID numbers have been chosen to follow the desired pattern (7 digit pattern, for example), will be automatically edited from other patterns (11 digit pattern, for example) into the same pattern you have previously selected (which is 7 digit pattern, in the example).

Up to 4 area codes are allowed for this feature for pattern Ⓐ and Ⓑ (p. 32, 33). The Caller ID numbers can be edited automatically on the base unit and the cordless handset separately. Changes made on the cordless handset cannot be used to make a call with the base unit and vice versa.

To activate this feature, you must 1) set this feature to on, and 2) make an out-going call from Caller List (p. 31) with a number which has one of 3 patterns that you have edited with considered area code, and that you prefer to be followed by future Caller ID numbers, so that in the future all the Caller ID numbers coming from the same area code will be displayed in the same pattern.

The Caller ID number Auto Edit feature is preset to ON at factory.

- If you fail to reach your destination when making the call, the phone number you dialed might have an incorrect pattern, please edit the phone number with another pattern (p. 32, 33).

For example, if you move to another area, you may need to turn this feature to OFF to erase previously edited area codes. Then, if still need, you may activate this feature again.

**Make sure the base unit and cordless handset are not being used.**

1 Press **MUTE/FUNCTION**.

► Save directory
Ringer volume
▼▲
►=Yes

2 Scroll to "Program" by pressing ▼ or ▲.

LCD contrast
► Program
▼▲
►=Yes

3 Press ► (Yes key).

► Set flash time
Set line mode
▼▲
►=Yes



4 Scroll to “Caller ID edit” by pressing or .

```
▶Caller ID edit
▼▲ ▶=Yes
```

5 Press (Yes key).

```
Auto edit
:On
▼▲ ▶=Save
```

6 Select “On” or “Off” by pressing or .

```
Auto edit
:Off
▼▲ ▶=Save
```

7 Press (Save key).

- A beep sounds.
- To exit the programming mode, press **OFF**.

```
Auto edit
:Off
```

- When the feature is set to OFF, the unit will still be able to display Caller ID, like regular Caller ID telephone, but the in-coming Caller ID number will not be edited by pattern and by area codes.

## ► Using the Caller List

# Storing Caller List Information in the Directory

**Cordless Handset**

You can store phone numbers that are in the Caller List into the directory.

**Storing must be carried out with the cordless handset.**

**Make sure the base unit and cordless handset are not being used.**

1 Press  or  to enter the Caller List.

10 new calls  
▼▲ ▶=Directory

2 Scroll to the caller you want to store in the directory by pressing  or , and press .

TURNER, CINDY  
1-234-456-7890  
11:20A JUN.12 ×3

• If the number requires editing, see page 32.

▶Edit  
Save directory  
▼▲ ▶=Yes

3 Scroll to “Save directory” by pressing  or , and press  (Yes key).

Edit  
▶Save directory  
▼▲ ▶=Yes

**If there is no name information for the caller, “Enter name” will be displayed.**

a) If a name is not required, press  (Next key) and  (Save key).

  
Enter name  
■  
◀▶ ▼=Next

b) If a name is required, enter the name (p. 41). When finished, press  (Next key) and  (Save key).

  
Enter name  
CINDY TURNER  
◀▶ ▼=Next

• A beep sounds.

• To continue storing other items, repeat from step 2.

• To exit the programming mode, press **OFF**.

  
CINDY TURNER  
1-234-456-7890  
▲=Edit ▶=Save

- You can exit the programming mode any time by pressing **OFF**.
- If the display shows “Directory full” in step 3, press **OFF** to exit the list. To erase other stored items from the directory, see page 46.
- After the maximum of 50 items has been stored, “Directory full” is also displayed.
- You cannot store caller information in the directory if a phone number is not displayed.
- If 3 beeps sound and display shows “Save error” in step 3, move closer to the base unit and start again from step 2.



# Erasing Caller List Information

After checking the Caller List, you can erase some or all of the entries with the cordless handset or base unit.

**Make sure the base unit and cordless handset are not being used.**

## To erase a specific caller from the Caller List

### Cordless Handset

- 1 Press or to enter the Caller List.

```
10 new calls
▼▲ ▶=Directory
```

- 2 Scroll to the caller you want to erase from the Caller List by pressing or .

```
REAGAN, TOM
1-888-777-6666
12:20A JAN.12 ✓
```

- 3 Press **CLEAR/INTERCOM/HOLD**.

```
Clear
```

- A beep sounds and the information is erased.
- To erase other items, repeat from step 2.
- To exit the Caller List, press **OFF**.

### Base Unit

- 1 Press or to enter the Caller List.

```
10 new calls
▼▲ ▶=Directory
```

- 2 Scroll to the caller you want to erase from the Caller List by pressing or .

```
REAGAN, TOM
1-888-777-6666
12:20A JAN.12 ✓
```

- 3 Press **CLEAR**.

```
Clear
```

- A beep sounds and the information is erased.
- To erase other items, repeat from step 2.
- To exit the Caller List, press **EXIT**.

# ► Using the Caller List

## To erase all entries in the Caller List

Before erasing all entries, make sure that “0 new call” is displayed.

### Cordless Handset

- 1 Press  or  to enter the Caller List.

```
0 new call
▼▲ ▶=Directory
```

- 2 Press **CLEAR/INTERCOM/HOLD**.

```
▶Exit
All clear
▼▲ ▶=Yes
```

- 3 Scroll to “All clear” by pressing  or .

```
Exit
▶All clear
▼▲ ▶=Yes
```

- 4 Press  (Yes key) or **CLEAR/INTERCOM/HOLD**.

```
All clear
```

- A beep sounds and all entries are erased.
- The cordless handset will exit the Caller List.

### Base Unit

- 1 Press  or  to enter the Caller List.

```
0 new call
▼▲ ▶=Directory
```

- 2 Press **CLEAR**.

```
▶Exit
All clear
▼▲ ▶=Yes
```

- 3 Scroll to “All clear” by pressing  or .

```
Exit
▶All clear
▼▲ ▶=Yes
```

- 4 Press  (Yes key) or **CLEAR**.

```
All clear
```

- A beep sounds and all entries are erased.
- The base unit will exit the Caller List.

# Directory




You can store up to 50 names and phone numbers in the directory using the cordless handset. All directory items are sorted by the first word in alphabetical order.

Using the directory, you can make a call by selecting a name on the display of the cordless handset or base unit.

## Storing Names and Numbers Cordless Handset

Storing must be carried out with the cordless handset.

Make sure the base unit and cordless handset are not being used.



Advanced Operation

1 Press **MUTE/FUNCTION**.

▶ Save directory  
Ringer volume  
▼▲ ▶=Yes

2 Press **▶** (Yes key) at "Save directory".  
• The display shows the number of stored items in the directory.


  
Directory=  
20 items

(Continued →)


## ► Directory

**3** Enter a name, up to 15 characters, with the dialing buttons, ◀ or ▶.

- See the steps for entering names and symbols (p. 41).
- If a name is not required, press ▼ (Next key) and go to step 5.




Enter name  
◀ ▶ ▼=Next



Enter name  
Tom Jones  
◀ ▶ ▼=Next

**4** Press ▼ (Next key).



Enter phone no.

**5** Enter a phone number, up to 22 digits.


- Each time you press **CLEAR/INTERCOM/HOLD**, a digit is erased. To erase all of the digits, press and hold **CLEAR/INTERCOM/HOLD**.
- To move the cursor, press ◀ or ▶.



0987654321  
◀ ▶ ▼=Next

**6** Press ▼ (Next key).

- If you want to change the storing name or number, press ▲ (Edit key) repeatedly to reach the desired display and change it.



Tom Jones  
098-765-4321  
▲=Edit ▶=Save

**7** Press ▶ (Save key).

- A beep sounds.
- To continue storing other items, repeat from step 2.
- To exit the programming mode, press **OFF**.



Tom Jones  
098-765-4321

- If a pause is required for dialing, **REDIAL/PAUSE** can be stored in a phone number counting as one digit (p. 57) in step 5.
- You can exit the programming mode any time by pressing **OFF**.
- If the display shows "Directory full" in step 2, the display will return to step 1. Press **OFF** to exit the list. To erase other stored items from the directory, see page 46.
- After the maximum of 50 items has been stored, "Directory full" is also displayed.
- If an alarm tone sounds in step 7, the item cannot be stored in the directory. Press **OFF** and try again from step 1.



# Entering Names and Symbols Cordless Handset

The cordless handset dialing buttons (0 to 9) can be used to enter letters and symbols. The letters are printed on the dialing buttons. Pressing each button selects a character as shown below.



Keys	Number of times key is pressed										
	1	2	3	4	5	6	7	8	9	10	11
1	#	&	'	(	)	*	,	-	.	/	1
2	a	b	c	A	B	C	2				
3	d	e	f	D	E	F	3				
4	g	h	i	G	H	I	4				
5	j	k	l	J	K	L	5				
6	m	n	o	M	N	O	6				
7	p	q	r	s	P	Q	R	S	7		
8	t	u	v	T	U	V	8				
9	w	x	y	z	W	X	Y	Z	9		
0	0	Blank									
◀	To move the cursor to the left.										
▶	To move the cursor to the right.										

Advanced Operation

- To enter another character using the same dialing button, press ▶ to move the cursor to the next space.

## If you make a mistake while entering a name

Use ◀ or ▶ to move the cursor to the incorrect character, press **CLEAR/INTERCOM/HOLD** to delete and enter the correct character. Each time you press **CLEAR/INTERCOM/HOLD**, a character is erased. To erase all characters, press and hold **CLEAR/INTERCOM/HOLD**.

## ► Directory

For example, to enter “Tom Jones”:


- |   |  |           |
|---|--|-----------|
| 1 | Press <b>8</b> four times.   | T         |
| 2 | Press <b>6</b> three times, then press <b>▶</b> .                            | To        |
| 3 | Press <b>6</b> once, then press <b>▶</b> twice.                              | Tom       |
| 4 | Press <b>5</b> four times, press <b>6</b> three times, then press <b>▶</b> . | Tom Jo    |
| 5 | Press <b>6</b> twice, press <b>3</b> twice, then press <b>7</b> four times.  | Tom Jones |

## Finding Stored Items Cordless Handset Base Unit

You can search the directory using the cordless handset or the base unit. “



**Make sure the base unit and cordless handset are not being used.**

- 1 Press **◀** or **▶** to enter the directory list.



- You can go to the Caller List by pressing **▶** (p. 30).

- 2 Press **▼** or **▲**.
- The first item is displayed.





**3** Scroll to the desired item by pressing or .


- All directory items are stored in the order shown on the right.

**To search for a name by initial**

① Press the dialing button for the first letter of the desired name until any name with the same initial is displayed (see the Index table below).

Ex. To find “Frank”, press **3** repeatedly until the first item under “F” is displayed.

② Press repeatedly until the name is displayed.



- You can exit the directory list any time by pressing **OFF** or **EXIT**.
- If “No items stored” is displayed in step 2, the directory is empty.

**Index table**

Keys	Index	Keys	Index
<b>1</b>	Other symbols, 1	<b>6</b>	M, N, O, 6
<b>2</b>	A, B, C, 2	<b>7</b>	P, Q, R, S, 7
<b>3</b>	D, E, F, 3	<b>8</b>	T, U, V, 8
<b>4</b>	G, H, I, 4	<b>9</b>	W, X, Y, Z, 9
<b>5</b>	J, K, L, 5	<b>0</b>	0


## ► Directory

### Dialing **Cordless Handset** **Base Unit**


“” is displayed only on the cordless handset display.

**Make sure the base unit and cordless handset are not being used.**


- 1 Press  or  to enter the directory list.




- 2 Press  or .
- The first item is displayed.



- 3 Scroll to the desired item that you want to dial by pressing  or .
- To search for the item by initial, see page 43.



- 4 **Cordless handset:**  
Press .
- Base unit:**  
Press **DIGITAL SP-PHONE**, or lift the handset.
- The number is dialed automatically.



- 5 To hang up,
- Cordless handset:**  
Press **OFF** or place the cordless handset on the charger.
- Base unit:**  
Press **DIGITAL SP-PHONE**, or place the handset on the cradle.


- You can exit the directory list any time as follows:  
When using the cordless handset, press **OFF**.  
When using the base unit, press **EXIT**.




# Editing **Cordless Handset**

Make sure the base unit and cordless handset are not being used.

1 Press or to enter the directory list.




2 Press or .  
•The first item is displayed.




3 Scroll to the directory item you want to change by pressing or , and press .


- To search for the item by initial, see page 43.
- If you do not need to change the name, go to step 5.



4 Edit the name using the dialing buttons, or (p. 41), up to 15 characters.




5 Press (Next key).



6 Add a number to the current number.

- If you do not need to change the number, press (Next key) and go to step 8.
- Each time you press **CLEAR/INTERCOM/HOLD**, a digit is erased. To erase all of the digits, press and hold **CLEAR/INTERCOM/HOLD**.
- To move the cursor, press or .



(Continued →)

## ► Directory

- 7 Press (Next key).
- If you want to change the storing name or number, press (Edit key) repeatedly to reach the desired display and change it.

Jane Walker  
1-234-456-7890  
▲=Edit ▶=Save

- 8 When finished, press (Save key).
- A beep sounds.
  - To continue editing other items, repeat from step 3.
  - To exit the directory list, press **OFF**.

Jane Walker  
1-234-456-7890

- You can exit the edit mode any time by pressing **OFF**.

## Erasing **Cordless Handset** **Base Unit**

“” is displayed only on the cordless handset display.

**Make sure the base unit and cordless handset are not being used.**

- 1 Press or to enter the directory list.

Directory list  
▼▲  
▶=Caller's list

- 2 Press or .
- The first item is displayed.

Ann  
123-456-7890

- 3 Scroll to the directory item that you want to erase by pressing or .
- To search for the item by initial, see page 43.

Helen  
1-234-567-8901

- 4 **Cordless handset:**  
Press **CLEAR/INTERCOM/HOLD**.

**Base unit:**

Press **CLEAR**.

- To stop erasing, press (No key).

Clear?  
◀=No ▶=Yes

- 5 **Cordless handset:**  
Press (Yes key) or **CLEAR/INTERCOM/HOLD**.

**Base unit:**

Press (Yes key) or **CLEAR**.

- A beep sounds.


Clear

- You can exit the directory list any time as follows:  
When using the cordless handset, press **OFF**.  
When using the base unit, press **EXIT**.



## Storing Phone Numbers in Memory **Base Unit**

You can store up to 3 phone numbers in the DIRECT buttons.  
**Make sure the base unit and cordless handset are not being used.**



1 Press **FUNCTION/EDIT**.

```
►Date and time
Save DIRECT#
▼▲                               ►=Yes
```

2 Scroll to "Save DIRECT#" by pressing ▼ or ▲.

```
Date and time
►Save DIRECT#
▼▲                               ►=Yes
```

3 Press ► (Yes key).

```
Select DIRECT#
:Direct1
▼▲                               ►=Yes
```

4 Scroll to the desired direct button by pressing ▼ or ▲.  
•You can select the desired direct button by pressing dialing buttons **1** (DIRECT1), **2** (DIRECT2) or **3** (DIRECT3).

```
Select DIRECT#
:Direct2
▼▲                               ►=Yes
```

(Continued ➔)

## ► One-Touch Dialer

5 Press ► (Yes key).



6 Enter a phone number, up to 22 digits.

- Each time you press **CLEAR**, a digit is erased. To erase all of the digits, press and hold **CLEAR**.
- To move the cursor, press ◀ or ▶.




7 Press ▼ (Next key).



8 Press ► (Save key).

- A beep sounds.
- To store other numbers, repeat from step 4.
- To exit the programming mode, press **EXIT**.



- If a pause is required for dialing, **PAUSE** can be stored in a phone number counting as one digit (p. 57) in step 6.
- You can exit the programming mode any time by pressing **EXIT**.

### To erase a stored number

Repeat steps 1 through 5 → press and hold **CLEAR** until all of the digits are erased → ▼ (Next key) → ► (Save key).

## Dialing **Base Unit**

1 Press the required DIRECT button (**DIRECT1**), (**DIRECT2**) or (**DIRECT3**).

- If 3 beeps sound, you have not stored the phone numbers in the DIRECT buttons. Store the number.
- The DIGITAL SP-PHONE indicator lights.
- The stored number is dialed.

- Numbers stored in the base unit can only be dialed by the base unit.
- You can also dial the stored number by pressing **DIGITAL SP-PHONE** or lifting the handset then pressing the DIRECT button.



## Cordless Handset    Base Unit

A 2-way intercom is possible between the cordless handset and the base unit.

### Paging the base unit from the cordless handset

#### 1 Cordless handset:

Press **CLEAR/INTERCOM/HOLD**.

Talk to the paged party after the beeps.

- “Intercom” is displayed.

#### 2 Base unit:

When the other party’s voice is heard, lift the handset or talk into the **MIC**.

#### 3 To end the intercom, press **OFF** on the cordless handset.

OR

When using the handset, place the handset on the cradle.

When using the speakerphone, press **LOCATOR/INTERCOM**.



### Paging the cordless handset from the base unit (Handset locator)

Using this feature, you can locate a misplaced cordless handset.

#### 1 Base unit:

Lift the handset and press **LOCATOR/INTERCOM** within 5 seconds.

- The cordless handset beeps for 1 minute and displays “Paging Press INTERCOM”.
- To stop paging, place the handset on the cradle.

#### 2 Cordless handset:

Press **CLEAR/INTERCOM/HOLD** to answer.

- “Intercom” is displayed.

#### 3 Base unit:

Talk into the handset.

#### 4 To end the intercom, press **OFF** on the cordless handset.

OR

Place the handset on the cradle.

- In step 1, the base unit user can also page by pressing **LOCATOR/INTERCOM** directly. You do not need to lift the handset.

—If the cordless handset user does not answer, press **LOCATOR/INTERCOM** to stop paging.

—If the cordless handset user answers, talk into the **MIC**.

To end the intercom from the base unit, press **LOCATOR/INTERCOM**.

### During an intercom call:

- If the cordless handset user has difficulty hearing the base unit user, decrease the base unit speaker volume by pressing .
- If an incoming call is received, the intercom call stops and the unit starts to ring. To answer, press , **DIGITAL SP-PHONE** or place the handset and lift it again. The intercom is ended.

## Transferring a Call Using the Intercom

**Cordless Handset**   **Base Unit**

The intercom can be used during a call. This feature enables you to transfer a call between the cordless handset and the base unit.

### From the cordless handset to the base unit

**1 Cordless handset:**  
During a call, press **CLEAR/INTERCOM/HOLD**.

- The call is put on hold and “Line on HOLD.”  
To transfer press INTERCOM.” is displayed.

**2** Press **CLEAR/INTERCOM/HOLD** again. Talk to the paged party after the beeps.

```
Line on HOLD.  
▶=Conference  
Intercom {■■■■}
```

- If the base unit user does not answer, press  to return to a call.

**3 Base unit:**  
When the other party's voice is heard, lift the handset or talk into the **MIC**.

**4** To complete the transfer:  
—when using the handset, press **OFF** on the cordless handset.  
—when using the speakerphone, press **DIGITAL SP-PHONE**.

### From the base unit to the cordless handset

**1 Base unit:**  
During a call, press **LOCATOR/INTERCOM**.

- The call is put on hold and DIGITAL SP-PHONE indicator flashes.
- If the cordless handset user does not answer:  
—when using the handset, press **LOCATOR/INTERCOM**, then press **HOLD** to return to a call.  
—when using the speakerphone, press **DIGITAL SP-PHONE** to return to a call.

**2 Cordless handset:**  
Press **CLEAR/INTERCOM/HOLD** to answer the page.

```
Line on HOLD.  
▶=Conference  
Intercom {■■■■}
```

**3** To complete the transfer:  
—when using the handset, place the handset on the cradle.  
—when using the speakerphone, press  on the cordless handset.

# Conference

While you are talking with an outside caller, you can call the base unit or cordless handset to make a conference call.

## Cordless Handset

**1 Cordless handset:**  
During a call, press **CLEAR/INTERCOM/HOLD**.

- The call is put on hold and “Line on HOLD.  
To transfer press INTERCOM.” is displayed.

**2** Press **CLEAR/INTERCOM/HOLD** again. Talk to the paged party after the beeps.

```
Line on HOLD.  
▶=Conference  
Intercom [||||]
```

- If the base unit user does not answer, press  to return to a call.

**3 Base unit:**  
When the other party's voice is heard, lift the handset or talk into the **MIC**.

**4** Press  (Conference key) to make a conference call on the cordless handset or the base unit.

## Base Unit

**1 Base unit:**  
During a call, press **LOCATOR/INTERCOM**.

- The call is put on hold and DIGITAL SP-PHONE indicator flashes.

- If the cordless handset user does not answer:
  - when using the handset, press **LOCATOR/INTERCOM**, then press **HOLD** to return to a call.
  - when using the speakerphone, press **DIGITAL SP-PHONE** to return to a call.

**2 Cordless handset:**  
Press **CLEAR/INTERCOM/HOLD** to answer the page.

```
Line on HOLD.  
▶=Conference  
Intercom
```

**3** Press  (Conference key) to make a conference call on the cordless handset or the base unit.

- During a conference, the outside call can be placed on hold by pressing **CLEAR/INTERCOM/HOLD** on the cordless handset or **HOLD** on the base unit. Internal communications between extensions are not suspended. To resume the conference, press  (Conference key) on the cordless handset or the base unit.

- To leave the conference,
  - For the cordless handset; press **OFF** or place the cordless handset on the charger.
  - For the base unit;

When talking with the speakerphone, press **DIGITAL SP-PHONE**.

When talking with the handset, place the handset on the cradle.

The two other parties can continue the conversation.

# Voice Mail Service


Voice mail service is an electronic on-line answering system offered by your telephone company. After subscribing, the voice mail system can answer calls automatically for you when your line is busy or if calls are not answered, and caller can leave their messages at the voice mail box virtually located at the telephone company. After the voice mail box having received messages, the unit will indicate it in two ways: (a) "Voice mail" and "☑" will display, and (b) the VM (Voice mail) indicator on the base unit will flash.

To use this feature, you must first store your access number.

## Storing a Voice Mail Access Number

### Cordless Handset

Make sure the base unit and cordless handset are not being used.



1 Press **MUTE/FUNCTION**.

▶Save directory	
Ringer volume	
▼▲	▶=Yes

2 Scroll to "Program" by pressing ▼ or ▲.

LCD contrast	
▶Program	
▼▲	▶=Yes



3 Press **▶** (Yes key).

▶Set flash time  
Set line mode  
▼▲ ▶=Yes

4 Scroll to "Save VM access#" by pressing **▼** or **▲**.

▶Save VM access#  
VM tone detect  
▼▲ ▶=Yes

5 Press **▶** (Yes key).

■  
◀▶ ▼=Next

6 Enter your access number, up to 32 digits.

- You may enter pauses\* (see below).
- Each time you press **CLEAR/INTERCOM/HOLD**, a digit is erased. To erase all of the digits, press and hold **CLEAR/INTERCOM/HOLD**.
- To move the cursor, press **◀** or **▶**.

1234567PPP8901  
◀▶ ▼=Next

7 Press **▼** (Next key).

- If you want to edit the entered number, press **▲** (Edit key) and return to step 6.

1234567PPP8901  
▲=Edit ▶=Save

8 Press **▶** (Save key).

- A beep sounds.
- To exit the programming mode, press **OFF**.

1234567PPP8901  
Save VM access#

- You can exit the programming mode any time by pressing **OFF**.

\*For quick access to your voice mail box by using

**FLASH/CALL WAIT/VOICE MAIL** or **VM**, you may add pauses between your voice mail box access number and your mail box password in step 6.

Ex. 1-222-333-4444 PPP 8888

Your voice mail box access number | Pauses | Your mail box password

Pressing **REDIAL/PAUSE** once creates a 3.5 second delay and counts as one digit. The delay time depends on a telephone company.

## To erase a stored number

Repeat steps 1 through 5 → press and hold **CLEAR/INTERCOM/HOLD** until all of the digits are erased → **▼** (Next key) → **▶** (Save key).

- A beep sounds.

## ▶ Voice Mail Service

# Setting the Voice Mail (VM) Tone Detection

### Cordless Handset

Your telephone company sends special signals (Voice mail tones) to activate the VM indicator.

Press  or **DIGITAL SP-PHONE** to listen to the dial tone. If you hear a series of dial tones followed by a continuous dial tone, this is indication that a new message was recorded.

Your phone comes set to detect these tones (set to “On”). Minutes after you hang up or after the phone stops ringing, your unit will seize the phone line and check if a message has been recorded. If a new message was recorded at your telephone company, “Voice mail” and “” will be displayed and the base unit VM (Voice mail) indicator will flash.

Set this programming to “Off” when:

- you do not subscribe to a voice mail service,
  - your telephone company does not send a series of tones, followed by a continuous tone, or
  - your phone is connected to a business or office telephone system (PBX).
- Please refer to below to set this programming to OFF.

If you are not sure which setting is required, consult your local telephone company or contact Panasonic Customer Call Center.

**Make sure the base unit and cordless handset are not being used.**

- 1 Press **MUTE/FUNCTION**, scroll to “Program” by pressing  or , and press  (Yes key).
- 2 Scroll to “VM tone detect” by pressing  or .
- 3 Press  (Yes key).
  - The current setting is displayed.
- 4 Select “On” or “Off” by pressing  or .
- 5 Press  (Save key).
  - A beep sounds.
  - To exit the programming mode, press **OFF**.

```
LCD contrast
▶Program
▼▲                               ▶=Yes
```

```
Save VM access#
▶VM tone detect
▼▲                               ▶=Yes
```

```
VM tone detect
:On
▼▲                               ▶=Save
```

```
VM tone detect
:Off
▼▲                               ▶=Save
```

```
VM tone detect
:Off
```

- You can exit the programming mode any time by pressing **OFF**.

# Listening to Voice Mail Messages

After the voice mail box having received messages, the unit will indicate it in two ways: (a) "Voice mail" and "☑" will display, and (b) the VM (Voice mail) indicator on the base unit will flash. To listen to your voice mail message(s), follow the steps below.

## Cordless Handset

1 Press **FLASH/CALL WAIT/VOICE MAIL**.

- The stored voice mail access number is displayed (p. 52, 53).

1234567PPP8901

2 Press .

- The cordless handset automatically dials the access number.

Talk  
1234567PPP8901

3 Follow the pre-recorded instructions.

4 When finished, press **OFF**.

## Base Unit

1 Press **VM**.


- The base unit is connected to the telephone line and automatically dials the access number.
- If 3 beeps sound, you have not stored the voice mail access number. Store the number (p. 52, 53).

2 Follow the pre-recorded instructions.

3 When finished, press **DIGITAL SP-PHONE**.

- If "Voice mail" and "☑" still remain on the display, the VM (Voice mail) indicator on the base unit still flashes even if you have listened to your voice mail message(s), press **MUTE/FUNCTION**, and press and hold **CLEAR/INTERCOM/HOLD** until the unit beeps. "Voice mail" and "☑" will disappear and the VM (Voice mail) indicator will turn off.
- If your voice mail service uses a voice mail tone and the recorded message is over 3 minutes long, "Voice mail" and "☑" may not be displayed, the VM (Voice mail) indicator may not flash.
- If your voice mail service uses a voice mail tone, the tone will be heard from any parallel connected phone. If you use another phone to retrieve messages, you have to dial your access number manually.

# Special Features



## Temporary Tone Dialing (For Rotary or Pulse Service Users)

**Cordless Handset**   **Base Unit**

Press **TONE** before entering access numbers which require tone dialing.

- The dialing mode changes to tone. You can enter numbers to access an answering service, electronic banking service, etc. When you hang up, the mode will return to pulse.

## Muting Your Conversation

**Cordless Handset**   **Base Unit**

### Cordless handset:

Press **MUTE/FUNCTION** while talking.

- “<MUTE>” flashes.

### Base unit:

Press **MUTE** while talking.

- “<MUTE>” flashes.
- The other party cannot hear your voice but you can hear theirs.
- **To release the mute**, press **MUTE/FUNCTION** on the cordless handset or **MUTE** on the base unit.



# For Call Waiting Service Users

**Cordless Handset**

**Base Unit**

Press **FLASH/CALL WAIT/VOICE MAIL** or **FLASH/CALL WAIT** if you hear a call-waiting tone while talking.

- The first call is put on hold and you can answer the second call.
- To return to the first caller, press **FLASH/CALL WAIT/VOICE MAIL** or **FLASH/CALL WAIT** again.
- The call waiting service cannot be used when a parallel connected telephone is in use.
- If this function does not operate properly, consult your telephone company for details.

## Call Waiting Caller ID Feature

Call Waiting Caller ID Feature allows the unit to display the second caller's information. After you hear a call-waiting tone while talking, the unit will display the caller's name with the phone number and "----Waiting----".

BROWN, NANCY
555-666-7777
----Waiting----

- Please contact your telephone company for details and availability in your area.

## How to Use the PAUSE Button (For PBX Line/Long Distance Calls)

**Cordless Handset**

**Base Unit**

We recommend you press **REDIAL/PAUSE** or **PAUSE** if a pause is required for dialing with a PBX or to make a long distance call.

Ex. Line access number **9** (PBX)

**9** → **REDIAL/PAUSE** or **PAUSE** → Phone number

- Pressing **REDIAL/PAUSE** or **PAUSE** once creates a 3.5 second pause. This prevents misdialing when you redial or dial a stored number.
- Pressing **REDIAL/PAUSE** or **PAUSE** more than once increases the length of the pause between numbers.

## ► Special Features

### FLASH Button Cordless Handset Base Unit

Pressing **FLASH/CALL WAIT/VOICE MAIL** or **FLASH/CALL WAIT** allows you to use special features of your host PBX such as transferring an extension call or accessing special telephone services (optional) such as call waiting.

- Pressing **FLASH/CALL WAIT/VOICE MAIL** or **FLASH/CALL WAIT** causes to release following operations:
  - temporary tone dialing,
  - muting your conversation.

### Selecting the flash time Cordless Handset

The flash time depends on your telephone exchange or host PBX. You can select the following flash times: “700, 600, 400, 300, 250, 110, 100 or 90 ms (milliseconds)”. Your phone comes from the factory set to “700 ms”.

**Make sure the base unit and cordless handset are not being used.**

- 1 Press **MUTE/FUNCTION**.

```
►Save directory
  Ringer volume
▼▲                ►=Yes
```

- 2 Scroll to “Program” by pressing ▼ or ▲.

```
  LCD contrast
►Program
▼▲                ►=Yes
```

- 3 Press ► (Yes key).

```
►Set flash time
  Set line mode
▼▲                ►=Yes
```

- 4 Press ► (Yes key) at “Set flash time”.  
• The current setting is displayed.

```
Flash time
                               :700ms
▼▲                ►=Save
```

- 5 Select the desired time by pressing ▼ or ▲.

```
Flash time
                               :110ms
▼▲                ►=Save
```

- 6 Press ► (Save key).  
• A beep sounds.  
• To exit the programming mode, press **OFF**.

```
Flash time
                               :110ms
```

- You can exit the programming mode any time by pressing **OFF**.
- If the unit is connected via a PBX, PBX functions (transferring a call etc.) might not work correctly. Consult your PBX supplier for the correct setting.

# Security Code Setting Cordless Handset & Base Unit

If “No link to base. Walk closer to base & try again” is displayed even if you use the cordless handset near the base unit, the cordless handset may lose communication with the base unit. It is necessary to set the same security code between the base unit and cordless handset. Follow the steps below.

**1 Base unit:**  
Press **[FUNCTION/EDIT]**.

▶Date and time  
Save DIRECT#  
▼▲ ▶=Yes

**2** Press **[7]**, **[3]**, then **[4]**.  
•No sound is present each time you press the dialing button. Confirm that the display on the right will be shown after pressing the buttons.

Portable  
Registering

**3 Cordless handset:**  
Press **[MUTE/FUNCTION]**.

▶Save directory  
Ringer volume  
▼▲ ▶=Yes

**4** Press **[7]**, **[3]**, then **[4]**.  
•No sound is present each time you press the dialing button. Confirm that the display on the right will be shown after pressing the buttons.  
•After the setting is completed, “Portable Registered” is displayed and a beep sounds from the base unit and cordless handset.

Portable  
Registering


•3 beeps sound and “Error!!” is displayed when you fail to set the security code. Try again from step 1.

# Wall Mounting


## Base unit

The base unit can be mounted on a wall phone plate.

- 1 Pull down the handset hook until it locks, **so the tab holds the handset.**




- 2 Press the tabs in the direction of the arrows (①), then remove the wall mounting adaptor (②).



- 3 Connect the AC adaptor. Tuck the telephone line cord inside the wall mounting adaptor, then push it in the direction of the arrow (① and ②).


- The word "UP WALL" should face upward.



Wall Template for the Charger Unit



2.4 cm

(15/16")



- 4** Connect the telephone line cord.  
Mount the base unit, then slide down.



- Raise the antennas.



To temporarily set the handset down during a conversation, place it as shown here.

## Charger unit

The charger can be wall mounted. Connect the AC adaptor. Install screws using the wall template (p. 60). Mount the charger (①). Slide it down (②), then slide down to the right (③) until it is secured.




# Belt Clip

---

You can hang the cordless handset on your belt or pocket using the belt clip.

## To attach the belt clip



## To remove the belt clip




# Optional Headset

---

Plugging an optional headset into the cordless handset allows a hands-free phone conversation. Please use only the Panasonic KX-TCA88 headset. To order, call the accessories telephone number on page 2.

## Connecting the optional headset to the cordless handset

Open the headset jack cover, and connect the optional headset to the headset jack as shown below.




When the optional headset is connected to the cordless handset, make sure to use the headset to talk with the caller. If you want to have a normal cordless phone conversation, disconnect the headset.


# Battery Replacement

If "Recharge battery" is displayed and/or "[ ■ ]" flashes after a few telephone calls even if the battery was fully charged, replace the battery with a new Panasonic PQP510SVC (P-P510) battery. To order, call the accessories telephone number on page 2.


- 1 **Carefully** insert a flat metal object in the slot, and push forward to release the lock. Remove the cordless handset cover.



- 2 Replace the battery. Then place the battery leads inside the groove, otherwise the leads may be damaged when closing the cover.



- 3 Close the cover.



- 4 Make sure you charge the new battery for about 15 hours in order to display the battery strength prompt correctly (p. 11).


A nickel cadmium battery that is recyclable powers the product you have purchased. At the end of its useful life, under various state and local laws, it is illegal to dispose of this battery into your municipal waste stream. Please call 1-800-8-BATTERY for information on how to recycle this battery.



# Adding Another Phone

---

This unit will not function during a power failure. To connect a standard telephone on the same line, use the Panasonic T-adaptor KX-J66. To order, call the accessories telephone number on page 2.




## If the Following Appear...


---

If the unit detects a problem, one of the following messages will be displayed on the cordless handset or the base unit.


### Cordless handset display



The battery needs to be charged. Place the cordless handset on the charger to charge the battery (p. 12).



The cordless handset has lost communication with the base unit. Move closer to the base unit and try again.



When trying to store an item or Caller List information in the directory, the directory memory is full (p. 36, 40). To erase other stored items from the directory, see page 46.

Base in use

While the base unit was being used,  or  was pressed to search the Caller List/directory list,  was pressed to select an option or **CLEAR/INTERCOM/HOLD** was pressed.

Save error

While storing items in the directory, the cordless handset has lost communication with the base unit. Move closer to the base unit and try again.

Line in use

{■■■■}

The display will be shown while the base unit is engaged in an outside call.

## Base unit display

⏰ 12:00AM JAN. 1 ⏰

When the clock needs adjusting, the time and date flashes. Adjust the clock (p. 13).

Line in use

The display will be shown while the cordless handset is engaged in an outside call.

Portable in use

While the cordless handset was being used,  or  was pressed to search the Caller List/directory list or **FUNCTION/EDIT** or **VM** was pressed.

# Troubleshooting

## Cordless handset

Problem	Cause and Remedy
"No link to base. Walk closer to base & try again" is displayed on the cordless handset display and an alarm tone sounds.	<ul style="list-style-type: none"><li>● You are too far from the base unit. Move closer and try again.</li><li>● Raise the base unit antennas.</li><li>● Plug in the AC adaptor of the base unit.</li><li>● The cordless handset may lose communication with the base unit. Set the security code (p. 59).</li></ul>
Static, sound cuts in/out, fades. Interference from other electrical units.	<ul style="list-style-type: none"><li>● Locate the cordless handset and the base unit away from other electrical appliances (p. 3).</li><li>● Move closer to the base unit.</li><li>● Raise the base unit antennas.</li><li>● Press  to select a clearer channel in the talk or intercom mode.</li></ul>
The cordless handset does not ring.	<ul style="list-style-type: none"><li>● The ringer volume is set to OFF. Set to HIGH or LOW (p. 20).</li></ul>
The cordless handset display is blank.	<ul style="list-style-type: none"><li>● Charge the battery fully (p. 11).</li></ul>
You cannot store a name and phone number in the directory.	<ul style="list-style-type: none"><li>● You cannot store an item in the directory while the base unit is in the talk or intercom mode.</li><li>● Do not pause for over 60 seconds while storing.</li></ul>
While programming or searching, the unit starts to ring and stops the program/search.	<ul style="list-style-type: none"><li>● To answer the call, press . Start again from the beginning after hanging up.</li></ul>



Problem	Cause and Remedy
The cordless handset does not display the caller's name and/or phone number.	<ul style="list-style-type: none"><li>● You need to subscribe to a Caller ID service.</li><li>● Other telephone equipment may be interfering with your phone. Disconnect it and try again.</li><li>● Other electrical appliances connected to the same outlet may be interfering with the Caller ID information.</li><li>● Telephone line noise may be affecting the Caller ID information.</li></ul>
The cordless handset display exits the Caller List or directory.	<ul style="list-style-type: none"><li>● Do not pause for over 60 seconds while searching.</li></ul>
When a second call is received during a conversation, the cordless handset does not display the new caller's name and/or phone number.	<ul style="list-style-type: none"><li>● The line mode selection is incorrect. See page 16.</li><li>● The caller requested not to send his/her information. See page 29.</li></ul>
You cannot page the base unit.	<ul style="list-style-type: none"><li>● The cordless handset is too far from the base unit.</li><li>● The base unit is engaged in an outside call, viewing the Caller List/directory list. Try again later. Wait until "Base in use" disappears.</li></ul>
You cannot redial by pressing <b>REDIAL/PAUSE</b> .	<ul style="list-style-type: none"><li>● If the last number dialed was more than 32 digits long, the number will not be redialed correctly.</li><li>● The button has a double function as either redial or pause. It will redial the last number dialed if pressed at the outset of a call (p. 24). If another number has been dialed first, it will operate as a pause button (p. 57).</li></ul>

## ► Troubleshooting

Problem	Cause and Remedy
You cannot have a conversation using the cordless handset.	<ul style="list-style-type: none"><li>●When the optional headset is connected (p. 62), you must use the headset to talk with the caller. To have a normal cordless phone conversation, disconnect the headset.</li></ul>
You cannot have a conversation using the optional headset.	<ul style="list-style-type: none"><li>●Make sure that the headset is connected properly (p. 62).</li></ul>

### Base unit

Problem	Cause and Remedy
The base unit does not ring.	<ul style="list-style-type: none"><li>●The ringer volume is set to OFF. Select HIGH or LOW (p. 20).</li></ul>
While programming or searching, the base unit starts to ring and stops the program/search.	<ul style="list-style-type: none"><li>●To answer the call, lift the handset or press <b>DIGITAL SP-PHONE</b>. Start again from the beginning after hanging up.</li></ul>
The base unit does not display the caller's name and/or phone number.	<ul style="list-style-type: none"><li>●You need to subscribe to a Caller ID service.</li><li>●Other telephone equipment may be interfering with your phone. Disconnect it and try again.</li><li>●Other electrical appliances connected to the same outlet may be interfering with the Caller ID information.</li><li>●Telephone line noise may be affecting the Caller ID information.</li></ul>
The base unit display exits the Caller List.	<ul style="list-style-type: none"><li>●Do not pause for over 60 seconds while searching.</li></ul>
When a second call is received during a conversation, the base unit does not display the new caller's information.	<ul style="list-style-type: none"><li>●The line mode selection is incorrect. See page 16.</li><li>●The caller requested not to send his/her information. See page 29.</li></ul>



Problem	Cause and Remedy
You cannot page a cordless handset.	<ul style="list-style-type: none"><li>● The cordless handset is too far from the base unit.</li><li>● The cordless handset is engaged in an outside call or viewing the Caller List/directory list. Try again. Wait until “Portable in use” disappears.</li></ul>
You cannot redial by pressing <b>REDIAL</b> .	<ul style="list-style-type: none"><li>● If the last number dialed was more than 32 digits long, the number will not be redialed correctly.</li></ul>

## General

Problem	Cause and Remedy
The unit does not work.	<ul style="list-style-type: none"><li>● Check the settings (p. 10–16).</li><li>● Charge the battery fully (p. 11).</li><li>● Clean the charge contacts and charge again (p. 12).</li><li>● Install the battery properly (p. 63).</li><li>● Place the cordless handset on the charger and unplug the AC adaptor of the base unit to reset. Plug in, and try again.</li></ul>
You cannot program items, such as the dialing mode.	<ul style="list-style-type: none"><li>● Programming is not possible while the unit is in the talk, speakerphone or intercom mode, or when viewing the Caller List/directory list.</li><li>● Do not pause for over 60 seconds while programming.</li><li>● Move closer to the base unit, if you use the cordless handset.</li><li>● Make sure that the unit is not being used.</li></ul>

## ► Troubleshooting

---

Problem	Cause and Remedy
Previously programmed information is erased.	<ul style="list-style-type: none"><li>● If a power failure occurs, programmed information may be erased. Reprogram if necessary.</li></ul>
“Recharge battery” is displayed on the cordless handset, “[ ■ ]” flashes or the unit beeps intermittently.	<ul style="list-style-type: none"><li>● Charge the battery fully (p. 11).</li></ul>
You charged the battery fully, but “Recharge battery” is still displayed and/or “[ ■ ]” continues to flash.	<ul style="list-style-type: none"><li>● Clean the charge contacts and charge again (p. 12).</li><li>● Install a new battery (p. 63).</li></ul>
If you cannot solve your problem	<ul style="list-style-type: none"><li>● Call our customer call center at 1-800-211-PANA(7262).</li><li>● Panasonic’s e-mail address for customer inquiries: consumerproducts@panasonic.com for customers in the USA or Puerto Rico ONLY</li></ul>

# Important Safety Instructions



When using this unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on this unit.
3. Unplug this unit from AC outlets before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this unit near water, for example, near a bathtub, washbowl, kitchen sink, or the like.
5. Place this unit securely on a stable surface. Serious damage and/or injury may result if the unit falls.
6. Do not cover slots and openings on the unit. They are provided for ventilation and protection against overheating. Never place the unit near radiators, or in a place where proper ventilation is not provided.
7. Use only the power source marked on the unit. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
8. Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.
9. Do not overload wall outlets and extension cords. This can result in the risk of fire or electric shock.
10. Never push any objects through slots in this unit. This may result in the risk of fire or electric shock. Never spill any liquid on the unit.
11. To reduce the risk of electric shock, do not disassemble this unit. Take the unit to an authorized servicer when service is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the unit is subsequently used.
12. Unplug this unit from the wall outlet and refer servicing to an authorized servicer when the following conditions occur:
  - A. When the power supply cord or plug is damaged or frayed.
  - B. If liquid has been spilled into the unit.
  - C. If the unit has been exposed to rain or water.
  - D. If the unit does not work normally by following the operating instructions. Adjust only controls covered by the operating instructions. Improper adjustment may require extensive work by an authorized servicer.
  - E. If the unit has been dropped or physically damaged.
  - F. If the unit exhibits a distinct change in performance.
13. During thunderstorms, avoid using telephones except cordless types. There may be a remote risk of an electric shock from lightning.
14. Do not use this unit to report a gas leak, when in the vicinity of the leak.

## SAVE THESE INSTRUCTIONS

## ► Important Safety Instructions

---

### **CAUTION:**

To reduce the risk of fire or injury to persons, read and follow these instructions.

1. Use only the battery(ies) specified.
2. Do not dispose of the battery(ies) in a fire. They may explode. Check with local waste management codes for special disposal instructions.
3. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
4. Exercise care in handling batteries in order not to short the battery to conductive materials such as rings, bracelets, and keys. The battery and/or conductor may overheat and cause burns.
5. Charge the battery(ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.

### **WARNING:**

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

- The AC adaptor is used as the main disconnect device, ensure that the AC outlet is located/installed near the unit and is easily accessible.

# FCC and Other Information



This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:ACJ-----.

If requested, this number must be provided to the telephone company.

Registration No. . . . . (found on the bottom of the unit)  
Ringer Equivalence No. (REN) . . . . . 0.1B

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3).

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact a Factory Servicenter or other Authorized Servicer. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

## WHEN PROGRAMMING EMERGENCY NUMBERS AND(OR) MAKING TEST CALLS TO EMERGENCY NUMBERS:

- 1) Remain on the line and briefly explain to the dispatcher the reason for the call.
- 2) Perform such activities in the off-peak hours, such as early morning or late evenings.

## ► FCC and Other Information

---

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this phone.

### **CAUTION:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

### **Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference is experienced, move the cordless telephone further away from the TV or VCR. This will often reduce, or eliminate, interference.

Operating near 2.4GHz electrical appliances may cause interference. Move away from the electrical appliances and/or press the CH (channel) button.

### **CAUTION:**

To comply with FCC RF exposure requirements, the base unit should be installed with its antenna located at 20 cm or more from persons and handset should be carried with the specific belt-clip provided for the handset to ensure compliance. Other non-tested belt-clips or similar body-worn accessories may not comply, therefore, should be avoided.

This equipment is hearing aid compatible as defined by the FCC in 47 CFR Section 68.316.

When you hold the phone to your ear, noise might be heard in your Hearing Aid. Some Hearing Aids are not adequately shielded from external RF (radio frequency) energy. If noise occurs, use an optional headset accessory or the speakerphone option (if applicable) when using this phone. Consult with your audiologist or Hearing Aid manufacturer about the availability of Hearing Aids which provide adequate shielding to RF energy commonly emitted by digital devices.

- 
- **Environment**—do not place the unit in a room where the temperature is less than 5°C (41°F) or greater than 40°C (104°F). Allow 10 cm (4") clearance around the unit for proper ventilation. Avoid excessive smoke, dust, mechanical vibration, shock, or direct sunlight.
  - **Medical**—consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The unit operates in the frequency range of 2401MHz to 2472MHz and the power output level can range from 0.001 watts to 0.20 watts.) Do not use the unit in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF (radio frequency) energy.
  - **Routine care**—wipe the unit with a soft cloth. Do not use benzine, thinner, or any abrasive powder. When you leave the unit unused for a long period of time, unplug the AC adaptor from the outlet.
  - **If there is any trouble**—disconnect the unit from the telephone line and connect a known working phone. If the known working phone operates properly, have your unit repaired by one of the authorized Panasonic Factory Service Centers. If the known working phone does not operate properly, consult your telephone company.

# Specifications

---

## ■ Base unit

<b>Power Supply:</b>	AC Adaptor (120 V AC, 60 Hz)
<b>Power Consumption:</b>	Standby: Approx. 3.0 W Maximum: Approx. 7.0 W
<b>Frequency:</b>	2.401 GHz – 2.471 GHz
<b>Dimensions (H × W × D):</b>	Approx. 90 mm × 192 mm × 210 mm (3 17/32" × 7 9/16" × 8 1/4")
<b>Mass (Weight):</b>	Approx. 720 g (1.59 lb.)

## ■ Charger

<b>Power Supply:</b>	AC Adaptor (120 V AC, 60 Hz)
<b>Power Consumption:</b>	Standby: Approx. 1.0 W Maximum: Approx. 4.0 W
<b>Dimensions (H × W × D):</b>	Approx. 73 mm × 94 mm × 101 mm (2 7/8" × 3 11/16" × 3 31/32")
<b>Mass (Weight):</b>	Approx. 160 g (0.35 lb.)

## ■ Cordless handset

<b>Power Supply:</b>	Ni-Cd battery (3.6 V, 850 mAh)
<b>Frequency:</b>	2.401 GHz – 2.471 GHz
<b>Dimensions (H × W × D):</b>	Approx. 37 mm × 58 mm × 217 mm (1 15/32" × 2 9/32" × 8 17/32")
<b>Mass (Weight):</b>	Approx. 220 g (0.49 lb.)
<b>Security Codes:</b>	1,000,000

■ **Dialing Mode:** Tone (DTMF)/Pulse

■ **Operating Environment:** 5 °C – 40 °C (41 °F – 104 °F)

Specifications are subject to change without notice.

PANASONIC CONSUMER  
ELECTRONICS COMPANY, DIVISION  
OF MATSUSHITA ELECTRIC  
CORPORATION OF AMERICA  
One Panasonic Way  
Secaucus, New Jersey 07094

PANASONIC SALES COMPANY,  
DIVISION OF MATSUSHITA  
ELECTRIC OF PUERTO RICO, INC.,  
Ave. 65 de Infanteria, Km. 9.5  
San Gabriel Industrial Park  
Carolina, Puerto Rico 00985

## Panasonic Telephone Products Limited Warranty

### Limited Warranty Coverage

If your product does not work properly because of a defect in materials or workmanship, Panasonic Consumer Electronics Company or Panasonic Sales Company (collectively referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

Parts	Labor
One (1) Year	One (1) Year

During the "Labor" warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty excludes both parts and labor for batteries, antennas, and cosmetic parts (cabinet). This warranty only applies to products purchased and serviced in the United States or Puerto Rico. This warranty is extended only to the original purchaser of a new product which was not sold "as is".

### Mail-In Service

For assistance in the continental U.S.A. in obtaining repairs please ship the product to:

**Panasonic Services Company**  
**Customer Servicenter**  
**Suite B**  
**4900 George McVay Drive**  
**McAllen, TX 78503**

For assistance in Puerto Rico call Panasonic Sales Company (787)-750-4300 or fax (787)-768-2910.

When shipping the unit carefully pack and send it prepaid, adequately insured and preferably in the original carton. Include a letter detailing the complaint and provide a day time phone number where you can be reached.

**IF REPAIR IS NEEDED DURING THE WARRANTY PERIOD THE PURCHASER WILL BE REQUIRED TO FURNISH A SALES RECEIPT/PROOF OF PURCHASE INDICATING DATE OF PURCHASE, AMOUNT PAID AND PLACE OF PURCHASE. CUSTOMER WILL BE CHARGED FOR THE REPAIR OF ANY UNIT RECEIVED WITHOUT SUCH PROOF OF PURCHASE.**

### Limited Warranty Limits And Exclusions

This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Factory Servicenter or other Authorized Servicer, or damage that is attributable to acts of God.

**THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY.** (As examples, this excludes damages for lost time, lost calls or messages, cost of having someone remove or re-install an installed unit if applicable, travel to and from the servicer. The items listed are not exclusive, but are for illustration only.) **ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Servicer. If the problem is not handled to your satisfaction, then write to the warrantor's Consumer Affairs Department at the addresses listed for the warrantor.

**PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.**

## ***Customer Services Directory***

***For Product Information, Operating Assistance, Literature Request, Dealer Locations, and all Customer Service inquiries please contact: 1-800-211-PANA (7262), Monday-Friday 9 am-9 pm; Saturday-Sunday 9 am-7 pm, EST. or send e-mail : consumerproducts@panasonic.com***

***Web Site: <http://www.panasonic.com>  
You can purchase parts, accessories or locate your nearest servicer by visiting our Web Site.***

### ***Accessory Purchases:***

**1-800-332-5368 (Customer Orders Only)  
Panasonic Services Company 20421 84th Avenue South, Kent, WA 98032  
(6 am to 5 pm Monday - Friday; 6 am to 10:30 am Saturday; PST)  
(Visa, MasterCard, Discover Card, American Express, Check)**

***Service in Puerto Rico  
Matsushita Electric of Puerto Rico, Inc. Panasonic Sales Company/  
Factory Servicer:  
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park,  
Carolina, Puerto Rico 00985  
Phone (787)750-4300 Fax (787)768-2910***

# Index

<b>A</b> Accessories..... 2	<b>I</b> Installation
Answering calls	AC adaptor..... 10
Base Unit..... 28	Adding another phone..... 64
Cordless Handset..... 28	Charger unit..... 11
Auto talk..... 19, 28	Corded handset..... 10
<b>B</b> Backlit LCD..... 25, 27	Telephone line cord..... 10
Base location..... 3	Intercom call..... 49
Battery, Charge..... 3, 11	Intercom paging..... 49
Battery information..... 12	<b>L</b> LCD contrast..... 21, 22
Battery replacement..... 63	Lighted cordless
Battery strength..... 11	handset keypad..... 25
Belt Clip..... 62	Line mode..... 16
<b>C</b> Call on hold..... 25, 27	Listening to
Call waiting caller ID..... 57	voice mail messages..... 55
Call waiting tone..... 57	Location of controls..... 6, 7, 8, 9
Caller ID	<b>M</b> Making Calls
Auto edit feature..... 32, 34	Base Unit..... 26
Caller ID service..... 14, 28, 29	Cordless Handset..... 23, 24
Caller List	Microphone..... 26, 28, 49
editing..... 32, 33	Muting a conversation..... 56
erasing..... 37, 38	<b>N</b> Noise..... 3
storing..... 36	<b>O</b> One-Touch Dialer..... 47
viewing..... 30	Dialing..... 48
Calling back	Storing..... 47
from Caller ID List..... 31	<b>P</b> PAUSE..... 57
Conference call..... 51	Pulse service..... 56
<b>D</b> Date and time..... 13	<b>R</b> Redial..... 24, 26
Dialing mode..... 15	Ringer Off..... 20
Directory..... 39	Ringer Volume..... 20
dialing..... 44	Rotary service, tone dialing..... 56
editing..... 45	<b>S</b> Safety Instructions..... 71
erasing..... 46	Security code setting..... 59
finding..... 42	Shipping product for
name and symbols..... 41	service..... Back cover
storing..... 39	Speakerphone..... 26
Displays..... 9	Specifications..... 76
<b>E</b> Error messages, base display..... 65	<b>T</b> Transferring a call..... 50
Error messages, cordless	Troubleshooting
handset display..... 64	Base Unit..... 68
<b>F</b> FCC and other information..... 73	Cordless Handset..... 66
FLASH button..... 58	General..... 69
Flash time..... 58	<b>V</b> Voice mail access number..... 52
Function Menu..... 17, 18	Voice mail tone..... 54
<b>H</b> Headset, optional..... 62	Volume control
Hold alarm..... 25, 27	Base Unit..... 27, 50
	Cordless Handset..... 25
	<b>W</b> Wall mounting
	Base unit..... 60
	Charger unit..... 61
	Warranty..... 77

## For product service

- Call 1-800-211-PANA(7262) for the location of an authorized servicer.
- Panasonic's e-mail address for customer inquiries: [consumerproducts@panasonic.com](mailto:consumerproducts@panasonic.com) for customers in the USA or Puerto Rico ONLY

## When you ship the product

- Carefully pack your unit, preferably in the original carton.
- Attach a letter, detailing the symptom, to the outside of the carton.

Symptom

---

- Send the unit to an authorized servicer, prepaid and adequately insured.
- Do not send your unit to the Panasonic Consumer Electronics Company listed below or to executive or regional sales offices. These locations do not repair consumer products.

- This cordless telephone is designed for use in the United States of America. Sale or use of this product in other countries may violate local laws.
- Ce téléphone sans fil est conçu pour être utilisé aux États-Unis d'Amérique. La vente ou l'emploi de cet appareil dans certains autres pays peut constituer une infraction à la législation locale.
- Este teléfono sin cordón fue elaborado para uso en los Estados Unidos de América. La venta o el empleo de este producto en ciertos países puede constituir violación de la legislación local.
- このコードレス電話機は、日本国外での使用を目的として設計されており、日本国内での使用は法律違反となります。従って、当社では日本国内においては原則として修理などのサービスは致しかねます。

**If you need assistance with the set-up or operation,  
please call 1-800-211-PANA(7262)**

**Panasonic Consumer Electronics Company,  
Division of Matsushita Electric Corporation of America**  
One Panasonic Way, Secaucus, New Jersey 07094

**Panasonic Sales Company,  
Division of Matsushita Electric of Puerto Rico, Inc.**  
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park  
Carolina, Puerto Rico 00985