



Call Assistant™ Intercom Autodialer with Busy Indication (Model CA48)

*For AT&T PARTNER-model phones at extensions 10 and 11
on PARTNER® Plus and PARTNER® II Communications Systems*

Installation Instructions

Important Safety Instructions

Always follow these basic safety precautions when using this product:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Never spill liquid on the product or drop objects into the slots and openings. Doing so may result in serious damage to the components.
4. Repair or service must be performed by a qualified repair person.
5. DO NOT use the product near water or in a wet or damp place (such as a basement).
6. To power this product, use only the power supply assembly specified in "Description" on the next page.

SAVE THESE INSTRUCTIONS

Copyright © 1995 AT&T
All rights reserved
Printed in U.S.A.

Comcode 107542672
October 1995 (Issue 1)

PARTNER is a registered trademark and Call Assistant is a trademark of AT&T.

Description

The installation instructions provided below tell you how to connect the Intercom Autodialer to the PARTNER-model phone at extension 10 or 11. For information about programming and using the Intercom Autodialer, see “Intercom Autodialers” in Chapter 1 and “Auto Dialing” in Chapter 5 of the *Programming and Use* guide.

Before starting, be sure you have the necessary parts (one autodialer, one adapter, one D8W line cord, one power cord, one power unit, and one button labeling sheet.)



CAUTION:

Be sure that the power supply assembly is the correct one for your country. Check the code on the power supply assembly box:

<i>U.S.</i>	<i>107525503</i>
<i>Canada</i>	<i>107637498</i>
<i>Other Countries</i>	<i>107525511</i>

If any part is missing or the power supply assembly is incorrect, in the continental U.S., call the AT&T hotline at 1 800 628-2888. Outside the continental U.S., contact your AT&T Representative or local Authorized Dealer.

Installation

1. Plug the adapter into the wall jack.
2. Connect the D8W line cord:
 - a. Plug one end of the D8W line cord into the J1 jack on the adapter.
 - b. Plug the other end into the IN jack on the bottom of the autodialer.
3. Connect the power cord and power unit:
 - a. Plug the blue-tinted connector (labeled D8AC) of the power cord into the jack on the power unit.
 - b. Plug the other end (clear tinted) of the power cord into the J2 jack on the adapter.
 - c. Plug the power unit into an electrical outlet.
4. Plug the phone's modular telephone cord into the OUT jack on the bottom of the autodialer.

5. Arrange the autodialer on the desk next to the phone, then:
 - a. Remove the plastic cover from the autodialer and label the button sheet with employee names. Place the button sheet back on the autodialer, then carefully replace the plastic cover.
 - b. Adjust the height of the autodialer to match the phone.

IMPORTANT:

If you unplug the system phone that is connected to an autodialer, you must reset the autodialer. To do so, unplug the D8W line cord (connected to the IN jack on the bottom of the autodialer) from the J1 jack on the adapter, then plug it back in.

