



## Voice Messaging Wallet Card

AT&T 585-300-704

Graphics © AT&T 1988 Comcode 106710163

### ACTIVITY MENU

- Record and Send Messages (record, edit, address, deliver) 1
- Get and Respond to Messages (retrieve, sort/save, respond) ABC  
2
- Create Personal Greetings (record, edit, activate) DEF  
3
- Check Outgoing Messages (retrieve, sort/save, review/modify, resend) GHI  
4
- Change Password/Create Lists/Personal Directories (create, review/modify, scan) JKL  
5
- Scan Messages Quickly (and/or headers) PRS  
7

### BASIC COMMANDS

Help	*4 or *H
Restart at Activity Menu	*7 or *R
Wait	*9 or *W
Transfer to an extension	*8 or *T
Look up name/extension	**6 or **N
Exit system	**9 or **X
Transfer call to operator	*0
Delete	*3 or *D
Undelete (may not be available with your system)	**8 or **U
Hold message in category	**4 or **H
Relog in	**7 or **R
Skip call answer greeting	1

#### Use while addressing:

Alternate addressing (switch between name/ext.)	*2 or *A
Use mailing list	*5 or *L

### PLAY-BACK CONTROLS

	Rewind	Play/Pause
<span style="border: 1px solid black; padding: 2px;">1</span>	<span style="border: 1px solid black; padding: 2px;">ABC 2</span>	<span style="border: 1px solid black; padding: 2px;">DEF 3</span>
Louder	Back Up	Advance
<span style="border: 1px solid black; padding: 2px;">GHI 4</span>	<span style="border: 1px solid black; padding: 2px;">JKL 5</span>	<span style="border: 1px solid black; padding: 2px;">MNO 6</span>
Softer	Slower	Faster
<span style="border: 1px solid black; padding: 2px;">PRS 7</span>	<span style="border: 1px solid black; padding: 2px;">TUV 8</span>	<span style="border: 1px solid black; padding: 2px;">WXY 9</span>
	Listen/Replay	Skip
<span style="border: 1px solid black; padding: 2px;">*</span>	<span style="border: 1px solid black; padding: 2px;">Oper 0</span>	<span style="border: 1px solid black; padding: 2px;">#</span>

Press 3 to pause and 3 again to continue. Q=7 Z=9

Voice Messaging Wallet Card  
585-300-704, Issue 2, 11/93