

MERLIN LEGEND† Communications System

Copyright © 1992 AT&T

Release 2.0, Issue 1, 10/92

† Trademark of AT&T

To order additional copies of these cards, call the
AT&T Customer Information Center at 1-800-432-6600.
 Ask for Select Code 555-620-151.

To Program:

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Press [Feature] then dial 00. 2. Press [Feature] and dial a speed dial code (01-24). 3. Dial the telephone number. | <ol style="list-style-type: none"> 4. Write the name or number next to the code below. 5. Repeat steps 2-4 to program additional numbers. 6. Press [Feature] then dial *00. |
|---|---|

To Use: Press **[Feature]** and dial a speed dial code (01-24).

Name	Code	Name	Code
	01		13
	02		14
	03		15
	04		16
	05		17
	06		18
	07		19
	08		20
	09		21
	10		22
	11		23
	12		24

(For use only with MLX-10† telephones)

Personal Speed Dial List

MERLIN LEGEND† Communications System
 Copyright © 1992 AT&T Release 2.0, Issue 1, 10/92
 † Trademark of AT&T

**To order additional copies of these cards, call the
 AT&T Customer Information Center at 1-800-432-6600.
 Ask for Select Code 555-620-151.**

Conference Calls	Transfer Calls
<ol style="list-style-type: none"> 1. Dial first extension or number 2. Press Conf 3. For phones with ICOM buttons, press line or ICOM button 4. Dial next extension or number 5. Announce call and press Conf 6. Repeat steps 2-5 for each participant 7. Hang up to end conference <ul style="list-style-type: none"> ■ Press Drop and line button to drop single participant ■ Press Hold to temporarily leave conference ■ Press any participant's line button to rejoin conference 	<p>Unannounced Transfer</p> <ol style="list-style-type: none"> 1. Press Transfer 2. Press line or SA button 3. Dial extension or number 4. Press Transfer or hang up <p>Announced Transfer</p> <ol style="list-style-type: none"> 1. Press Transfer 2. Press line or SA button 3. Dial extension or number 4. Announce call 5. Press Transfer or hang up <p>One-Touch Manual Transfer</p> <ol style="list-style-type: none"> 1. Press Auto Dial button 2. Announce call 3. Press Transfer or hang up <p>One-Touch Auto Transfer</p> <ol style="list-style-type: none"> 1. Press Auto Dial <p>Camp-On</p> <ol style="list-style-type: none"> 1. Press programmed Camp-On button or press Feature and dial 57
Conference and Transfer	

MERLIN LEGEND† Communications System

Copyright © 1992 AT&T

Release 2.0, Issue 1,10/92

† Trademark of AT&T

To order additional copies of these cards, call the AT&T Customer Information Center at 1-800-432-6600. Ask for Select Code 555-620-151.

To Use:

Lift handset or press **[Speaker]**. Press **[Feature]** and dial a 3-digit system speed dial code. See your System Manager for these codes.

Name	Code	Name	Code

System Speed Dial List

MERLIN LEGEND† Communication System

Copyright © 1992 AT&T

Release 2.0, Issue 1, 10/92

† Trademark of AT&T

To order additional copies of these cards, call the
AT&T Customer Information Center at 1-800-432-6600.
Ask for Select Code 555-620-151.

Follow these instructions when using features that you
have not programmed onto buttons on your telephone.

1. Press [Feature].

2. Dial the code.

Feature	Feature Code
Account Code Entry	82+ account code + #
Call Waiting Pickup	87
Callback-Selective	5 5
To cancel:	<u>[Drop]</u> + line button
Camp On	57
Forward/Follow Me	From your phone: 33 + other ext. no. From other phone: 34 + your ext. no.
To cancel from your phone:	33 + your ext. no.
To cancel from other phone:	*34 + your ext. no.
To cancel All:	*34 *(Cancels <i>all</i> forward/follow calls to your phone)
Group Pickup	88
Last Number Dial	84
Pickup	9+ ext. no. or line no.
Privacy	31
To cancel:	31
Recall	* 775

Feature Codes

MERLIN LEGEND† Communications System

Copyright © 1992 AT&T

Release 2.0, Issue 1, 10/92

† Trademark of AT&T

To order additional copies of these cards, call the
AT&T Customer Information Center at 1-800-432-6600.
Ask for Select Code 555-620-151.

Follow these instructions to program a feature onto a button.

1. Write the feature name next to a button.
2. Press [Feature] and dial 00.
3. Press the button you labeled.
4. Dial the programming code.
5. Press [Feature] and dial *00.

Feature	Programming Code
Account Code Entry	* 82
Auto Dial - Outside No.	* 21 + phone no.
- Inside No.	* 22+ ext. no.
Callback-Selective	* 55
Camp On	* 57
Coverage - Primary	* 40+ ext. no.
- Secondary	* 41 + ext. no.
- Group	* 42+ group no.
Coverage Off	* 49
Do Not Disturb	* 47
Forward	* 33
Group Pickup	* 88
Last Number Dial	* 84
Park	* 86
Pickup	* 9 + ext. no. or line no.
Privacy	* 31
Recall	* 775
Saved Number Dial	* 85

Button Programming